

Car Manual - Honda Civic 2024

Chapter 1: Starting Your Vehicle

To start your Honda Civic, insert the key into the ignition or press the push-button start while keeping your foot on the brake pedal. The engine will crank and start within a few seconds. Make sure the transmission is in Park before starting the engine. If the engine does not start, check the battery and fuel level.

Chapter 2: Tire Maintenance

Check your tire pressure at least once a month using a tire pressure gauge. The recommended tire pressure for the Honda Civic is 32 PSI for both front and rear tires. Underinflated tires can decrease fuel efficiency and cause uneven tire wear. Rotate your tires every 5000 to 7500 miles to ensure even wear across all four tires.

Chapter 3: Oil Change

The Honda Civic requires an oil change every 7500 miles or every 12 months, whichever comes first. Use 0W-20 full synthetic motor oil for optimal engine performance. The oil filter should be replaced with every oil change. Check the oil level regularly using the dipstick located near the front of the engine.

Chapter 4: Battery Care

The battery in your Honda Civic is a 12-volt battery located under the hood. Inspect battery terminals for corrosion regularly and clean them with a baking soda solution if needed. If the battery is more than 3 years old, have it tested annually at a service center. Jump-starting instructions: connect the positive cable first, then the negative cable.

Chapter 5: Brake System

The Honda Civic uses disc brakes on all four wheels. Brake pads should be inspected every 15000 miles. Replace brake pads when the friction material is less than 2mm thick. Brake fluid should be replaced every 3 years regardless of mileage. If you notice squealing or grinding noises when braking, have the brakes inspected immediately.