Userspace ALSA

alsa-lib

alsa-lib

- The main way to interact with ALSA devices is to use alsa-lib.
- `https://github.com/alsa-project/alsa-lib`
- It provides mainly access to the devices but also goes further and allows handling audio in userspace.
- The library itself is actually named
- The include file is `/asoundlib.h`

alsa-lib API

- ```
  int snd_pcm_open(snd_pcm_t ** pcmp, const char * name, snd_pcm_stream_t stream, int mode)
  ```
- is the name of the PCM to be opened.
- can be either `\_PCM\_STREAM\_PLAYBACK` or `\_PCM\_STREAM\_CAPTURE`
- can be a combination of `\_PCM\_NONBLOCK` and `\_PCM\_ASYNC`
- ```
  int snd_pcm_close(snd_pcm_t *pcm)
  ```
- Closes the PCM.

PCM name

- This can be specified as a hardware device. The three arguments (in order: CARD,DEV,SUBDEV) specify card number or identifier, device number and subdevice number (-1 means any). For example: `:0` or `:1,0`. Instead of the index, the card name can be used: `:STM32MP15DK,0`
- Or through the plugin: `:mypcmdef`, `:hw:0,0`.
- The list of available names can be generated using `\_card\_next` to iterate over all the physical cards. See `\_list` in .

alsa-lib API - PCM

- The next step is to handle the PCM stream parameters
- ```
  snd_pcm_hw_params_t *hw_params;
  int snd_pcm_hw_params_malloc(snd_pcm_hw_params_t ** ptr)
  int snd_pcm_hw_params_any(snd_pcm_t * pcm, snd_pcm_hw_params_t *
  params)
  ```
- This will allocate a `\_pcm\_hw\_params\_t` and fill it with the range of parameters supported by .
- ```
  int snd_pcm_hw_params_set_access(snd_pcm_t *pcm, snd_pcm_hw_params_t
  *params,
                                   snd_pcm_access_t _access)
  ```
- This set the proper access type: interleaved or non-interleaved, mmap or not.

alsa-lib API - PCM

```
int snd_pcm_hw_params_set_format(snd_pcm_t *pcm, snd_pcm_hw_params_t
*params,
                                 snd_pcm_format_t val)
```

- This set the format, using a `\_PCM\_FORMAT\_` macro.

alsa-lib API - PCM

```
int snd_pcm_hw_params_set_channels(snd_pcm_t *pcm, snd_pcm_hw_params_t
*params,
                                   unsigned int val)
```

- Sets the number of channels.

```
int snd_pcm_hw_params_set_rate_near(snd_pcm_t *pcm, snd_pcm_hw_params_t
*params,
                                    unsigned int *val, int *dir)
```

- Sets the sample rate, setting to 0 will require the exact rate.

```
int snd_pcm_hw_params_set_periods(snd_pcm_t *pcm, snd_pcm_hw_params_t
*params,
                                  unsigned int val, int dir)
```

alsa-lib API - PCM

```
int snd_pcm_hw_params_set_period_size(snd_pcm_t *pcm,
snd_pcm_hw_params_t *params,
                                      snd_pcm_uframes_t val, int dir)
int snd_pcm_hw_params_set_buffer_size(snd_pcm_t *pcm,
snd_pcm_hw_params_t *params,
                                      snd_pcm_uframes_t val)
```

- Sets the number of periods and the period size in the buffer or the buffer size.

alsa-lib API - PCM

- ```
  int snd_pcm_hw_params(snd_pcm_t * pcm, snd_pcm_hw_params_t * params)
  ```
- Installs the parameters and calls `\_pcm\_prepare` on the stream.
- ```
  void snd_pcm_hw_params_free(snd_pcm_hw_params_t * obj)
  ```
- Frees the allocated `\_pcm\_hw\_params\_t`.
- ```
  int snd_pcm_prepare(snd_pcm_t * pcm)
  ```
- Prepares the stream.
- ```
  int snd_pcm_wait(snd_pcm_t * pcm, int timeout)
  ```

alsa-lib API - PCM

- Waits for the PCM to be ready.

alsa-lib API - PCM

```
snd_pcm_sframes_t snd_pcm_writei(snd_pcm_t *pcm, const void *buffer,
snd_pcm_uframes_t size)
snd_pcm_sframes_t snd_pcm_readi(snd_pcm_t *pcm, void *buffer,
snd_pcm_uframes_t size)
snd_pcm_sframes_t snd_pcm_writen(snd_pcm_t *pcm, void **bufs,
snd_pcm_uframes_t size)
snd_pcm_sframes_t snd_pcm_readn(snd_pcm_t *pcm, void **bufs,
snd_pcm_uframes_t size)
```

- Write or read from an interleaved or non-interleaved buffer.

```
int snd_pcm_mmap_begin(snd_pcm_t *pcm, const snd_pcm_channel_area_t
**areas,
                       snd_pcm_uframes_t *offset, snd_pcm_uframes_t
*frames)
snd_pcm_sframes_t snd_pcm_mmap_commit(snd_pcm_t *pcm, snd_pcm_uframes_t
```

alsa-lib API - PCM

```
offset,
                                        snd_pcm_uframes_t frames)
snd_pcm_sframes_t snd_pcm_mmap_writei(snd_pcm_t *pcm, const void
*buffer,
                                        snd_pcm_uframes_t size)
snd_pcm_sframes_t snd_pcm_mmap_readi(snd_pcm_t *pcm, void *buffer,
snd_pcm_uframes_t size)
snd_pcm_sframes_t snd_pcm_mmap_writen(snd_pcm_t *pcm, void **bufs,
snd_pcm_uframes_t size)
snd_pcm_sframes_t snd_pcm_mmap_readn(snd_pcm_t *pcm, void **bufs,
snd_pcm_uframes_t size)
```

- Write or read from an interleaved or non-interleaved mmap buffer.

alsa-lib API - controls

- It is possible to set controls programatically.
-
```
snd_ctl_t *handle;
int snd_ctl_open (snd_ctl_t **ctl, const char *name, int mode)
```
- Opens the sound card to be controlled.
-
```
snd_ctl_elem_id_t *id;
#define snd_ctl_elem_id_alloca(ptr)
snd_ctl_elem_value_t *value;
#define snd_ctl_elem_value_alloca(ptr)
```
- Allocate a `\_ctl\_elem\_id\_t`, referring to a particular control and a `\_ctl\_elem\_value\_t` to be set for this control.

alsa-lib API - controls

```
void snd_ctl_elem_id_set_interface(snd_ctl_elem_id_t *obj,
snd_ctl_elem_iface_t val)
void snd_ctl_elem_id_set_name(snd_ctl_elem_id_t *obj, const char *val)
```

- Set the interface and name of the control to be set.

alsa-lib API - controls

- A lookup is needed to fill the `\_ctl\_elem\_id\_t` completely

```
int lookup_id(snd_ctl_elem_id_t *id, snd_ctl_t *handle)
{
    int err;
    snd_ctl_elem_info_t *info;
    snd_ctl_elem_info_alloca(&info);

    snd_ctl_elem_info_set_id(info, id);
    if ((err = snd_ctl_elem_info(handle, info)) < 0) {
        return err;
    ```
    snd_ctl_elem_info_get_id(info, id);

    return 0;
```
```

alsa-lib API - controls

```
void snd_ctl_elem_value_set_id(snd_ctl_elem_value_t *obj, const
snd_ctl_elem_id_t *ptr)
```

- Links the value with the control id.

```
void snd_ctl_elem_value_set_boolean(snd_ctl_elem_value_t *obj, unsigned
int idx, long val)
void snd_ctl_elem_value_set_integer(snd_ctl_elem_value_t *obj, unsigned
int idx, long val)
void snd_ctl_elem_value_set_integer64(snd_ctl_elem_value_t *obj,
unsigned int idx,
                                      long long val)
void snd_ctl_elem_value_set_enumerated(snd_ctl_elem_value_t *obj,
unsigned int idx,
                                       unsigned int val)
void snd_ctl_elem_value_set_byte(snd_ctl_elem_value_t *obj, unsigned
```

alsa-lib API - controls

```
int idx,
                                    unsigned char val)
void snd_ctl_elem_set_bytes(snd_ctl_elem_value_t *obj, void *data,
size_t size)
```

- Set the value in `\_ctl\_elem\_value\_t`.
-
```
int snd_ctl_elem_write(snd_ctl_t *ctl, snd_ctl_elem_value_t *data)
```
- Actually set the control.

Going further

- UCM: The ALSA Use Case Configuration: https://www.alsa-project.org/alsa-doc/alsa-lib/group__ucm__conf.html
- ALSA topology: https://www.alsa-project.org/wiki/ALSA_topology

Using alsa-lib

```
tools to:

- Reorder channels

- Split channels

- Resample

- Mix samples
```

Going further

```
- Apply effects
```