

RomBoot

stored in ROM
in the CPU



U-Boot SPL

stored in MMC, NAND or SPI flash
runs from SRAM, initialize DRAM



Linux Kernel

stored in MMC, NAND, network...
runs from DRAM