06-1 Userspace Initialization - init.d

Chapter 6

Initialization

- Chapter 5 Kernel Initialization
- Chapter 6 Userspace Initialization

Chapter 6 - Userspace Initialization

- At startup
 - Kernel initializes
 - Mounts a root file system
 - Executes set of initialization routines
- We'll start with a minimal filesystem and build on it

Root File System:

Top-Level Directories

	Directory	Contents
tree	bin	Binary executables, usable by all users on the system
	dev	Device nodes (see Chapter 8, "Device Driver Basics")
bone\$ tree	etc	Local system configuration files
/ bin	home	User account files
dev etc	lib	System libraries, such as the standard C library and many others
home lib	sbin	Binary executables usually reserved for superuser accounts on the system
sbin usr	usr	A secondary file system hierarchy for application programs, usually read-only
var tmp	var	Contains variable files, such as system logs and temporary configuration files
_	tmp	Temporary files

Root File System: Top-Level Directories

```
bone$ sudo mkdir /mnt/eMMC
bone$ sudo mount /dev/mmcblk1p1 /mnt/eMMC/
bone$ tree -L 1 /mnt/eMMC
                                         bone$ tree -L 1
/mnt/eMMC
                  opt/
    - bin/
                  -proc/
    -boot/
                                           -- bin
                  -root/
    - dev/
                                           - dev
                  -run/
    etc/
                  -sbin/
                                            - etc
    -home/
                  -srv/
                                              home
    - lib/
                  - sys/
    - media/
                                              lib
                  <del>-</del> tmp/
    mnt/
                                              sbin
                  usr/
                  'var/
                                              usr
                                              var
                                               tmp
```

Minimal File System

```
busybox
                                   Later
      sn -> busybox
      console
      init.d
                  Symbolic
                   Link
    laes
    1d-2.3.2.so
   ld-linux.so.2 -> ld-2.3.2.so
    libc-2.3.2.so
     bc.so.6 -> libc-2.3.2.so
5 directories, 8 files
```


Page 138

- Final sequence of events for the kernel thread called kernel_init spawned by the kernel during the final stages of boot
- run_init_process() function never returns if no error conditions
- Memory space in which the calling thread is executing from is overwritten by the called program's memory image
- In effect, the called program directly replaces the calling thread, including inheriting its Process ID (PID)

Kernel's Last Boot Steps (.../init/main.c)

Page 138 (cont.)

- This is the start of user space processing
- Unless the kernel is successful in executing one of these processes, the kernel will halt, displaying the message passed in the **panic()** system call
- If you have been working with embedded systems for any length of time, and especially if you have experience working on root file systems, you are more than familiar with this kernel **panic()** and its message!
- If you search on Google for this **panic()** error message, you will find page after page of hits for this FAQ



run_init_process("/bin/sh");

panic("No init found. Try passing init=
option to kernel.");

First User Space Program

• Most systems: /sbin/init is spawned.

```
-- bin
  -- busybox
  '-- sh -> busybox
 -- dev
                                run_init_process("/sbin/init");
  '-- console
                                run init process("/etc/init");
  - etc
                                run init process("/bin/init");
  '-- init.d
                                run init process("/bin/sh");
  '-- rcs
                                                  Busybox is run
 - lib
                                                   as the initial
-- ld-2.3.2.so
-- ld-linux.so.2 -> ld-2.3.2.so
                                                    process
-- libc-2.3.2.so
'-- libc.so.6 -> libc-2.3.2.so
```

Resolving Dependencies

- You can't put just any program as init
- There may be dependencies

Customized Initial Process

console=ttyS0,115200 ip=bootp
root=/dev/nfs init=/sbin/myinit

The init process

- Use standard init
- Reads /etc/inittab

```
# /etc/inittab: init(8) configuration.
# $Id: inittab,v 1.91 2002/01/25 13:35:21 miquels Exp $

# The default runlevel.
id:5:initdefault:

# Boot-time system configuration/initialization script.
# This is run first except when booting in emergency (-b) mode.
si::sysinit:/etc/init.d/rcs
```

The init process

- # What to do in single-user mode.
- ~~:S:wait:/sbin/sulogin
- # /etc/init.d executes the S and K scripts upon change
- # of runlevel.
- #
- 10:0:wait:/etc/init.d/rc 0
- l1:1:wait:/etc/init.d/rc 1
- 12:2:wait:/etc/init.d/rc 2
- 13:3:wait:/etc/init.d/rc 3
- 14:4:wait:/etc/init.d/rc 4
- 15:5:wait:/etc/init.d/rc 5
- 16:6:wait:/etc/init.d/rc 6

The init process

- # Normally not reached, but fallthrough in case
 of emergency.

 z6:6:respawn:/sbin/sulogin

 s:2345:respawn:/sbin/getty 115200 ttyS2

 # /sbin/getty invocations for the runlevels.

 #

 # The "id" field MUST be the same as the last

 # characters of the device (after "tty").

 #

 # Format:

 # <id>:<runlevels>:<action>:<process>
 #
- 1:2345:respawn:/sbin/getty 38400 ttyl

Runlevels

Runlevel	Purpose	
0	System shutdown (halt)	
1	Single-user system configuration for maintenance	
2	User defined	
3	General purpose multiuser configuration	
4	User defined	
5	Multiuser with graphical user interface on startup	
6	System restart (reboot)	

- Runlevel scripts are found in /etc/rc.d/init.d/
- or /etc/init.d/

NFS Restart

```
$ /etc/rc.d/init.d/nfs restart
Shutting down NFS mountd: [ OK ]
Shutting down NFS daemon: [ OK ]
Shutting down NFS quotas: [ OK ]
Shutting down NFS services: [ OK ]
Starting NFS services: [ OK ]
Starting NFS quotas: [ OK ]
Starting NFS daemon: [ OK ]
Starting NFS mountd: [ OK ]
```

Runlevel Directory Structure on 4.4 Beagle

```
bone$ ls -dl /etc/rc*

drwxr-xr-x 2 root root 4096 Aug 28 11:26 /etc/rc0.d

drwxr-xr-x 2 root root 4096 Aug 28 11:26 /etc/rc1.d

drwxr-xr-x 2 root root 4096 Aug 28 11:26 /etc/rc2.d

drwxr-xr-x 2 root root 4096 Aug 28 11:26 /etc/rc3.d

drwxr-xr-x 2 root root 4096 Aug 28 11:26 /etc/rc3.d

drwxr-xr-x 2 root root 4096 Aug 28 11:26 /etc/rc4.d

drwxr-xr-x 2 root root 4096 Aug 28 11:26 /etc/rc5.d

drwxr-xr-x 2 root root 4096 Aug 28 11:26 /etc/rc6.d

-rwxr-xr-x 1 root root 306 Aug 28 11:18 /etc/rc.local

-rw-r--r-- 1 root root 101 Aug 28 11:21 /etc/rcn-ee.conf

drwxr-xr-x 2 root root 4096 Aug 28 11:27 /etc/rcs.d
```

Example Runlevel Directory on 4.4 Beagle

```
bone$ ls -ls /etc/rc5.d/
total 0
4 -rw-r--r-- 1 root root 677 Apr 6 2015 README
0 lrwxrwxrwx 1 root root 18 Aug 28 11:17 S01bootlogs -> ../init.d/bootlogs
0 lrwxrwxrwx 1 root root 17 Aug 28 11:21 S01hostapd -> ../init.d/hostapd
0 lrwxrwxrwx 1 root root 14 Aug 28 11:17 S01motd -> ../init.d/motd
0 lrwxrwxrwx 1 root root 17 Aug 28 11:21 S01rsyslog -> ../init.d/rsyslog
0 lrwxrwxrwx 1 root root 17 Aug 28 11:21 S02apache2 -> ../init.d/apache2
0 lrwxrwxrwx 1 root root 14 Aug 28 11:21 S03cron -> ../init.d/cron
0 lrwxrwxrwx 1 root root 14 Aug 28 11:21 S03dbus -> ../init.d/dbus
0 lrwxrwxrwx 1 root root 17 Aug 28 11:26 S03haveged -> ../init.d/haveged
0 lrwxrwxrwx 1 root root 21 Aug 28 11:21 S03loadcpufreg -> ../init.d/loadcpufreg
0 lrwxrwxrwx 1 root root 15 Aug 28 11:21 S03rsync -> ../init.d/rsync
0 lrwxrwxrwx 1 root root 13 Aug 28 11:21 S03ssh -> ../init.d/ssh
0 lrwxrwxrwx 1 root root 16 Aug 28 11:21 S03udhcpd -> ../init.d/udhcpd
0 lrwxrwxrwx 1 root root 22 Aug 28 11:21 S04avahi-daemon -> ../init.d/avahi-daemon
0 lrwxrwxrwx 1 root root 19 Aug 28 11:21 S04bluetooth -> ../init.d/bluetooth
0 lrwxrwxrwx 1 root root 17 Aug 28 11:21 S04connman -> ../init.d/connman
0 lrwxrwxrwx 1 root root 22 Aug 28 11:21 S04cpufrequtils -> ../init.d/cpufrequtils
0 lrwxrwxrwx 1 root root 18 Aug 28 11:21 S05rc.local -> ../init.d/rc.local
0 lrwxrwxrwx 1 root root 19 Aug 28 11:21 S05rmnologin -> ../init.d/rmnologin
```

Beagle 3.8

beagle\$ cat /etc/init.d/README

You are running a systemd-based OS where traditional init scripts have been replaced by native systemd services files. Service files provide very similar functionality to init scripts. To make use of service files simply invoke "systemctl", which will output a list of all currently running services (and other units). Use "systemctl list-unit-files" to get a listing of all known unit files, including stopped, disabled and masked ones. Use "systemctl start foobar.service" and "systemctl stop foobar.service" to start or stop a service, respectively. For further details, please refer to systemctl(1).

Beagle 3.8 (cont)

beagle\$ cat /etc/init.d/README

Note that traditional init scripts continue to function on a systemd system. An init script /etc/init.d/foobar is implicitly mapped into a service unit foobar.service during system initialization.

Thank you!

Further reading:

man:systemctl(1)

man:systemd(1)

http://Opointer.de/blog/projects/systemd-for-admins-3.html

http://www.freedesktop.org/wiki/Software/systemd/Incompatibilities