

GETTING STARTED

1. UNBOXING

Carefully remove device from packaging.

Items included: Device, charger, USB cable, quick start guide, warranty card.

Save original packaging for potential returns.

2. INITIAL SETUP

Step 1: Charge device to 100% before first use.

Step 2: Power on by holding power button for 3 seconds.

Step 3: Follow on-screen setup wizard.

Step 4: Connect to Wi-Fi network.

Step 5: Sign in or create TechMart account.

Step 6: Register product at techmart.com/register for warranty activation.

3. ACCOUNT MANAGEMENT

Create account at account.techmart.com.

Username: Your email address.

Password: Minimum 8 characters, 1 uppercase, 1 number.

Enable 2FA for security: Settings then Security then Two-Factor Authentication.

4. TROUBLESHOOTING

Device won't power on:

Charge for at least 30 minutes.

Hold power button for 10 seconds for force restart.

Contact support if issue persists.

Cannot connect to Wi-Fi:

Toggle Wi-Fi off and on in Settings.

Forget network and reconnect.

Check router is working.

Reset network settings if needed.

Device running slow:

Clear cache: Settings then Storage then Clear Cache.

Close background apps.

Perform factory reset as last resort.

Screen issues:

Adjust brightness: Settings then Display.

Check for software updates.

Contact warranty support for hardware screen issues.

5. SOFTWARE UPDATES

Updates delivered automatically when on Wi-Fi overnight.

Manual update: Settings then System then Software Update.

Never interrupt an update in progress.

6. FACTORY RESET

WARNING: This deletes all data. Backup first.

Settings then System then Reset then Factory Reset.

Confirm with your password.