


TECKNET

Wireless Keyboard



Model: TK-KB005

User Manual


EN DE

Thank you for purchasing TECKNET wireless keyboard. Please read this User Manual thoroughly before use of the product and retain it for future reference. If you have any problem using this product, please contact us by email at support@ylinksworld.com.

Package Contents



Product Overview



Specifications


- 1. Operating voltage: 3.3V-4.2V
- 2. Operating current: <3 mA
- 3. Input: DC 5V/500mA
- 4. Transmission Power: 0.8dBm

Getting Started

Charge the Keyboard before First Use

- ⚡ Red Light: Charging
- ⚡ Green Light: Fully Charged

Turn on the Keyboard



EN-01


Connecting the Keyboard to Your Device(s):

For BT Channels


- Step 1:** Select a Channel:
Press one of the three BT channel keys to select from BT 1, BT 2, and BT3.



- Step 2:** To enter pairing mode, press and hold the channel key you selected for over 3 seconds until the corresponding indicator flashes rapidly.




- Step 3:** Activate Bluetooth on your device and select "TK-KB005" from the available device list to connect with.




EN-02

For USB Connectivity Channel

- Step 1:** Press the USB connectivity channel key.



- Step 2:** Plug the USB receiver to a USB-A port on your computer, and it is ready to go.



- *Follow the steps above to connect the keyboard to 4 devices using channels BT 1, BT 2, BT3, and USB connectivity.**

Enhancing Keyboard Compatibility

Once the keyboard is connected, use the key combinations below to enhance compatibility with the corresponding operating system.
For Android devices: press Fn + Q
For Windows devices: press Fn + W
For iOS devices: press Fn + E

Switching between Connected Devices



- Short press one of the four channel keys to switch between connected devices.

Energy-saving Sleep Mode

The keyboard will enter sleep mode if it's left on and not being used. Press any key and wait a second or two to bring it out of sleep mode.

EN-03

Fn + Space Bar

- To display the current channel of the keyboard, press Fn and the Space Bar. The indicator light corresponding to the current channel will flash three times.

Status Indicators

⚡	Charging Indicator
●	BT 1 Channel/Num Lock Indicator
●	BT 2 Channel/Caps Lock Indicator
●	BT 3 Channel Indicator: Green Light
●	USB Connectivity Indicator: Red Light
●	Low Battery Indicator: Red Light Flashes
●	Scroll Lock Indicator: Green Light

Function Keys

Fn + Esc	Lock / Unlock Fn Key	/	/
F1	Decrease Screen Brightness	F7	Play/Pause
F2	Increase Screen Brightness	F8	Next Track
F3	Browser Homepage	F9	Mute / Unmute
F4	Search	F10	Volume Down
F5	Undo	F11	Volume Up
F6	Previous Track	F12	Lock Screen

Energy-saving Sleep Mode

EN-04

IMPORTANT SAFETY INSTRUCTIONS-CAREFULLY FOLLOW THESE INSTRUCTIONS.

- 1. RETAIN THESE INSTRUCTIONS - This sheet contains important safety and operating instructions.
- 2. Before using the product, read all instructions and caution markings on the product, accessories, and device.
- 3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 4. Children should be supervised to ensure that they do not play with the appliance.
- 5. Keep the product away from the fire to avoid an explosion.
- 6. Do not place the product in or near an inflammable, explosive, or hazardous object.
- 7. Do not operate the product with a damaged cord or plug.
- 8. Do not disassemble the product. Disassembly may result in a risk of safety hazards.
- 9. Do not drop or shake the product.
- 10. Reduce the risk of electric shock, unplug the product from the power supply when not in use or switch off the power supply.
- 11. Do not place the product in or near water, rain, excess moisture, or extreme heat.

How to claim the warranty

Please contact retailers or visit TECKNET website or email support@ylinksworld.com for more information. To extend the warranty period, please visit TECKNET website and register your TECKNET products within 90 days of purchase.

Disclaimer

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products mentioned herein.

CORRECT DISPOSAL OF THIS PRODUCT

(Waste Electrical and Electronic Equipment)
This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.
To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.
Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

SIMPLIFIED EU DECLARATION OF CONFORMITY

Hereby, Shenzhen Unichain Technology Co., Ltd. declares that the product type TK-KB005 is in compliance with Directive 2014/53/EU.
The full text of the EU declaration of conformity is available at the following internet address: <https://teckneteu.com/>

12

MONTH

Limited 12-Month Warranty

What this warranty covers.

Shenzhen Unichain Technology Co., LTD. (Manufacturer: "Unichain") warrants to the original purchaser of this TeckNet product that the product shall be free of defects in design, assembly, material, or workmanship.

What the period of coverage is.

Unichain warrants the TECKNET product for **12 Months**.

What will we do to correct problems?

Unichain will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product).

What is not covered by this warranty?

All above warranties are null and void if the TeckNet product is not provided to the original purchaser or if Unichain determines that the TeckNet product has been improperly installed, altered in any way, or tampered with. The TeckNet Product Warranty does not protect against acts of God such as flood, earthquake, lightning, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (e.g. brownouts or sags), non-authorized program, or system equipment modification or alteration.

How to claim the warranty

Please contact retailers or visit TECKNET website or email support@ylinksworld.com for more information. To extend the warranty period, please visit TECKNET website and register your TECKNET products within **90 days** of purchase.

Disclaimer

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products mentioned herein.

FCC STATEMENT
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Vielen Dank für Ihren Kauf der TECKNET kabellosen Tastatur. Bitte lesen Sie diese Bedienungsanleitung gründlich vor der Verwendung des Produkts und bewahren Sie sie zur späteren Referenz auf. Wenn Sie Probleme bei der Verwendung dieses Produkts haben, kontaktieren Sie uns bitte per E-Mail unter support@ylinksworld.com.

Lieferumfang



Produktübersicht



Technische Daten

- 1. Betriebsspannung: 3,3V-4,2V
- 2. Betriebsstrom: <3mA
- 3. Eingang: DC 5V/500mA
- 4. Übertragungsleistung: 0,8dBm

Erste Schritte

Laden Sie die Tastatur vor dem ersten Gebrauch auf

- ⚡ Rotes Licht: Laden
- ⚡ Grünes Licht: Vollständig aufgeladen

Schalten Sie die Tastatur ein




EN-07

Verbindung der Tastatur mit Ihren Geräten:


Für BT-Kanäle

Schritt 1:


Drücken Sie die Taste für den USB-Verbindungs-Kanal.



Schritt 2: Halten Sie die ausgewählte Kanaltaste über 3 Sekunden, bis die entsprechende Anzeige schnell blinkt, um in den Pairing-Modus zu wechseln.



Schritt 3: Aktivieren Sie Bluetooth auf Ihrem Gerät und wählen Sie "TK-KB005" aus der verfügbaren Geräteliste aus, um eine Verbindung herzustellen.




DE-01


Für den USB-Verbindungs-Kanal

Schritt 1:

Drücken Sie Fn und die Leer Taste, um den aktuellen Kanal der Tastatur anzuzeigen. Die entsprechende Anzeige wird drei Mal blinken.



Schritt 2: Schließen Sie den USB-Empfänger an einen USB-A-Anschluss Ihres Computers an. Die Verbindung ist bereit.



Befolgen Sie die oben genannten Schritte, um die Tastatur über die Kanäle BT 1, BT 2, BT3 und USB-Verbindung mit 4 Geräten zu verbinden.

Um die Tastaturoberfläche zu verbessern

Sobald die Tastatur verbunden ist, verwenden Sie die folgenden Tastenkombinationen, um die Kompatibilität mit dem entsprechenden Betriebssystem zu verbessern:

- > Für Android-Geräte: drücken Sie Fn + Q
- > Für Windows-Geräte: drücken Sie Fn + W
- > Für iOS-Geräte: drücken Sie Fn + E

Wechseln zwischen verbundenen Geräten