

1 DNC Functions of AIP

1.1 General information / basic view of DNC

The HYDRA-DNC module provides functions to manage DNC programs, to download DNC programs onto a machine or to upload changed programs from a machine.

Provided that the module is active, it can be opened in the “workplace” section using the “DNC” button. The DNC function is started for the machine selected in the basic dialog. However, the DNC dialog cannot be opened if a machine is selected that is not assigned to a DNC family.

The opened dialog (DNC basic dialog) shows the below-mentioned data.

Operation

Operation number and designation of the operation that is logged on and selected in the basic dialog.

Order

Order number of the operation logged on and selected in the basic dialog.

Article

Article/item number of the operation logged on and selected in the basic dialog.

Workplace

Workplace/machine number and short description.

Selection

By default, selection is made “by DNC family”. The configured filter fields displayed..

But it is also possible to define another type of selection that is specific to the machine within the hytnrcfg.ini file (the entries to be made are written in brackets).

Selection by order (KEYTYP=A)

The “search term” fields, etc. are hidden. The filter field is activated instead within the table. DNC resources are already loaded and displayed while the dialog is being opened. The information line below the grid is hidden.

Selection by program (KEYTYP=P)

The table is empty at first. The “search term” field refers to the “DNC element”. Filtering refers to the DNC element.

DNC family

The DNC family which the currently selected machine is assigned to is displayed here. Please note: A machine should only be assigned to one DNC family. Any of the assigned DNC families will be displayed here if the machine is assigned to more than one DNC family.

“Released” status only

If this checkbox is checked only DNC resources are displayed that are currently assigned to the “released” status.

Memorize

If this checkbox is checked the entered search term is saved, when the dialog is closed. In case nothing is entered in the input field, the value “empty” is saved.

Table

The table of the “manage DNC elements” dialog is already filled while the dialog is being opened, provided that selection is based on programs or orders. In case the “by DNC family” option is selected, the list will only be loaded already while opening the dialog if at least one filter field is filled out.

The “manage DNC elements” dialog shows all available DNC resources:

Maintain setup parameters (SP)

Operation 0100 InjectionMolding

Prod.Order S6100305 Article SAR-FMO011-K-5013

Workplace 60610 ENG21

Selection by SD familiy SP Family IM_SET

☐ only status 'released' Search term ☐ Memorize

Filter	Setup parameter	ESD Familie	File size	Resource status
	ESD-SA-4026-127A	IM_SET	2267	RELEASED
	ESD-SA-4026-127B	IM_SET	2267	RELEASED
	<New>	IM_SET		

Filter [Article]>SAR-FMO011-K-5013 [Tool]>SG-4026-127 [Machine]>60610 [(Humidity)

SP record ESD-SA-4026-127A

Staff Number

Cancel Refresh Search Filter Lock Save

07/12/12 23:54:12

Filter fields

The four filter fields are shown here if the selection is based on the “by DNC family” option . Depending on how the DNC family is configured, the fields will be assigned to default values of order and machine. Provided that the “memorize” checkbox is checked, the entered filter criteria will already be assigned the next time the dialog is opened. If, however, a default value is configured for a field in the DNC family, this assignment takes priority.

The filter fields may be entered unless the “read-only” option has been configured. All filter fields can be entered if no OP is logged on. In this case, the input is not mandatory. A configuration in the hytnrcfg.ini dialog can prevent the fields from being released.

[Tnr Konfiguration 0]

DNCFreeSearchReadOnly=On

If the DNC dialog is started from the order sequencing list, filter fields react as it is the case if operations are logged on, as the selected order is transferred as reference.

DNC element

When an entry is selected in the list, the respective DNC element is taken over to the input field. As an alternative, the DNC element may also directly be written into the input field.

The functions that can be started using the buttons down right generally refer to the DNC element displayed in this input field.

Badge number

The staff badge number has been designed for checking authorizations for the functions that are displayed down right in the toolbar and that are described in the following:

-  - Update/refresh
-  - Show DNC resource
-  - Show assigned documents: DNC documents
-  - DNC upload machine → AIP

-  - DNC download AIP → Machine
-  - Lock DNC resource/change status
-  - Release locked DNC resource

1.2 Update

This function updates  the list. The value entered in the “search term” input field is taken into account in this context. The file size of DNC resources available at the AIP is entered in the corresponding column. Furthermore, the status of the DNC resource is displayed.

When loading the list by touching/clicking the corresponding button, it is checked whether or not filter fields configured as “read-only” for the upload are available (configuration of user fields of the DNC family). These fields have to be filled out in order for the list to be loaded.

1.3 Show DNC resource

The file content of the DNC resource is displayed. This function is only available, provided that the DNC-VIS license has been purchased.

1.4 DNC documents

The “DNC documents” function is only available if the “DNC-AEB” license is active (HYDRA-DNC 7.2).

The terminal loads the list of documents assigned to the resource and displays them.

By selecting an entry in the list and clicking/touching the “open document” button, the file is downloaded to the terminal and displayed in an internal or external viewer – depending on the respective file extension.

1.5 Upload

The “upload” function reads a resource from the machine and copies it into the configured target directory. For this purpose, the element has to be released for the upload.

An upload may always be performed if a DNC family is filtered and a <new element> is selected afterwards. At first a dialog appears where element and file name may be entered. Moreover, other filter criteria may be entered. The four lower fields of the upload dialog may be used for this purpose. Configuration of these fields is read out from the DNC family of the resource selected in the DNC dialog.

The fields may be configured as user fields at the client.

A field is only visible if at least one of the options “filter”, “mandatory field at upload”, “pre-assignment at upload” or “read-only” is set.

The field is initialized with default values if the “pre-assignment at upload” option is configured.

The field is grayed out, provided that the “not alterable/read-only” button is set. But the field remains unchanged if the “mandatory field at upload” option is set at the same time.

A new line is displayed in the list after the upload.

The upload is documented as event in the resource history. Two events are entered with the upload. They are to be distinguished by the dialog IDs:

- N: Beginning of the upload; the resource record is entered or changed.
- F: The file pertaining to the record has arrived the target directory.

The two events normally occur in very short intervals. In case the “F” event is missing, the transmission of the file has been interrupted unexpectedly. A download only transfers the file. The record is not changed. Consequently, only one event is entered in the history for the download.

1.6 Download

The “download” function collects a resource from the configured directory and copies it to the machine. Before starting the download, users have to identify themselves by their badge number. It is checked whether or not they are authorized to download programs.

The download process is documented as event in the resource history.

1.7 Lock DNC resource or change status

The resource status may be changed in this dialog.

The status change may be documented as event in the resource history.

**Change status of DNC element ESD-SG-8014-127**

SP record	ESD-SG-8014-127
SP Family	IM_SET

Actual status	999
New status	11

Filter

Status	Status designation
11	K-MAINTENANCE
12	OUTSOURCE-K2
13	SCRAPPED
99	BLOCKED

Page 1 • Page 2

Comment

Staff Number

9999

☐ Memorize

 Cancel

 Change status

07/13/12 00:00:42

1.8 Release DNC resource

When a resource is released its status switches to the status assigned to the processing flag "F". Consequently, the status does not have to be selected or entered.

The status change is documented as event in the resource history.

Release of locked resources:



Release SP element ESD-SG-8014-127A

SP record	ESD-SG-8014-127		
SP Family	IM_SET		

Actual status	999		
---------------	-----	--	--

Comment

Staff Number

9999

☐ Memorize






07/12/12 23:59:25