

1 Display of "Produced Batches" in AIP

Overview

Using the [3rd list of the machine master](#), it is possible to display the output batches produced for a running operation that is subject to batch management.

A default number of 20 output batches is displayed for each machine in the list. Output batches (yield and scrap batches) are shown, which have been produced at this terminal since output batches were changed.

As this list is only kept locally by the terminal, it is not synchronized with the server, when AIP is started.

Configuration

The settings required to use the third list can be found in the document dealing with [configuration](#).

Display

Produced output batches				
...	Batch HU4RD9711P Article 5468-41 Aluminum roll 200 mm x 1000 m	Batch HU4RD9711O Article 5468-41 Aluminum roll 200 mm x 1000 m	Batch HU5AD1G117 Article 565-941 Aluminum roll 100 mm x 1000 m	Batch HU4RD9711Q Article 5468-41 Aluminum roll

If several third lists are enabled, you can switch between the lists in the header line.

The list shows, among others, the article, article name and batch number. Some of the fields might not be completed depending on the data collection scenario when generating output batches.