

1 Central Configuration File hytnrcfg.ini

This file includes different configurations for all or single terminals at a central place.

Each section is available in a generally accepted version
[section 0].

However, entries included in this section can be overwritten by entries in a terminal-specific section
[section <TNR-USER>]

<TNR-USER> = HydraUser = Terminal number + 2000 e.g. 2010,2101,..) for exactly one terminal/HYDRA User



The hytnrcfg.ini file is loaded from the server every time the terminal is started.

Section / Entry	Comment
	→→→
[Tnr configuration 0]	
FollowExternStatus=on	Transfer of machine statuses when reloading machine list Useful if status change is set by PDM or another terminal
[Terminal->Installation 0]	
InstallFonts=on	If this is set to "off" fonts will not be installed during the restart. ON=DEFAULT
OnlyInstallFontsAfterDownload=false	"InstallFonts=on": If true then fonts will only be installed directly after a download. If false then fonts will be installed every time the terminal is restarted. (false = DEFAULT)
InstallTvicport=on	If "off" the LPT driver "tvicport.sys" will not be installed. It is required for HYDRA-ZKS. ON = DEFAULT
[Terminal->USR 0]	

AttachedApplication=First	This configuration checks whether or not an application is connected in Windows that matches the file extension of the document to be displayed from the OP info dialog. If there is such an application, it will be used for displaying the document. If there is no connection, viewers configured in ctaip.ini (→ [ext. software]) and internal viewers will be used. In case, an extension is completely unknown it is attempted to display it as text Different settings may be configured: First → search for connected application first AfterUserViewer → If a UserViewer is configured this one overrides the connected application (also applies for ExcelViewer, WordViewer and PowerpointViewer) Last → Only if no ctaip.ini assignment is found for the file extension, then the connected assignment will be searched for (default). Off → Connected application is never searched.
HTTPBrowser=standard	Viewing of documents (via OP info): If documents are configured with a path of the <u>type</u> "http", the file will not be downloaded to the terminal, but the link will only be transferred to a browser. The default browser for the terminal is htmview3.exe, as this one can be operated by touchscreen. If this entry is set, the default browser configured in Windows will be used.
SupressErrorMessage=70012	Suppress message "material is not planned"
[SignatureRecording->User 0]	
ManualBadgeInput=true	This configuration specifies whether or not the field "user" can be edited in the terminal (by default: no editing) true → activates keyboard input for the "user" field in the terminal

Transparency=255	The signature dialog can also be transparent. 255 → Signature dialog is 0 % transparent (not transparent) 1 → Signature dialog is 99% transparent (maximum transparency) (Default = 155) Available as of CTAIP (V# 2.0.2.25) / CTWIN (V# 7.2.5.99)
ShowPosition=TR	The position of the signature dialog can be adjusted as follows: TL Top – Left TM Top – Middle TR Top – Right ML Middle – Left MM Middle – Middle (Default) MR Middle – Right BL Bottom – Left BM Bottom – Middle BR Bottom – Right Available as of CTAIP (V# 2.0.2.25)
USE_SERVICE_ACCOUNT=1	0 (default) SSO: do not use ServiceAccount (requires the terminal to be started with the "user" domain (SSO)). Please note: ServiceAccount=1 can only be used if all users are in the "root" domain. SubDomain users are not supported.
SIGNATURE_1_USER_TYPE=REPORTING_USER_READONLY	REPORTING_USER_READONLY The tab identifying users via the Windows user is activated and assigned to "user" by default. The "user" field is read-only. This requires, however, that in the HYDRA HR master the "SSO" option is set for all users logging in. Otherwise, successful authentication is impossible. REPORTING_USER_CHANGEABLE The tab identifying users via the Windows user is activated and assigned to "user" by default. The "user" field can be modified. This requires, however, that in the HYDRA HR master the "SSO" option is set for all users logging in. Otherwise, successful authentication is impossible.

SIGNATURE_1_LOGON_TYPE=HYDRA	"" / Not set / "EMPTY" There is also an alternative login procedure. HYDRA The tab identifying users via the Windows user is blocked. The HYDRA user must be used for identification purposes. This requires, however, that in the HYDRA HR master all users logging in are created and that the "SSO" option is not set. Otherwise, successful authentication is impossible. ACTIVEDIRECTORY The tab identifying users via the HYDRA user is blocked. The Windows user must be used for identification purposes. This requires, however, that in the HYDRA HR master the "SSO" option is set for all users logging in. Otherwise, successful authentication is impossible. MIXED_BUT_UNIQUE Either the HYDRA or Windows login procedure is available, subject to whether or not the "SSO" option is set for the registered user in the HYDRA HR master. "SSO" enabled → Windows only "SSO" disabled → HYDRA only
SIGNATURE_2_LOGON_TYPE=HYDRA	Identical to SIGNATURE_1_LOGON_TYPE (see above)
ExtendedSignatureRecording=true	Used for signatures with the terminal in the area of quality data collection.

1.1 Layout configuration

Entry		Comment
Section and/or	[terminal configuration 0] [terminal configuration 2XXX];	(general configuration) (2XXX terminal-specific configuration)
AUTO-CONFIRM-UHR-ERROR-MESSAGE=TRUE		In case of an error in reading the clock (e.g. after coming out of standby mode), this configuration makes sure that the time is accepted without having to confirm a dialog. Afterwards the terminal time will be synchronized with the server time using a PDM command.
SUPPRESS-MAXIMUM-NUMBER-OF-MACHINES-WARNING=ON		As of ctaip V# 2.0.2.23 Prevents the warning after restarting the terminal if more than 32 machines are assigned to the terminal (static/dynamic). (Default = OFF)

Entry	Comment
NetRuntimeMode=2	As of ctaip V# 2.0.2.50: Alternative calculation of the target quantity since logon: The net run time is not calculated from the times when the production lock is enabled (PSperre=green) but only from the shift times less the shift breaks. Consequently, it can also be displayed, even if the terminal program has been restarted.
Section [QRD-PRINTER->TICKET 0] ;(general configuration) [QRD-PRINTER->TICKET 2xxx] ;(2XXX configuration for a specific terminal)	
COMPLETE-ABSENCE-OF-LOCAL-MNR-DATA-FOR-EVENT=< Events >	Reloads the machine row for the configured <Events>, if it is not available locally => This configuration might be required/necessary for a group workplace without machine assignment.
COMPLETE-ABSENCE-OF-LOCAL-ANR-DATA-FOR-EVENT=< Events >	Reloads the order row for the configured <Events>, if it is not available locally ➔ This option has been implemented to access order data within the master data, e.g. when logging an order on.
COMPLETE-...-EVENT=< Events > COMPLETE-...-EVENT=#ALL# COMPLETE-...-EVENT=A_AN A_P_AN	Explanation on the configuration of <Events> ➔ Using <#ALL#> the row (ANR/MNR) that is not available is reloaded for any event. ➔ <A_AN A_P_AN> restricts reloading of information to the specified events. The ID <DLGFAM> is preferred to the ID <DLG> in order to identify the <Event>.