

1 Discrete Consumption Input at AIP

	→	
--	---	--

Summary

The function described below makes it possible to enter material consumption at the AIP shop floor terminal so that it can be uploaded via an interface in the form of goods movements.

Material consumption can be entered at the AIP shop floor terminal while an operation is being interrupted, while an operation is being logged off or when entering a partial confirmation/upload

Configuration

The document dealing with the [configuration](#) is to be taken into account for discrete consumption input.

Dialog and procedure

AIP provides the following features to enter material consumption based on the produced (total) quantity.

In the dialogs

- Log operation off (A_AB)
- Interrupt operation (A_UN)
- Partial confirmation/upload for operation (A_TR)

an additional "consumption" button is available with which the "Component consumption posting" dialog can be called up.



It is also possible to make the button available that is used to call up the "Component consumption posting" dialog from the MPL specific dialogs used for operation interruption (A_UN_MPL, A_UN_RF, A_UN_RS) or for operation log off (A_AB_MPL, A_AB_RF, A_AB_RS). However, what needs to be considered in this regard is that in MPL, consumption of batch-related material is posted differently.

Figure: "Partial confirmation/upload (A_TR)" dialog with "Consumption" button in AIP

The input dialog opens after the "Consumption" button is pressed.

The status information shown includes the workplace displayed in the dialog from which the function is called up, the operation and also the yield and scrap quantities entered in the dialog from which the function is called up. When calling up from an MPL dialog, the entered quantity is displayed based on whether classified ("Quality") as scrap or as yield.

Furthermore, a table is displayed showing the components that are flagged in the component list as consumption type "D". The following data is displayed in the table.

BOM item

BOM item

Input.Mat.No.

Material number of the material component.

Input.Mat.Des.

Material designation of the material component.

Consumption

Calculated consumption based on the quantity entered in the dialog from which the function is called up:

$$\text{Rechnerischer Verbrauch} = (\text{Gutmenge} + \text{Ausschuss}) * \text{Einsatzmenge}$$



Only yield and scrap quantities are taken into account when calculating the consumption.

Quantities are not set off against each other (e.g. scrap set off against yield) when the calculated consumption is determined.

Unit

Quantity unit (unit of the input quantity).

Input quantity

Input quantity required to produce one quantity unit of the output material.

When a component is selected from the list, the calculated consumption is proposed in the "Consumption" input field. If the actual consumption deviates from the calculated consumption, the operator can now modify this quantity; it is transferred to the list. Any consumption that was modified manually is shown highlighted in "green" in the list (e.g. ).

By pressing the "Reset" key, the component list can be called up again; this will recalculate the consumption quantities; any consumption quantities that were already modified will be overwritten.

After confirming this dialog and the dialog from which the function is called up, the consumption quantities are updated and are thus transferred to the server via the posting. There, the consumption is updated as the status in the component list at the operation. In addition, one material movement (goods issue) is written for each component.



The material consumption is only posted as a goods movement if the dialog was called up explicitly. Material consumptions that were not posted are not automatically posted when the operation is logged off or interrupted.

If the consumption input dialog is integrated in the partial upload dialog and if it is not called up when a partial upload is executed or when the entry is interrupted, the system will remember the calculated consumption for all material components of the consumption type "D" and will account for it the next time the consumption input dialog is called up.

Example (assumption: a material component with the input quantity 2 is defined at the operation):

- Call up the partial upload dialog (A_TR): Enter yield 9, scrap 1
- Call up the consumption input dialog (A_VERB)
 - $(9 * 2 + 1 * 2 =) 20$ is proposed as material consumption
 - Cancel the dialog (do not click on OK to confirm)
- Confirm the partial confirmation/upload dialog (A_TR)
 - The yield 9 and the scrap 1 are posted at the operation.
 - The system remembers the calculated consumption of 20
- Call up the partial upload dialog (A_TR) once more: Enter yield of 5
- Call up the consumption input dialog (A_VERB)
 - $(20 + 5 * 2 =) 30$ is now proposed as material consumption
 - Confirm with OK
- Confirm the partial confirmation/upload dialog (A_TR)
 - The yield 5 is posted to the operation
 - The consumption of 30 is posted as a goods movement

If after calling up the consumption input dialog it is canceled and thus closed and the quantity is then modified in the dialog that calls up the function and if then the consumption input dialog is once again called up, then the consumption quantities that were proposed the first time it was called up will still be shown in this dialog. This is why the proposed material consumption will need to be updated by clicking on the "Reset" button as the case may be.