

1 Machines / Workplaces

Available methods

Method	Usage
MNR.INSERT	Create machine/workplace
MNR.UPDATE	Change machine/workplace
MNR.DELETE	Delete machine/workplace

Data

Column	Description
Field	Field name
V (usage)	S Key field clearly identifying the data record. (Further key fields might be required). The field must be completed. M Mandatory field
T(ype)	Data type of the field
L(ength)	Field length For fields of data type DEC: Overall number of digits without decimal separator and algebraic sign
D(ecimal places)	For fields of data type DEC: Number of decimal places; otherwise: not relevant
Description	Description and/or comment of the field

Field	V	T	L	D	Description
BEARB	M	CHAR	10		HYDRA User
MNR.MNR	S	CHAR	8		Machine/workplace
MNR.BEZX		CHAR	8		Short name
MNR.BEZX		CHAR	40		Name
MNR.VAB		CHAR	15		Responsibility area
MNR.KST		CHAR	10		Cost center
MNR.TYP		CHAR	1		Workplace category (see possible values displayed in the GUI)
MNR.SPERR		CHAR	1		ID "blocked" "J" yes "N" no
MNR.ART		CHAR	1		Workplace type (see possible values displayed in the GUI)
MNR.OPT:FREMDAPZ		CHAR	1		ID "external workplace" "J" yes "N" no
MNR.FIR		CHAR	4		Company
MNR.MGRP		CHAR	8		Group
MNR.CAT		CHAR	10		Category
MNR.BDEJMOD		NUMC	3		Year model
MNR.MSTDSATZ		DEC	6	2	Standard rate machine
MNR.PSTDSATZ		DEC	6	2	Standard labor rate

Field	V	T	L	D	Description
MNR.LEIGRAD		NUMC	3		Performance level
MNR.AKKORD		CHAR	1		Incentive wage indicator (see possible values displayed in the GUI)
MNR.ICON		CHAR	20		File name
MNR.OPT:MULTIAG		CHAR	1		Logon of multiple OPs (see possible values displayed in the GUI)
MNR.OPT:VLISTMOD		CHAR	1		Sequencing list (see possible values displayed in the GUI)
MNR.VLISTANZ		NUMC	3		Number of OPs in sequencing list
MNR.OPT:VLISTZW		CHAR	1		Compulsory sequence (see possible values displayed in the GUI)
MNR.VISLIST3		CHAR	10		Display 3rd list The field includes none, one or several of these options. They are separated by semicolon: "M" Input material "R" Resources "P" Staff "A" Output material Example: "M;R;P;A" if all options are set
MNR.VISFHTNRAAN		CHAR	1		Material/PRT list when logging on OPs (see possible values displayed in the GUI)
MNR.DLGSTRG		CHAR	10		Dialog control
MNR.OPT:MAABP		CHAR	1		Quantity posting to staff (see possible values displayed in the GUI)
MNR.OPT:AGIST		CHAR	1		ID "Posting on OPs not logged on" "J" yes "N" no
MNR.OPT:ANTDAUER		CHAR	1		Posting of machine time for simultaneous OPs (see possible values displayed in the GUI)
MNR.OPT:AANSKBAUTO		CHAR	1		Log OP on automatically when shift ends (see possible values displayed in the GUI)
MNR.OPT:PABSKE		CHAR	1		Log person off automatically when shift ends (see possible values displayed in the GUI)
MNR.PLANFKT		CHAR	1		Planning function (see possible values displayed in the GUI)
MNR.PLANJMOD		NUMC	3		Planned year model
MNR.KAPJMOD		NUMC	5		Availability (per mil)
MNR.OPT:CHV		CHAR	1		Batch management (see possible values displayed in the GUI)
MNR.MATPUF:IN		CHAR	12		Preceding material buffer
MNR.MATPUF:OUT		CHAR	12		Subsequent material buffer
MNR.OPT:CNRAUTOGEN		CHAR	1		Automatic generation of batch number (see possible values displayed in the GUI)
MNR.VISVERBRBLZ		CHAR	1		ID "Consumption balance" "J" yes "N" no
MNR.OPT:TRANROUT		CHAR	1		ID "Generate transport order for output material" "J" yes "N" no
MNR.OPT:TRANRIN		CHAR	1		ID "Generate transport order for input material" "J" yes "N" no
MNR.VERB:GUT		CHAR	3		Allocation of yield "AUS" Scrap "NCH" Rework "PRB" Open quantity

Field	V	T	L	D	Description
MNR.VERB:AUS		CHAR	3		Allocation of scrap "GUT" Yield "NCH" Rework "PRB" Open quantity
MNR.VERB:NCH		CHAR	3		Allocation of rework "GUT" Yield "AUS" Scrap "PRB" Open quantity
MNR.VERB:PRB		CHAR	3		Allocation of open quantity "GUT" Yield "AUS" Scrap "NCH" Rework
MNR.OPT:GUTMANU		CHAR	1		ID "Manual entry of yield" "J" yes "N" no
MNR.OPT:AUSMANU		CHAR	1		ID "Manual entry of scrap" "J" yes "N" no
MNR.OPT:NCHMANU		CHAR	1		ID "Manual entry of rework quantity" "J" yes "N" no
MNR.OPT:PRBMANU		CHAR	1		ID "Manual entry of open quantity" "J" yes "N" no
MNR.OPT:GUTMANUTAKT		CHAR	1		ID "Posting of yield as cycles" "J" yes "N" no
MNR.OPT:AUSMANUTAKT		CHAR	1		ID "Posting of scrap as cycles" "J" yes "N" no
MNR.OPT:NCHMANUTAKT		CHAR	1		ID "Posting of rework as cycles" "J" yes "N" no
MNR.OPT:PRBMANUTAKT		CHAR	1		ID "Posting of open quantity as cycles" "J" yes "N" no
MNR.OPT:UMRMENGE		CHAR	1		Basis for MDE quantity conversion (see possible values displayed in the GUI)
MNR.EGE:GUTP		CHAR	3		Quantity unit (P)
MNR.UMRFAKTP:Z		NUMC	9		Quantity unit (P) - numerator, primary quantity
MNR.UMRFAKTP:N		NUMC	9		Quantity unit (P) - denominator, primary quantity
MNR.EGE:GUTS		CHAR	3		Quantity unit (S)
MNR.UMRFAKTS:Z		NUMC	9		Quantity unit (S) - numerator, primary quantity
MNR.UMRFAKTS:N		NUMC	9		Quantity unit (S) - denominator, primary quantity
MNR.EGE:GUTT		CHAR	3		Quantity unit (T)
MNR.UMRFAKTT:Z		NUMC	9		Quantity unit (T) - numerator, primary quantity
MNR.UMRFAKTT:N		NUMC	9		Quantity unit (T) - denominator, primary quantity
MNR.EGE:GUTB		CHAR	3		Quantity unit (B)
MNR.UEBART		CHAR	1		Monitoring type "Z" Cyclic monitoring "B" Operating signal "K" No monitoring
MNR.UEBDAUER		NUMC	3		Minimum cycle/malfunction time (seconds)

Field	V	T	L	D	Description
MNR.IZYABW		NUMC	4		Cycle extension
MNR.ANZSTAKT		NUMC	4		Number of target cycles
MNR.MWANZ		NUMC	1		Cycles to be evaluated
MNR.OPT:MSTAUAF		CHAR	1		ID "Activation of required malfunction reason input" "J" yes "N" no
MNR.OPT:MSTAUDAUER		NUMC	4		Delay time (seconds)
MNR.BUCHSPERRE		CHAR	1		Posting during prod. lock "G" Posting as yield "A" Posting as scrap "X" No posting
MNR.IMPFAKT		NUMC	3		Pulse factor specific to machines
MNR.TLG		NUMC	5		Partitioning specific to machines
MNR.STKZG		NUMC	4		Waiting period short-term malfunction (seconds)
MNR.OPT:WENDAUTO		CHAR	1		ID "Extended weekend automatic" "J" yes "N" no
MNR.DIGOUT:MSPERRE		NUMC	2		Output "machine lock"
MNR.DIGOUT:SMENGE		NUMC	2		Output "target quantity reached"
MNR.DIGOUT:STOER		NUMC	2		Output "machine down"
MNR.DIGIO		NUMC	2		Free I/O
MNR.DIGIN:CAWL		NUMC	2		Output batch change
MNR.OPT:PDV		CHAR	1		ID "Collect process data" "J" yes "N" no
MNR.EXTTYP		CHAR	1		External connection "K" No external connection "J" DS100 "N" MT3 "E" Engel interfacing "A" Arburg control system "P" PDE (Process Data Collection)
MNR.EXTSNR		NUMC	8		Serial number
MNR.EXTID		NUMC	2		Device address
MNR.USRFLD		CHAR	8		User field key
MNR.FU:1		DATE	10		User field 1
MNR.FU:2		DATE	10		User field 2
MNR.FU:3		DATE	10		User field 3
MNR.FU:4		DATE	10		User field 4
MNR.FU:5		DATE	10		User field 5
MNR.FU:6		DATE	10		User field 6
MNR.FU:7		NUM	8		User field 7
MNR.FU:8		NUM	8		User field 8
MNR.FU:9		NUM	8		User field 9
MNR.FU:10		NUM	8		User field 10
MNR.FU:11		NUM	8		User field 11
MNR.FU:12		NUM	8		User field 12
MNR.FU:13		NUM	8		User field 13
MNR.FU:14		NUM	8		User field 14
MNR.FU:15		NUM	8		User field 15
MNR.FU:16		NUM	8		User field 16

Field	V	T	L	D	Description
MNR.FU:17		NUM	8		User field 17
MNR.FU:18		NUM	8		User field 18
MNR.FU:19		NUM	8		User field 19
MNR.FU:20		NUM	8		User field 20
MNR.FU:21		NUM	8		User field 21
MNR.FU:22		NUM	8		User field 22
MNR.FU:23		DEC	13	3	User field 23
MNR.FU:24		DEC	13	3	User field 24
MNR.FU:25		DEC	13	3	User field 25
MNR.FU:26		DEC	13	3	User field 26
MNR.FU:27		DEC	13	3	User field 27
MNR.FU:28		DEC	13	3	User field 28
MNR.FU:29		CHAR	1		User field 29
MNR.FU:30		CHAR	1		User field 30
MNR.FU:31		CHAR	1		User field 31
MNR.FU:32		CHAR	1		User field 32
MNR.FU:33		CHAR	1		User field 33
MNR.FU:34		CHAR	1		User field 34
MNR.FU:35		CHAR	1		User field 35
MNR.FU:36		CHAR	1		User field 36
MNR.FU:37		CHAR	1		User field 37
MNR.FU:38		CHAR	1		User field 38
MNR.FU:39		CHAR	1		User field 39
MNR.FU:40		CHAR	1		User field 40
MNR.FU:41		CHAR	1		User field 41
MNR.FU:42		CHAR	1		User field 42
MNR.FU:43		CHAR	1		User field 43
MNR.FU:44		CHAR	1		User field 44
MNR.FU:45		CHAR	10		User field 45
MNR.FU:46		CHAR	10		User field 46
MNR.FU:47		CHAR	10		User field 47
MNR.FU:48		CHAR	10		User field 48
MNR.FU:49		CHAR	10		User field 49
MNR.FU:50		CHAR	10		User field 50
MNR.FU:51		CHAR	20		User field 51
MNR.FU:52		CHAR	20		User field 52
MNR.FU:53		CHAR	20		User field 53
MNR.FU:54		CHAR	20		User field 54
MNR.FU:55		CHAR	20		User field 55
MNR.FU:56		CHAR	20		User field 56
MNR.FU:57		CHAR	20		User field 57
MNR.FU:58		CHAR	20		User field 58
MNR.FU:59		CHAR	20		User field 59
MNR.FU:60		CHAR	20		User field 60
MNR.FU:61		CHAR	20		User field 61
MNR.FU:62		CHAR	20		User field 62
MNR.FU:63		CHAR	20		User field 63
MNR.FU:64		CHAR	20		User field 64

Field	V	T	L	D	Description
MNR.FU:65		CHAR	40		User field 65
MNR.FU:66		CHAR	40		User field 66



The resource BAPI (RES.UPDATE) must be used to edit general information of the machine configuration, e.g. inventory no. engraving no., drawing no., manufacturer, owner, acquisition costs, supplier information and responsibilities.