

1 Key Fields / Supported Characters

General notes

In all alphanumeric fields, HYDRA does not support specific special characters. The following characters are not supported: "%", "ß", "*", "\", "/", "|", "_", "?". Reason: You cannot enter these characters on the shop floor terminals or the clients do not support these characters.

You must not use the characters ";" (semicolon), "," (comma) and "'" (apostrophe) because they are often interpreted as comment characters or separators and can lead to unwanted results.

Workplace/machine numbers (resources of type "MNR")

Workplace/machine numbers and numbers of capacity/machine groups are interpreted as alphanumeric values. Alphanumeric field with a maximum length of 8, left-aligned.

When you create or copy a workplace, the system checks if the characters used are allowed. The following characters are allowed:

- Numbers "0" to "9" ([US-ASCII 30_{hex} - 39_{hex}](#))
- Letters "A" - "Z" (upper case letters - [US-ASCII 41_{hex} - 5A_{hex}](#))
- "-" ([US-ASCII 2D_{hex}](#))

Lower case letters are automatically converted to upper case letters when a new workplace is created.

You must not use blanks. If required, you must prefix the numbers by leading zeros ("0").

The entry "SYSTEM" as workplace/machine number is reserved for HYDRA and may not be used.

It is possible to overwrite the valid characters for the workplace/machine numbers in the INI configuration. To this end, you must specify the valid characters as a regular expression (in brackets).

Field	Value
Name	INPUT
Section	PATTERN
Key	MNR
Value	^(?!SYSTEM) ([A-Z0-9(){}~^#+!\$._%-]+)\$
Active	☒

Minimum requirement: b_mnr.dll version 8.1.1.102

Resource numbers (resources of type <> "MNR")

Resource numbers are interpreted as alphanumeric values. Alphanumeric field with a maximum length of 20; left-aligned.

When you create or copy a resource, the system checks if the characters used are allowed. The following characters are allowed:

- Numbers "0" to "9" ([US-ASCII 30_{hex} - 39_{hex}](#))
- Letters "A" - "Z" (upper case letters - [US-ASCII 41_{hex} - 5A_{hex}](#))
- Umlauts "Ä", "Ö", "Ü" ([Extended ASCII C4_{hex}, D6_{hex}, DC_{hex}](#))
- "-" ([US-ASCII 2D_{hex}](#))

You may not use umlauts or special characters (e.g. "%", "ß", "*", "\", "/", "|", "_", "?") because you cannot enter these characters on the shop floor terminals or because the clients do not support these characters.

You must not use blanks. If required, you must prefix the numbers by leading zeros ("0").

Lower case letters are automatically converted to upper case letters when a new resource is created.

It is possible to overwrite the valid characters for the resource numbers in the INI configuration. To this end, you must specify the valid characters as a regular expression (in brackets).

Field	Value
Name	INPUT
Section	PATTERN
Key	RES
Value	^([0-9A-ZÄÖÜ(){}~^#+!\$. _%-]+)\$
Active	☒

Minimum requirement: b_res.dll version 8.1.1.117

HYDRA order number

There are some differences with respect to the order number in the HYDRA data model and the interface.

Order number

The order number (field AUNR) contains the actual order number as it is known in the ERP system and transferred to HYDRA. The order number is specified in the HYDRA basic settings; by default, this number has a length of 8 characters.

Operation number

The operation number (field AGNR) clearly identifies a defined process step of an order. The operation number is specified in the HYDRA basic settings; by default, this number has a length of 4 characters.

MES order number

The MES order number (field ANR) combines the order and the operation number and sometimes also the sequence number from the ERP system (if licensed). Its length therefore results from the total of the separate number lengths.

The total length must not exceed 25 digits. If DOS terminals are used, the total length must not exceed 16 digits.

Note the following for the order or operation number:

- Preferably only use the numbers "0" to "9" ([US-ASCII 30_{hex}](#) - [39_{hex}](#)).
- If you use letters, only the characters "A" - "Z" (upper case - [US-ASCII 41_{hex}](#) - [5A_{hex}](#)) and "-" ([US-ASCII 2D_{hex}](#)) are allowed. Do not use lower case letters.
- You may not use blanks in the numbers. The order or operation numbers must have the specified number of digits with the characters "0" to "9" or "A" to "Z". If required, you must prefix the numbers by leading zeros ("0").
- HYDRA does not support any umlauts, blank or special characters (see section *General notes*) for the order or operation number because you cannot enter these characters on the shop floor terminals or because the clients do not support these characters.