

1 Advanced Object Configuration

Overview

HYDRA menu	System Administration → System Settings → Advanced Object Configuration
FEDRA menu	System Administration → System Settings → Advanced Object Configuration
Transaction code	adoc
Function authorization	adoc

Purpose

You can use the *Advanced object configuration* to configure specific objects additionally.

Integration

Advanced object configuration is a central function used by numerous applications/functions. How this function is to be used is described in the documents dealing with the corresponding detail applications.

The user's [responsibility area](#) is checked if they want to display and change defined configurations.

Field Descriptions

Object Type

Object type for which the configuration applies (MNR, TNR; MATTYP, ...).

Object ID 1 – 4

Further keys by way of which an object (including the object type) can be identified uniquely. (DB mapping object type => hyd_obj_attributes.key1: Object ID 1 – 4 => hyd_obj_attributes.key 2-5).

Parameter

The actual parameter for the configuration of the system object.

Parameter value

Value for the configuration

Responsibility area

Responsibility area of the configuration

Active

A filter with three statuses (tri-state)

- active: all active configurations are displayed;
- inactive: all inactive configurations are displayed;

- grayed out: active as well as inactive configurations are displayed.

Reference

Unique database reference to a data record (configuration). This reference does not have a specific function and has been designed for information purposes.

Further notes

Please find below an overview of functions and processing methods configured by the advanced object configuration.



This list does not make any claim to being exhaustive.

Area	Processing	Link
MDE 8.1	Setting of outputs subject to status and posting scenarios	Link
BDE 8.1	Waiting period processing machine: machine-specific definitions	Link