

1 Assignment of Production Levels

Overview

Menu	Master data → Material → Production levels → Assignment
Transaction code	asplev
Function authorization	asplev

Usage

This function is used to create or modify the assignment of [production levels](#) in the system.

Integration

Forming [production levels](#) enables an individual summary of machines and [material buffers](#) that can be used in various evaluations, e.g. in the analysis of the range of coverage.

Requirement

The [production levels](#) must be defined in the system.

Selection criteria

The following selection criteria are available in the application:

Production level

Selection or input of the [production level](#)

Material buffer

Selection or input of the [material buffer](#)

Machine

Selection or input of the machine

Editing functions

The following dialog opens to edit a data record:



Add

Adds a new assignment.



Delete

Deletes the selected or several selected assignments.

Field descriptions "production levels - assignment"

Once the editing dialog is opened, the below-mentioned fields are available:

Production level

If a production level is selected, only this one will be displayed. Wildcard characters may be used in this selection option.

Type

Machine: A machine is assigned to the production level.

Material buffer: A material buffer is assigned to the production level.

Machine

Machine which is to be assigned to the production level.

If one or several machines with similar name (input of wildcard characters) is/are selected, the display of production levels that might be selected is restricted to the production levels that this machine is assigned to.

Material buffer

Material buffer that is to be assigned to the production level.

If one or several material buffers with similar name (input of wildcard characters) is/are selected, the display of production levels that might be selected is restricted to the production levels that this material buffer is assigned to.