

1 Assignment of DNC family to machine

Summary

Menu	Master data → Resources → Assignment of DNC family to machine
Transaction code	dncmas
Function authorization	mddncma.*

To control sequences and handle plausibilities on the terminal, DNC families are assigned to machines.

Usage

Assigning machines (in general: workplaces) to DNC families defines the DNC families from which programs can be used on the machine. The defined families are used as filter criteria on the machines.

Please note: This assignment is also the activation of the DNC functionality on the terminal for the assigned machine:

- A machine has at least one family assignment: The terminal allows DNC operation and when started, it also connects the DNC channel. A DNC channel for the HYDRA process communication controller (PCC) must be set up on the terminal.
- If there is no assignment for the machine, the DNC function for the machine is switched off.

Requirement

The DNC function is licensed.

Selection criteria

The following selection criteria are available in the application:

Workplace

The workplace/ machine to which a type is to be assigned.

DNC family

The assigned DNC family

Field descriptions

Default

If several families are assigned, one can be identified as the default, which will be used as the basic setting.