

1 Dynamic Dialogs

Overview

Menu	System administration → Terminals → Dynamic dialogs
Transaction code	ddconf
Function authorization	ddconf

Purpose

You can use the configuration of the dynamic dialogs to change the AIP input dialogs in a quick and efficient manner according to the user's requirements.

The system delivery includes a basic dialog configuration. You can edit and change this configuration using the functions described in the following.

You can use the function "Dynamic dialogs" to configure and customize the dialogs on the AIP. With this function, the general dialog parameters and specific AIP options are specified.

The application *Dynamic dialogs* also includes the configuration of fields and function keys. You can therefore easily configure the input dialogs in this one application.



The complete functionality of the dialog configuration includes a lot of options, but it is also very complex. For this reason, we recommend to change the dialogs only after consultation with MPDV and only by experts.

Integration

To define the tab order, the fields and the buttons of dialogs, you need not only use the application *Dynamic dialogs*, but also the applications *Dynamic dialogs - Workflow*, *Dynamic dialogs - Fields* and *Dynamic dialogs - Function keys*.

Requirements

Some of the functions require the development license MDS-AIS to be fully available. The restricted functions are marked in the document using "(*)".



Basics of the functions without development license:

- Existing data can be changed. Only data for default dialogs with user 0 must not be changed without development license.

- You cannot create new data without development license, except fields in existing dialogs.
- You can copy the existing data to terminal groups or terminals and then change them. Without development license, you cannot copy to default dialogs with user 0.

Selection criteria

The fields **Dialog**, **Type** and **User** are provided as selection criteria.

Toolbars

The application *Dynamic dialogs* provides several toolbars.

Toolbar *Main page*

This toolbar includes functions to edit dialogs. The different functions are described [below](#).

Toolbar *Dynamic dialogs - fields*

The toolbar *Dynamic dialogs - fields* includes functions to edit [fields](#).

Toolbar *Dynamic dialogs - function keys*

The toolbar *Dynamic dialogs - function keys* includes functions to edit [function keys](#).

Functions of toolbar *Main page*

Insert (*)

Use the function *Insert* to create new dynamic dialogs in the system.

[Copy](#) (*)

Use the function *Copy* to copy complete configurations, single dialogs or parts of a dialog.



(*) Without development license, you can only copy complete dialogs or complete dialog configurations. Without development license, you cannot copy to default dialogs with user 0.

You require a development license for all other functions.

Edit

Use the function *Edit* to edit existing dynamic dialogs in the system.

Delete (*)

The function *Delete* deletes the selected dialogs including fields and buttons.

An undo function does not exist.



If you delete default dialogs (AIPDEF and DEF with user 0) (*), we strongly recommend to backup the dialogs before deletion.



(*) Without development license, you cannot delete default dialogs for user 0.



Test dialog

Function authorization: ddconf.test

Use the function *Test dialog* to call the dialog. You can test its functions, fields and function buttons.



Activate dialogs

Function authorization: ddconf.activate

The function *Activate dialogs* [activates the dynamic dialogs](#). The dialogs are then available on the terminals.



Save dialog configuration

Function authorization: none

The function *Save dialog configuration* saves the current dialog configuration on the server.



Enable simple dialogs

Function authorization: ddconf.actsdlg

Use the function *Enable simple dialogs* to activate the simplified dialogs that can be used when needed. These dialogs show all data that must be entered on one page.



Workflow

Function authorization: ddconfw.*

The function *Workflow* calls the application [Workflow](#).

Field description

Dialog

Dialog ID

Type

Dialog type:

- AIPDEF/DEF – standard dialog
- AIPTNR/TNR – terminal dialog
- AIPTGRP/TGRP – dialog for terminal group

User

According to type: terminal number or terminal group.



Note for the fields **Type** and **User**: there are some effects that are described in section **Activating dynamic dialogs**.

Key text

The field *Key text* is not used.

Resolution

You can use the field *Resolution* to scale the dialog and the controls (default = empty).

Short text

Use the field *Short text* to configure the tab title of the dialog. This text is shown when the dialog is used as tab in a workflow.

Long text

Use the field *Long text* to configure the dialog title of the dialog. This text is only shown if the dialog is a one-page dialog without workflow configuration.

Function 1

Use the field *Function 1* to select the function that is called when the dialog is opened.

If an entry starts with "FKT=", the function specified is called in the dialog script using the function `DynDlgFunctions_<DLG>()`.

Optionally, a preassignment of field *yield* is possible when *A_AB* or *A_UN*

in function 1 (when dialog is opened) or 2 (when ANR is exited):

- **SET_RESTME**
Remaining quantity = target quantity - yield – scrap (up to now) – scrap (in current dialog)
- **SET_RESTM2**
Remaining quantity = target quantity – yield

Other entries are still available for reasons of downward compatibility (CTWIN), but are not used in current software versions.

Function 2

Use the field *Function 2* to select the function that is called just before the dialog is closed.

Entries starting with "FKT=" are possible here. MPDV recommendation: with script functions called on closing a dialog, trigger these script functions via the script of the relevant function key because the context is known then.

Comment

The field *Comment* is not used.

Height

Use the field *Height* to configure the height of the dialog window.

Only relevant with CTWIN dialogs and POPUP windows (see options 2).

Width

Use the field *Width* to configure the width of the dialog window.

Only relevant with CTWIN dialogs and POPUP windows (see options 2).

Key

If you configure a "+" in field *Key*, the dialog ID is shown in the window title of a one-page dialog (e.g. "Log on OP and person" > "Log on OP and person <A_P_AN>"). This information is useful for non-German customers and for the support.

Key ID

The field *Key ID* is not used.

Activation

The field *Active* specifies if the dialog is active or not active. Cannot be modified.

AIP options**Licenses**

Use the field *Licenses* to optionally define one or several licenses, separated by semicolon.

- If the field *Licenses* is empty, the dialog step is always active.
- If licenses are entered in field *Licenses*, then the dialog step is only displayed if at least one of the licenses is available (OR conjunction).

Otherwise, the dialog step is **not displayed**.

Example:

DNC-BP;WRM-BP

Static condition

You can define one or several conditions via AND conjunction in field *Static condition*. The condition refers to the values of acronyms. For each acronym, you can enter one or several valid values, separated by semicolon.

Static conditions do not change in the course of a dialog. Static conditions are only evaluated when the workflow is opened.

If no condition is specified, the dialog step is always active.

If the condition is not fulfilled, the dialog step is **not displayed**.

Syntax for conditions:

Example of a value request:

MNR.MGRP=100

The machine group must be 100.

Example of array access/comparison

```
TNR.PARAM3 [ 5 ] =5
```

The fifth character must be 5 (counting starts with 1).

```
TNR.PARAM3 [ 3 . . 5 ] =345
```

The characters 3 to 5 must be 345.

Example of negated conditions, several values are allowed

```
XXX<>12;34 & YYY=34;56
```

This condition is true if the content of <XXX> does not equal "12" or "34" and the content of <YYY> is equal to "34" or "56".

Example of programmed functions

```
PRG:EMPTY->ABC
```

The condition is true if the acronym ABC is empty or the acronym does not exist.

```
PRG: [NOT] EMPTY->ABC
```

The condition is true if the ID ABC exists and is not empty.

Dynamic condition

You can define one or several conditions via AND conjunction in field *Dynamic condition*. The condition refers to the values of acronyms. For each acronym, you can enter one or several valid values, separated by semicolon.

Dynamic conditions refer to acronyms that you can enter or change in the dialog. They are evaluated when the system changes to the next workflow tab.

If no condition is specified, the dialog step is always active.

If the condition is not fulfilled, the dialog step is **deactivated**.

The syntax of dynamic conditions is the same as the syntax of static conditions.

Forced fields

You can use the field *Forced fields* to configure fields that are required for the processing but that are not configured as hidden fields. You configure several field acronyms using semicolon (e.g. KNR;PNR; . .). The field acronyms are then available in the dialog buffer.

User defined 1

Additional configuration options:

```
BUTTONHEIGHT=50
```

In case of workflows or dialogs with one tab only, this configuration specifies the initial height of the button bar before scaling (default 30).



The dialog field positions do not automatically change.

User defined 2

Additional configuration options:

Configuration of a pop-up window with the configured height and width before scaling.

Example: POPUP:150:50:clYellow

Syntax	pop-up window	POPUP	key	word
	X position	150	X position top left corner (default 5)	
	Y position	50	Y position top left corner (default 5)	
	color	clYellow	color of dialog background (default \$A0FFFF)	

Copying dynamic dialogs

You can use the function *Copy dynamic dialogs* (button *Copy* in the toolbar) to copy complete configurations, single dialogs or parts of a dialog.

Function selection

Copy entire configuration

You can use the function *Copy entire configuration* to copy a complete configuration, e.g. from the default configuration (AIPDEF 0) to a terminal (e.g. AIPTNR nnn, with nnn= terminal number) or to a terminal group (AIPTGRP nnn, with nnn = terminal group). If you copy the configuration, the default configuration is still used with all terminals that do not have their own configuration. And later on you can change the custom configuration without affecting other users. In this mode, the input fields *Dialog from* and *Dialog to* are hidden.

Copy complete dialog

Use the function *Copy complete dialog* to call the following three copy operations in one operation.

Copy dialog without buttons and fields (*)

Use the function *Copy dialog without buttons and fields* to copy the basic or dialog information of the dialog. Fields and function keys are not copied.

Copy buttons of a dialog (*)

Use the function *Copy buttons of a dialog* to copy only function keys. The target dialog must exist before the copy operation.

Copy fields of a dialog (*)

Use the function *Copy fields of a dialog* to copy only fields. The target dialog must exist before the copy operation.



When you copy dialogs, you can specify type and user for the source (*From*) and the target (*To*). If the complete configuration is copied, the input fields of *Dialog from* and *Dialog to* are hidden.



(*) Without development license, you can only copy in mode *Copy entire configuration* or *Copy complete dialog*. Without development license, you cannot copy to default dialogs with user 0.

Activate dynamic dialogs

If you use the function *Activate dialog*, the configured dynamic dialogs are available on the server and can then be downloaded to the terminals. Without activation, the dialogs and the possible changes are saved on the system, but the terminals still download the version activated last.

You can activate dialogs for single terminals or for terminal groups. When you activate a dialog, you specify the activation type and the user number that can be a terminal or a terminal group.

Type	Value of User	Description
AIPTNR, TNR	Terminal number	Activates all dialogs for the terminal. If a dialog is not explicitly configured for the terminal number, the dialog is activated with type AIPDEF/DEF and user 0. The activation for user 0 provides the default dialogs. The activated dialogs are stored as files on the server: Schema: \\<Server>\<InstDir>\<SystemNr>\spool\aip<User>.* Example: \\MyServer\mip3\3\spool\aip10.* or: Schema: \\<Server>\<InstDir>\<SystemNr>\spool\<User>.* Example: \\MyServer\mip3\3\spool\10.*
AIPTGRP, TGRP	Terminal group	Activates all dialogs for the terminal group. The system only activates the dialogs that are explicitly configured for the terminal group. The activated data does not include default dialogs. The activated dialogs are stored as files on the server: Schema: \\<Server>\<InstDir>\<SystemNr>\spool\aiptgrp<User>.* Example: \\MyServer\mip3\3\spool\aiptgrp900.* or: Schema: \\<Server>\<InstDir>\<SystemNr>\spool\tgrp<User>.* Example: \\MyServer\mip3\3\spool\tgrp10.*

When you **load the dialogs from the terminal**, only the activated configurations are used. The following priority applies:

1. If dialogs are activated for the terminal, only the dialogs activated for the terminal are loaded. No other dialogs are loaded.
2. If dialogs are activated for the terminal group, only the dialogs activated for the terminal group are loaded. No other dialogs are loaded.
3. If no dialogs are activated for the terminal or the terminal group, then the default dialogs are loaded. The default dialogs are the dialogs activated for terminal/AIP terminal 0.

Enable simple dialogs

In the system, simplified dialogs are available that may be used if required. On one page, these dialogs show all data that must be entered. The dialogs are activated for the default terminal user AIPDEF using the function *Enable simple dialogs*.

This setting affects the following input dialogs:

- Log on order → A_AN
- Log on order + person → A_P_AN
- Interrupt order → A_UN
- Finish order → A_AB
- Post part quantities (partial confirmation) → A_TR



The activation of the simplified dialogs can only be performed once.
You can only undo the activation if you manually change the workflow.



With older installations: It is possible that with the simple dialogs "Log on order (A_AN)" or "Log on order + person (A_P_AN)" the data transfer to the dialog fields does not work after selection of an operation. Here, the configuration in the ctaipplay.ini must be corrected.

In section [WF@ANR], you must enter the current standard file ctaipplay.ini in line DATAFIELDS.