

1 Dynamic Dialogs - Workflow

Overview

Menu	System administration → Terminals → Workflow
Transaction code	ddconfw
Function authorization	ddconfw

Purpose

You can use the dialog configuration to change the AIP input dialogs in a quick and efficient manner according to the user's requirements.

The system delivery includes a basic dialog configuration. You can edit and change this configuration using the functions described in the following.

The function "Dynamic Dialogs - Workflow" defines the order of tabs in a complex dynamic dialog.



The complete functionality of the dialog configuration includes a lot of options, but it is also very complex. For this reason, we recommend to change the dialogs only after consultation with MPDV and only by experts.

Integration

To define the tab order, the fields and the buttons of dialogs, you must not only use the application "Dynamic dialogs - Workflow", but also the applications "Dynamic dialogs", "Dynamic dialogs - Fields" and "Dynamic dialogs - Function keys".

Requirements

The dialog that you want to configure must already exist in the "Dynamic dialogs".



Some of the functions require the development license MDS-AIS to be fully available. The restricted functions are marked in the document using "(*)".

Basics of the functions without development license:

- Existing data can be changed. Only data for default dialogs with user 0 must not be changed without development license.
- You cannot create new data without development license, except fields in existing dialogs.

- You can copy the existing data to terminal groups or terminals. Without development license, you cannot copy to default dialogs with user 0.

Selection criteria

The application provides the following selection criteria:

Workflow

Selection by workflow

Type

You can select from different dialog types:

- AIPDEF – default dialog
- AIPTNR – terminal dialog
- AIPTGRP – dialog for terminal group

Dlg user

Selection by terminal number or terminal group

Toolbar

Insert (*)

Creating a new workflow

Edit (*)

Editing a workflow



(*) Without development license, you cannot edit workflows. Editing a workflow is the same as creating a new workflow. You need a developer license to create new workflows.

Delete

[Deleting a workflow](#)

Copy

[Copying a workflow](#)

In addition to the standard function calls, the following function calls are available:



Dynamic dialogs

Function authorization: ddconf.*

The function "Dynamic Dialogs" calls the application [Dynamic dialogs](#).

**Test dialog**

Function authorization: ddconf.test

The function "Test dialog" opens the selected [Workflow](#) to test all settings and the functionality.

**Save dialog configuration**

Function authorization: none

The function "Save dialog configuration" saves the current dialog configuration.

**Activate dialogs**

Function authorization: ddconf.activate

The function *Activate dialogs* [activates the dynamic dialogs](#). The dialogs are then available on the terminals.

Field description

General

Workflow

Identifier of the workflow

The identifier can be assigned to a button on the AIP, for example. This button then opens the respective workflow dialog.

Type

AIPDEF:	default workflow
AIPTNR:	terminal workflow
AIPTGRP:	workflow for terminal group

User

User number restrictions

The default workflows have Dlg user "0" and type "AIPDEF".

Dialog

If you perform the function in the workflow using the server, the dialog identifier (DLG) specified in this field is transferred to the dialog data.

By specifying the dialog identifier via the "Dialog" field, you can define customer-specific workflows that send default dialogs to the server.

Title

Title of the workflow dialog. Using the notation <XXX>, you can define placeholders for important local information on the AIP. The title is then displayed as header in the workflow dialog.

Keep forced dialog sequence

If the field "Keep forced dialog sequence" is enabled, the order of the dialog steps is set and cannot be changed, i.e. you can only go to the next dialog step (tab).

User defined 1

Additional configuration options:

`BUTTONHEIGHT=50`

In case of workflows with several tabs, this configuration specifies the initial height of the button bar before scaling.



If you configure an alternative button height, the dialog field positions do not change automatically.

User defined 2...3

The fields "User defined 2...3" are currently not used.

Comment

You can use the field "Comment" to configure a description of the workflow.

Steps**Step 1...10**

Name of the dialog configuration for dialog step 1...10. The dialog steps are displayed and performed in the specified order. You can use the different dialog steps in any workflow.

Script 1...10

W: The script of the workflow is run (and not the script of the dialog step).

S: The script of the dialog step is run (and not the script of the workflow).

Copying dynamic dialogs (workflow)

You can use the function "Copy" to copy complete workflow configurations of a dialog.

Function selection

Copy entire configuration

You can use the function "Copy entire configuration" to copy the complete workflow configuration, e.g. from the default configuration (AIPDEF 0) to a terminal (e.g. TNR nnn, with nnn= terminal number). If you copy the workflow configuration, the default configuration is still used for all terminals that do not have an own configuration. And later on you can change the custom configuration without affecting other users. If you use the mode "Copy entire configuration", the input fields "Workflow from" and "Workflow to" are hidden.

Copy workflow

If you use the function "Copy workflow", only the workflow entries for a selected dialog (workflow) are copied.



(*) Without a development license, you can only copy entire workflows or the entire configuration. You cannot copy to default workflows for user 0 without a development license.

Deleting dynamic dialogs (workflow)

If you use the function "Delete", you can delete the entries that include workflow data. The dialogs themselves are not deleted.



(*) Without a development license, you cannot delete default dialogs for user 0.

Testing dynamic dialogs

Use the function "Test dialog" to call the dialog. You can test its functionality or the separate steps.

Activate dialogs

If you use the function *Activate dialog*, the configured dynamic dialogs are available on the server and can then be downloaded to the terminals. Without activation, the dialogs and the possible changes are saved on the system, but the terminals still download the version activated last.

You can activate dialogs for single terminals or for terminal groups. When you activate a dialog, you specify the activation type and the user number that can be a terminal or a terminal group.

Type	Value of field User	Description
AIPTNR, TNR	Terminal number	Activates all dialogs for the terminal.

		If a dialog is not explicitly configured for the terminal number, the dialog AIPDEF/DEF with user 0 is activated. The activation for user 0 provides the default dialogs.
AIPTGRP, TGRP	Terminal group	Activates all dialogs for the terminal group. The system only activates the dialogs that are explicitly configured for the terminal group.

In general, dialogs that are configured for a terminal have a higher priority than dialogs for terminal groups. If dialogs are activated for a terminal, the dialogs of the respective terminal group are ignored.

If no dialogs are activated for the terminal group or for the terminal number, the terminal loads the dialogs that are activated for user number 0.

Porting notes: from AIP to AIP2 / workflow with one workflow step

The difference in the terminal script processing in AIP and AIP2 in case of a workflow with only one workflow step is as follows:

Example:

Workflow: [U_TST]
with only one dialog step: [WF_U_TST]

In the **AIP**, all "dynamic dialog user exits" have been performed as **workflow** script ("U_TST").

In the **AIP2**, the following activities are performed independent of the dynamic workflow/dialog configuration:

- The user exit "DynDlgInit_" is always executed as **workflow** script ("U_TST").
- All other user exits are called in the **dialog** tab script ("WF_U_TST").

As of the AIP2 version 8.2.1.10, you can use the following workflow configuration to specify the same processing in the workflow script ("U_TST") as in the AIP:

"Step 1" "WF_U_TST" (STEP:1= WF_U_TST)
"Script" "W" (WFSCR:1=W)