

1 Function Groups

Overview

HYDRA menu	Master data → Escalation management → Function groups
FEDRA menu	Detailed scheduling → Master data → Escalation history
Transaction code	escfg
Function authorization	escfg

Purpose

You use this function to create or modify function groups in the system.

Integration

Use function groups in the escalation management to

- notify several recipients at a time;
- identify specific recipients within a group (e.g. a group of maintenance engineers) that meet special requirements, e.g. the recipient is present.

Requirements

You have defined the recipients as person in the [HR master data](#) and:

- if you want a notification via e-mail, you have created the e-mail address of the person;
- If you want a notification in the MOC, you have linked the user in the [User administration](#) to a person of the HR master.

Field descriptions

Function

The function is the name of the function group. If function groups already exist, you can select the group via the detail selection.

Priority

The priority defines the notification order within a function group. You can assign the same priority to several persons within a function group.

The highest priority is "1", the lowest priority is "999". The priority helps the system to deliver the messages.

Personnel number

The personnel number identifies the person that should be notified.

Check console

If you have checked the option, the system will verify if the person is logged on to the client. If the person is not logged on, the system verifies the person with the next priority level. You use this setting, if you do not use the "time and attendance" system. In case of a negative result, i.e. the person is not logged on to the client/console, the message is not delivered in an alternative form (text message, e-mail...).

Example:

Three maintenance engineers work in three different shifts. If you assign within a group the same priority to all three of them, only the engineer actually logged in to the console receives the message.

If you want to use the function "Check console", you must have entered the personnel number in the User administration.

Check attendance

If you have checked the option "Check attendance", the system will verify, if the respective employee is logged on to the PZE system "time and attendance" (only in connection with PZE-BP).

The escalation management will suppose that the person is present, if the following PZE events occur: In, break, entrance before clocking in (with access control system ZKS).

There is an AND-link between the settings "Check console" and "Check attendance". If both options are checked, the person only receives messages when he or she is present AND logged in to the console.

That is the reason why we recommend to check the option "console" OR the option "attendance".



The system cannot send a message to a function group, if no one of this group is logged in to the console or is logged in to the PZE system "time and attendance".

In this case the escalation management will generate the event "NO_PERSON_AVAILABLE". You should assign a dispatcher group to this event or you should search for this event on a daily basis in order to find cases left aside.