

1 Setup Change List

Overview

HYDRA menu	Production control --> Planning aid --> Setup change list
FEDRA menu	Detailed Scheduling → Planning → Setup change list
Transaction code	setli
Function authorization	setli

Available user fields		
Where?	Object type/user field key	Source (type)
Setup change list table	AGNR/SYSTEM	Operation (MF-D)
How to configure user fields?		Which user field types are available?

Purpose

The setup change list provides the user with an overview of the machines to be set up next. The operations listed which are planned in next. Setups, due to material, tool or color changes, are marked to improve your overview.

In addition, the setup change list has been designed as preview for (subsequent) shifts, which enables the responsible persons in the shift to know which machines have to be set up next.

Requirements

Operations have to be planned exactly with respect to dates to be able to determine setup changes.

Selection criteria

The application provides the following selection criteria:

Date ... until

Shows all planned setup changes (planned operations) that coincide with the selected date range. The option "consider job end" option (see below) specifies which operations are exactly to be taken into account.

Cost center

Shows the setup changes that are planned on workplaces assigned to the selected cost center.

Workplace

Shows the setup changes that are planned on the selected workplaces.

Group

Shows the setup changes that are planned on the workplaces of the selected groups.

Order category

Shows the setup changes that are planned for orders of the selected order category.

Consider job end

Generally, only planned operations assigned to the control indicators L, S, V or U are taken into account. Subject to the "consider job end" option, the result list and, as a result the table, shows the following operations:

- The "consider job end" option is set: operations the start of which is prior to the selection period and the planned end of which coincides with the selection period are displayed. This applies to planned as well as running operations.
- The "consider job end" option is set: the below-mentioned operations are considered in addition to operations the planned start of which coincides with the selection period: - operations the start of which is prior to the selection period and the planned end of which coincides with the selection period

- operations the start of which is prior to the selection period and with the planned end after the selection period. This applies to planned operations (control indicators S, V, U) as well as running operations (control indicator L).

It can be reasonable NOT to check the "consider job end" option, provided that setup change lists are to be printed for each shift in advance.

Field descriptions

In general, if selected by workplace, group and cost center, only operations are selected that are actually planned on a workplace. Operations that are in the pool of groups are not selected. In addition, only operations are selected that are planned on workplaces for the responsibility area of which the user is authorized.

Remarks on selected columns

Workplace

Shows the workplace where the OP is currently planned for OPs that are not running (status U or V). For running OPs, the workplace is displayed where the OP is currently logged on.

Group

Group to which the workplace is assigned.

Cost center

Cost center to which the workplace is assigned.

Status

Current operation status. Shows the colored LED as well as the status text.

Article

The value is taken from the operation.

←Planned start/planned end

The planned dates can be taken from the order information, tab Detailed Planning, under Planned Dates - Start or End. Note: the planned dates as per planning are used; the remaining run time is not taken into account.

Target duration

The target duration is calculated as follows: $(\text{target quantity} * \text{target cycle} / \text{part} / 1000) * \text{machine efficiency} / 100$ ←←

Tool

The value is taken from the operation.

Storage location

(Original) storage location that is assigned to the tool. Please note: This information is only provided if the HYDRA tool and resource management (HYDRA-WRM) module is in use and edited in this master data.

Current storage location

Storage location that the tool is assigned to on the basis of its logon as a resource of type WNR. The material buffer that is assigned to the workplace in the workplace/resource configuration as the upstream material buffer is used as the storage location.

Note: The assignment is only done in case of using the HYDRA Tool and Resource Management (WRM).

Color

The value is taken from the operation.

Addition

The value is taken from the operation.

Planned start (setup date)

Planned setup date; corresponds to the planned start date of the operation.

Change

See below.

"Symbol"

See below.

Setup time

Total of the values "setup time" and "additional setup time" at the operation.

M/O rel. setup

Machine/operator relation for setup; the value is taken from the operation.

Table setup change, symbol

When setting the value in the Setup Change column, the neighboring operations are evaluated (according to the planned start date).

- If the value in the Tool field changes, the value "Tool" and the symbol are entered. 
- If the value in the Tool field does not change, but the value in the Color field does, then the "Color" value and the icon are entered. 
- If the value in the Tool and Color fields does not change, but the value in the Material field does, then the value "Material" and the symbol are entered.  .
- If the value in the Tool, Color and Material fields does not change, but the value in the Article field does, then the value "Article" and the icon will be entered.  The symbol for "Article" and "Material" is the same.



These values remain even if the user chooses another table sorting that does not correspond to the sequence of the planned dates.

The fields described above are the fields that are directly adjacent to the operation.

Toolbar

When you call a function or target application, the parameters of the table are always transferred. For this reason, always select an entry to call an application.



Order information (function authorization: orin)

Use this button to call the application [Order information](#).



Order overview (function authorization: orov)

Use this button to call the application [Order overview](#).