

1 Split Batch

Summary

Menu	Material management→ Inventory management→ Batch data overview→ Split batch
Transaction code	batch.split
Function authorization	batch.split

Usage

The split batch function in [batch data overview](#) can be used to split and/or to separate an existing batch into an unrestricted number of batches.

The number of splits will only be restricted by the remaining quantity of batches or in case of merged batches by the remaining subordinate batches/serial numbers. If the sum of the split quantities is higher than the remaining quantity of the original batch, splitting is not possible. It is possible to create splits with yield and/or scrap quantities.

Requirements

A batch can only be split if the following conditions are met:

- the batch must have the status F (free)
- the batch must have a remaining quantity that is higher than 0 or must be assigned to subordinate batches/serial numbers accordingly.
- the user must have the function authorization for splitting

At the moment, it is impossible to:

- split off individual subordinate batches/serial numbers from merged batches that will not be linked up in a new merged batch.
- split scrap batches/locked batches.

Selection criteria

The possible selection criteria are the same as for the [batch data overview](#).

There are two tables to select the respective batches manually.

- Table for viewing all of the selected batches (altogether).
- Table with the batches already selected for splitting.

Field descriptions

The main fields of the function are described in the following:

Splitting "simple" batches:

Quantity to be split off

Entry of the quantity that is to be split off from the existing batch

Batch class

Entry of the batch class to be created

Quantity

Entry of the quantity to be split off

Reason

Entry of the batch reason if the class is scrap

Print report

This indicator must be set to print-out a report stored to the split batch (as an option)

Splitting merged batches:

Batch number

External batch number of the selected merged batch

Internal batch number

System-wide unique batch number of the selected merged batch assigned internally.

Batch class

Batch class of the selected merged batch.

Remaining quantity

Current quantity of the selected merged batch.

Batches to be split off

The display list shows all subordinate batches/serial numbers assigned to the selected merged batch. They are selected and split off accordingly.

Batch class

Batch class to be selected for the new merged batch to be split off.

Reason

Entry of the batch reason if the batch class of the merged batch to be split off is e.g. scrap.



This function is only available if the modification [batchsplitextension](#) is enabled.

Editing functions (of batch data overview)

In general, the batch data overview provides the following two variants to split batches.

Provided that the function authorization MALUSPLITM is available, the "split batch" function provides two options of splitting/separation. Otherwise, the selection option is disabled and the option "repost remaining quantity of batch to new batch" is set by default.

For "simple" batches:

1. Repost remaining quantity of batch to new batch

If the sum of the split quantities is smaller than the remaining quantity of the batch, this difference quantity will be used to create a new batch (class: yield; status: free). The existing batch will then be set to the "processed" status.

2. Reduce existing batch to remaining quantity

The existing batch will be reduced by the sums of the split quantities. If the remaining quantity of the batch will then be 0, the status will be set to "processed".

For merged batches:

Users select the merged batch they want to split off. If it is a "merged batch" (indicator at the batch), the application shows all subordinate batches/serial numbers assigned to this merged batch.

Users choose (multiple selection) the subordinate batches/serial numbers they want to split off into a new merged batch. Users select the batch class for the new merged batch (and thus for the newly assigned subordinate batches/serial numbers).

After using the "split" function, the new merged batch is posted and the selected subordinate batches/serial numbers are assigned to the new merged batch. To do so, the relevant assignment to the "old" merged batch is deleted. The remaining, unselected sub-batches/serial numbers remain with the existing merged batch (existing number).



This function is only available if the modification [batchsplitextension](#) is enabled.