

1 Workplace terminal assignment

Overview

	→	
Menu	Master data => Workplaces/machines => Terminal assignment	
Transaction code	wta	
Function authorization	mdwta	

Purpose

This function is used to configure the machine assignment for the terminal.

Purpose

The assignment of a machine to a terminal is a requirement to use MDE-specific functions such as automatic shift change, cyclic status updates or recording via MSS. However, these functions are only available if the terminal is configured as a so-called "MDE terminal" (see Terminal Configuration). Terminals configured as ADE terminals do not provide these function even if the machines/workplaces are not assigned to the terminal.

The assignment ensures that the machine/OP is displayed by default on the terminal.

The number of machines that can be assigned depends on the terminal type.

Terminal type CT-541:	only one assignment possible
Terminal type CT-76x, CT 83x, CT84x, CT850 (AIP 8.1 and 8.2):	up to 16 assignments possible (even though the terminal is configured as master terminal) up to 10 machines may be used for the process data collection (HYDRA-PDV).
Terminal type CT-56x:	up to 8 assignments possible
Terminal type A-SUB	up to 20 assignments possible.

All machines previously assigned to terminals are shown according to the selected terminals. The order in which the display is shown on the terminal is determined by the position specified here.

If a production line (only available if MDE-LIN license is available) is assigned to the terminal, all aggregates of the production line are automatically assigned to the terminal and displayed in gray under the position "99". Aggregates cannot be removed from the assignment. If a production line is removed from the assignment, the aggregates assigned to the production line are automatically removed. Production lines can only be attributed to the terminal types CT76x, CT83x (max. 2 lines) and CT84x (max. 3 lines).

The option "Processing" can perform different assignments of the machine type to the terminal. The following options are available:

A - BDE processing

M – MDE processing

Processing as per operation mode of the terminal

Therefore, workplaces/machines with HYDRA-MDE-processing and workplaces only with HYDRA-ADE-processing may be assigned to an MDE terminal.

You have to set the processing to "BDE processing" for a group workplace, if you want to assign the group workplace to a terminal.



Number of terminal assignments

You can only assign a machine/workplace to a single terminal. If you want to assign a machine to several terminals, then you have to obtain the appropriate license.



Configuration changes

Restart the terminal to ensure that the settings or changes made can be interpreted by the terminal shop floor program.

Selection criteria

The application provides the following selection criteria:

From - to

Select terminal number

Field descriptions

Terminal

Assign a machine to a unique terminal number.

Position

Display position of the machine at the terminal and for the terminal assignment at the client.

Machine

Machine you assign to the terminal.

Processing

Here, you have the following 3 options:

- A BDE processing
- M MDE processing
- Processing as per operation mode of the terminal