

1 List of Measures containing Detailed Display

In the measure overview a list of all measures appears on the left hand side. This list contains measures relating to complaint header, complaint detail as well as failure analysis.

If a complaint contains several complaint details, for each combination of complaint header and complaint detail a separate entry appears in the complaint overview list. All measures are displayed in order to obtain an overview. It is irrelevant if the measures are assigned to a complaint detail or a failure type. Therefore, all measures are displayed which refer to the same complaint number.

The content can be restricted using a filter. A match code filter is available for the user. Content to be filtered in a text is replaced by the symbol "*". Using the symbol "?" an individual symbol can be replaced. The complete content of a measure list can be filtered. The following information is part of the complaint list:

- Measure number - measure description
The above information is separated with a hyphen and is displayed in the 1. line of a measure.
Possible display format: "2324 - oil parts" ("2324 is the measure number and "oil parts" is the measure description).
- Measure text - target date

Article number - article description
Information is part of the 2. line and are also separated by a hyphen.

Also, the status of a complaint is highlighted by a colored LED symbol. The following color assignments for a measure status are valid:

- Completed => green LED
- open=> yellow LED
- in process => red LED
- sighted => blue LED
- other status => black LED

In the right display area detailed information is shown in the list for the selected measure. The parallel display of the left and right display area is dependent on the selected display medium. Only the measure list is displayed on the smartphone. In order to show details the required measure should be selected.

Using a smartphone the fields "Fulfillment in %" and "Effectiveness in %" are not displayed.

In the detailed overview the selected measure can be processed via a button.

The new creation of measures is carried out in the home screen of the detailed complaint display. Here you can decide if the measure should be collected in the complaint header or the complaint detail.

Collection of measure for a failure type can only be done via the MOC.