

1 Configuration PDV-ESK

1.1 Activate escalation messages

Escalation messages are activated in the terminal. The configuration file `pdv_dll` is stored in the directory "ctwin" or "ctaip"... In this file, you can modify the `CallESK` parameter. By default, the function is disabled and set to "N". The function is enabled if the parameter is set to the value "Y".

Excerpt from the file `pdv_dll.ini`:

```
[Common]
; # @Eskappendix:      file ending of captured escalations
Eskappendix=pesk
[Blade]
; # @CallESK:          flag whether escalation messages should be sent when limits are exceeded
; #                   supported values are Y (Yes, send messages) and N (do not send messages)
; # @ESKWaitTime:      time interval that has to pass before escalation messages are sent
;                       successively
CallESK=Y
ESKWaitTime=600
```

1.2 Define limits and activate automatic generation of errors

MOC: Quality management - Process data collection - Collection rules. Go to: *Recorded characteristics*, tab *Specifications*

Here, you can define the limits mentioned below. These limits specify when an automatic error and a resulting escalation are generated. The limit value must be a valid decimal value and the option that enables the automatic generation of errors must be checked.

You may include the following limits in an escalation:

LTL	lower tolerance limit
LPAL	lower process action limit
UPAL	upper process action limit
UTL	upper tolerance limit

1.3 Further conditions

MOC: Quality management - Process data collection - Collection rules. Go to: *Recorded characteristics*, tab *Inspection - Computation*

Enable the option "Check characteristic".

In addition, the process parameter you want to evaluate must be of data type INTEGER or DECIMAL.

1.4 Debug options

You can easily trace back the correct configuration using the file pdvinitpp.2<terminal no>. The section including the process parameters is most important. The following must apply for the process parameters:

CHECKLIMITS	Y	(merkmal_pruef / [v] check characteristic)
DATATYPE	DECIMAL or INTEGER	
ESKUPIL	Y	(opeg_aktiv / in specification dialog : [v] auto. generate error for UPAL)
ESKUTL	Y	(otg_aktiv / in specification dialog : [v] auto. generate error for UTL)
ESKLTL	Y	(utg_aktiv / in specification dialog : [v] auto. generate error for LTL)
ESKLPIIL	Y	(upeg_aktiv / in specification dialog: [v] generate auto error for LPAL)
UPIL	integer	(UPAL (must not be empty or (null) if ESKUPIL= Y))
UTL	integer	(UTL (must not be empty or (null) if ESKUTL=Y))
LTL	integer	(LTL (must not be empty or (null) if ESKLTL=Y))
LPIL	integer	(LPAL (must not be empty or (null) if ESKLPIL=Y))