

1 Configuration of Weighing Components

Usage

You use the "pass batch attributes on" function if attributes of input batches are to be transferred to the generated output batch when changing output batches.

Dialog configuration

The input function is controlled by the dynamic dialogs A_VBRKOMP and KOMP_WIEG

Activation of the posting function at the terminal

Specific posting functions are enabled at AIP by an entry in the file *ctaipbut.ini*.

This is an example for the entry in ctwinbut.ini:

CTAIPBUT.INI
F1=A_VBRKOMP, weigh



The dynamic dialogs A_VBRKOMP and KOMP_WIEG must be available.

System configuration

Operation data

The following additional fields have be filled out for the operation using the PPS interface:

- No batch management requirement
- Target quantity per charge (calculated form primary target quantity / secondary quantity)(ab.soll_menge_ansatz)
- Number of charges (secondary quantity in pieces) - default = 1
- Batch

Data included in component list

These parameters have to be filled out for discrete material components using the PPS interface:

- Tolerance (in percent) → mlst_hy.mengen_tol

- Deviation (absolute value) → mlst_hy.mengen_abweichung
- Input quantity and unit of input quantity
- Component type must be D - discrete