

Manual

Cavity-Related Change of Partitioning BDE-NBT 8.2

Version 1.2.23049

Last changed on: 01.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Overview: Cavity-Related Change in Partitioning	4
2	Recording of the Cavity-Related Partitioning on the AIP	5
3	Reason Texts	8
4	Reasons	9

1 Overview: Cavity-Related Change in Partitioning

Purpose

This component is used if you wish to perform and document cavity-related changes in partitioning or cavity.

Integration

The cavity-related change in partitioning is performed at Windows shop floor terminals. The function represents an extension of the posting dialog "Change partitioning" (M_TLG) available in the BDE/MDE.

If you use the Tool and Resource Management module (WRM) and its WRM-NST component, extended tests against WRM master data are feasible.

Features

- Definition of reasons for the change in partitioning/cavities at Windows shop floor terminals
- Recording of released and blocked cavities at Windows shop floor terminals. Input of the cavity number, selection of a reason and entry of an optional comment
- Checking partitioning when logging on the order against the partitioning of the tool resource (precondition: WRM-NST) and warning if exceeded.
- Display of a list for selection of a cavity and validation check of the cavity number against the cavities defined at the tool resource (precondition: WRM-NST).
- Reducing or increasing the partitioning of the machine and the active operation by the number of released or blocked cavities
- Additional activation/deactivation of the mold cavity master data and calculation of the current partitioning in the tool master data record (precondition: WRM-NST).
- Logging of the posting "Change in partitioning" as an event
- Display of the logged posting in the workplace/machine history (precondition: MDE-MMD).

Please note: The posting dialogs are activated as part of HYDRA customizing.

2 Recording of the Cavity-Related Partitioning on the AIP

Purpose

You use this function to document changes when tool cavities are opened or closed.

Integration

If you change the so-called partitioning (i.e. the parts per cycle), the partitioning stored for the operation selected is changed. The change of the partitioning is documented in the machine history.

If you use the Tool and Resource Management (WRM) and if you change the cavity-related partitioning, then the system also changes the partitioning that is stored for the currently logged on tool.

Requirements

This functionality requires a license. The configuration requirements are described in section [Configuration](#).

Function description

When you open the dialog, the order information is transferred from the operation selected and displayed in the dialog. Except the field *Comment*, all fields of the dialog must be filled.

Cavity number (*mandatory field*)

You can select the cavity number via list (only in connection with WRM) or enter the number manually.

Reason (*mandatory field*)

The selection list of the *Reason* shows reasons that you can select according to the "type of change" selected.

Configure the reasons on the client in the configuration "reasons". Distinguish between increase (reason type "E") and reduction (reason type "R").

Comment (*optional field*)

You can enter a comment for the posting.

Staff badge number (*mandatory field*)

Enter the ID/badge number of the person making the posting.

The person must be authorized in the HR master data to change the cycle/partitioning.



The partitioning is changed on the server. For this reason, you can only change the partitioning on the server in ONLINE mode because the lists on the terminal cannot be updated otherwise.

Configuration

Configuration on the MOC

To use the function, you must configure reasons for the increase or reduction of the partitioning. First create the [reason texts](#) on the MOC, then assign them to the [reasons](#). When you configure the reasons, you must distinguish between increase of partitioning (reason type "E") and reduction of partitioning (reason type "R").

Configuration AIP 8.1 or AIP 8.2 in list mode

In the standard configuration file ctaipbut.ini, the configuration has been prepared as follows.

Standard configuration

```
...
[MNR-ALL-Page2]
;1=M_TLG_NEST,L,Kavität ändern,Objects.png
1=M_TLG,L,Teiligkeit ändern,Objects.png
...
```

After change of the configuration

```
...
[MNR-ALL-Page2]
1=M_TLG_NEST,L,Kavität ändern,Objects.png
;1=M_TLG,L,Teiligkeit ändern,Objects.png
...
```

Configuration AIP 8.2 in tile mode



Please note the specifications made for any customer-specific configuration on the AIP. The configuration options are presented in the training EAT-AIP *Extended Application Training MES-Terminal*.

1. Close the shop floor software, if started.
2. Call the Windows Explorer (e.g. using the shortcut <Windows> + e).
3. Change to the AIP subdirectory *gui*.
4. Create a backup of the file *L_anr.xml*.
5. Start an editor (e.g. notepad) and open the file *L_anr.xml*.
6. Search for the line, that includes *M_TLG* :
 <OnClick Identifier="M_TLG" Parameterprozessor="TFocusedDataRows">Notify</OnClick>

7. Change the identifier from *M_TLG* to *M_TLG_NEST*:

`<OnClick Identifier="M_TLG_NEST" Parameterprozessor="TFocusedDataRows">Notify</OnClick>`

8. Save the file *I_anr.xml*.
9. Start the shop floor software.

3 Reason Texts

Summary

	Doku-Eigenschaft „Version“ hinzugefügt	
Menu	Master data → Workplaces / Machines → Reason texts	
Transaction code	reat	
Function authorization	mdreat	

Usage

Use this function to create or to change the reason texts available in the system.

Integration

The basic texts saved to the system will be shown upon the definition of the [Reasons](#) as reference.

Field descriptions

Reason texts

Unique number to identify the text

Designation

Designation of the reason text

4 Reasons

Summary

Menu	Master data → Workplaces / Machines → Reasons
Transaction code	reas
Function authorization	mdreas

Usage

Use this configuration to create or to change the reasons available in the system. Reasons may either be created for the entire system or referred to a workplace

Integration

The reasons that are saved to the system will be available for collection on the terminal as well as in different applications. They are used to classify quantities of materials or modifications.



In order for the settings or the changes made to be able to be interpreted by the terminal shop floor program, the terminal, which the workplace/machine is assigned to, has to be restarted. All terminals should be restarted, provided that new reasons have been created or reasons affecting the entire system have been changed.

Requirements

You have defined [reason texts](#) in the system.

Selection criteria

The following selection criteria are available in the application:

Type

Reason type, e.g. scrap

Workplace

Workplace selection.



Reasons that are configured for the "workplace" SYSTEM, will always be displayed even if a workplace will explicitly be restricted.

Reason

Unique reason number

Designation

Designation of the reason. Wildcards can be used.

Superior reason

Selection of a superior reason. All reasons will be selected that have the selected reason as (direct) superior reason.

Field descriptions**Workplace**

Assignment of a reason text to a workplace. If "SYSTEM" is entered, this will apply as system-wide assignment.



System-wide reasons will always apply in addition to the workplace-specific reasons and will therefore also be displayed in the terminal's selection list.

Type

Classification and/or grouping of reasons

Possible values:

A	Scrap reason
N	Rework reason
P	Open quantity reason (before: problematic quantity)
G	Yield reason: will be interpreted as deviation reason
L	Reasons for batch logs (relevant in connection with MPL)
R	Reduce (partitioning) reason (relevant in connection with WRM)
E	Increase (partitioning) reason (relevant in connection with WRM)

Reason

Identification number of the reason.



As system-wide reasons always apply in addition to reasons relating to workplaces, their numbers have to be unique, i.e. a scrap reason with the number 99 for the SYSTEM workplace must not be defined at the same time as workplace-related scrap reason assigned to the number 99.

Reason text no.

Identification number of the [reason text](#)

Designation

Related reason text from the reason text configuration.

Ext. reference

For each assignment exists an alphanumeric representation that can be uploaded back to the interface, for example

Scrap material

Is used in connection with HYDRA-MPL

Superior reason

The reference to a superior reason is reserved for further extensions/modifications; at present it has no function and should consequently not be completed.

“Copy“ detail application

The "copy" button can be used to copy reasons defined in relation to a workplace from one workstation to the next. Reasons of the "workplace" SYSTEM cannot be copied.

The below-mentioned options are supported while copying:

- **Copy currently selected reason**

This option can be used to copy the currently selected reason. For this purpose, enter the below pieces of information in the fields below "To":

 - **Workplace:** target workplace for which the reason is to be copied
 - **Type:** Choose the reason type under which the reason is to be created for the target workplace. The field is assigned by default to the type of the currently selected reason.
 - **Reason:** Enter the reason number under which the reason is to be created for the target workplace. The field is assigned by default to the type of the currently selected reason.
- **Copy all reasons**

This option allows copying of all reasons defined for a workplace to another workplace. However, a prerequisite for this is that reasons have not yet been configured for the target workplace. To do so, enter the target workplace for which the reasons are to be copied in the "workplace" field. Please note that all workplace reasons are always copied, irrespective of the type of the reason.
- **Copy missing reasons**

In contrast to the previous option, this function allows for reasons to be copied to another workplaces, even if reasons are already assigned to this workplace. To do so, enter the target workplace for which the reasons are to be copied in the "workplace" field. Please note that all workplace reasons will always be copied, irrespective of the type of the reason.