

Manual

Escalation Messages for FEP FEP-ESK 8.1

Version 1.0.1374

Last changed on: 19.06.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Overview – Escalation Messages for FEP	4
2	Available Escalations	5
2.1	Error Analysis Criterion Generated for an Inspection Order (CPAUERR.INSERTED)	5
2.2	Measure Generated (CMASSN.INSERTED)	8
2.3	Formula Calculation: Incorrect Characteristic Reference in Calculated Characteristics (CPAUMW.CALCULATED_CRITERIAS_GET_VARIABLE_VALUE)	9
2.4	Error when Setting the Calculated Variable Value (CPAUMW.CALCULATED_CRITERIAS_SET_VARIABLE)	10
2.5	Revised Inspection Severity (CDYHSTPR_DYPSCHARF_CHANGED)	11

1 Overview – Escalation Messages for FEP

Purpose

HYDRA escalation management provides a framework of functions that can be used to forward events that occur or were recorded in HYDRA to individual users or user groups in real time. During the process, escalation management takes active steps to ensure users are notified.

After notification, escalation management monitors times until acknowledgment by the recipients and until escalation is concluded. Escalations can be forwarded to other users or user groups during processing.

Implementation Notes

You use escalation management when you would like to have active, real-time notification of specific events in the area of in-process inspections in order to prevent failures and to increase efficiency and productivity through rapid response.

Integration

The triggered events/escalations are posted to central escalation management. This forms the framework for forwarding and following up on the events triggered.

For notification of people, escalation management accesses both [User administration](#) and the [HR master data](#) stored in the system. Notifications can be sent out as e-mails by integrating the local mail server into the system.

Features

- Provision of different escalation postings in the area of inspection data collection
- Event configuration: Configuration of order-related events
- Forwarding of the detected events to the escalation framework.

2 Available Escalations

2.1 Error Analysis Criterion Generated for an Inspection Order (CPAUERR.INSERTED)

If an error analysis criterion (failure type, failure location, failure cause, etc.) for an inspection order is generated, the escalation is triggered.

Event	IDs	Description
CPAUERR.INSERTED	CPAUERR.RECTYP	Data type
	CPAUERR.BER	Area
	CPAUERR.PANNR	Inspection requirement
	CPAUERR.PAUNR	Inspection order
	CPAUERR.AFO	OP
	CPAUERR.STPRNR	Sample number
	CPAUERR.WERTNR	Measured value number
	CPAUERR.ERRTYP	Type of error analysis entry FA (failure type) FU (failure cause] FO (failure location) VU (causer) Different entries for each type could be defined in the quality master data.
	CPAUERR.ERRNR	Number of error analysis entry
	CPAUERR.GEWICHTUNG	Weighting
	CPAUERR.BEM	Comment
	CPAN.FU:1 CPAN.FU:2 CPAN.FU:3 CPAN.FU:4 CPAN.FU:5	Fast user field 1 Fast user field 2 Fast user field 3 Fast user field 4 Fast user field 5 (of inspection requirement) (Type: CHAR)

Event	IDs	Description
	CPAN.FU:6 CPAN.FU:7 CPAN.FU:8 CPAN.FU:9 CPAN.FU:10	Fast user field 6 Fast user field 7 Fast user field 8 Fast user field 9 Fast user field 10 (of inspection requirement) (Type: LONG)
	CPAN.FU:11 CPAN.FU:12	Fast user field 11 Fast user field 12 (of inspection requirement) (Type: Double)
	CPAN.FU:13 CPAN.FU:14	Fast user field 13 Fast user field 14 (of inspection requirement) (Type: Date)
	CPAN.ATK	Article number (of inspection requirement)
	CPAN.ATKIDX	Article IDX (of inspection requirement)
	CPAN.ANR	Order number (CAQ) (of inspection requirement)
	CPAN.MNR	Machine number (of inspection requirement) (of sample) (Feb.2011)
	MNR.BEZK	Machine designation
	ARTIKEL.ATKBEZ	Article designation
	ARTIKEL.GRP	Article group
	CMM.OTG	Upper tolerance limit (absolute figure) (of the inspection order characteristic)
	CMM.UTG	Lower tolerance limit (absolute figure) (of the inspection order characteristic)
	CPAUMW.MW	Measured value
	CPAUMW.BEMERK	Comment (of the measured value)
	CPAUMW.PNR	Inspector ID (of the measured value)
	CPAUMW.KNR	Inspector badge number (of the measured value)
	CPAUMW.NUM:EINTTYP	Type of number entry ("NUMBER")
	CPAUMW.NUM:EINTNR	Number of the number entry

2.2 Measure Generated (CMASSN.INSERTED)

When a measure is generated, the escalation is triggered.

Event	IDs	Description
CMASSN.INSERTED	CMASSN.MASSER	Measure ID
	CMASSN.RECTYP	Data type
	CMASSN.RECREF	Assignment
	CMASSN.BER	Area
	CMASSN.KEY:1	Key field 1
	CMASSN.KEY:2	Key field 2
	CMASSN.KEY:3	Key field 3
	CMASSN.KEY:4	Key field 4
	CMASSN.KEY:5	Key field 5
	CMASSN.MASNR	Measure number
	CMASSN.MASTEXT	Measure text
	CMASSN.VERANT:TYP	Responsible - Type
	CMASSN.VERANT:NR	Responsible - Number
	CMASSN.STA	Status
	CMASSN.ZIELDAT	Target deadline - Date
	CMASSN.ZIELZEI	Target deadline - Time
	CMASSN.ELEM	Corresponding workflow element
	CMASSN.BEM	Comment
	PNR	Responsible (only when the responsible person comes from the personnel catalog)

2.3 Formula Calculation: Incorrect Characteristic Reference in Calculated Characteristics (CPAUMW.CALCULATED_CRITERIAS_GET_VARIABLE_VALUE)

If the reference could not be resolved to a source characteristic during calculation of characteristics, an escalation is triggered.

Event	IDs	Description
CPAUMW.CALCULATED_CRITERIAS_GET_VARIABLE_VALUE	CPAUMW.RECTYP	Data type
	CPAUMW.BER	Area
	CPAUMW.PANNR	Inspection requirement number
	CPAUMW.PAUNR	Inspection order number
	CPAUMW.AFO	OP
	CMERK.BFORMEL:TYP	Level of characteristic calculation (see document Formula Calculation) V - Single values S - Samples C - Characteristics
	CMERK.BFORMEL	Calculation formula for the characteristic
	ERR:TEXT	Error description
	VAR:NAME	Incorrect variable

2.4 Error when Setting the Calculated Variable Value (CPAUMW.CALCULATED_CRITERIAS_SET_VARIABLE)

During calculation of characteristics, it was possible to resolve a reference to a source characteristic. If an error occurred when inserting the calculated numerical value into the formula, an escalation is triggered.

Event	IDs	Description
CPAUMW.CALCULATED_CRITERIAS_SET_VARIABLE	CPAUMW.RECTYP	Data type
	CPAUMW.BER	Area
	CPAUMW.PANNR	Inspection requirement number
	CPAUMW.PAUNR	Inspection order number
	CPAUMW.AFO	OP
	CPAUMW.STPRNR	Sample number (of the calculated value)
	CPAUMW.WERTNR	Single value number (of the calculated value)
	CMERK.BFORMEL:TYP	Level of characteristic calculation (see document Formula Calculation) V - Single values S - Samples C - Characteristics
	CMERK.BFORMEL	Calculation formula for the characteristic
	ERR:TEXT	Error description
	VAR:NAME	Name of the variable concerned
	VAR:VALUE	Calculated value for the variable

2.5 Revised Inspection Severity (CDYHSTPR_DYPSCHARF_CHANGED)

If the inspection severity is revised, the escalation is triggered.

Event	IDs	Description
CDYHSTPR_DYPSCHARF_CHANGED	CPAUSP.RECTYP	Data type sample
	CPAUSP.BER	Sample range
	CPAUSP.PANNR	Inspection requirement
	CPAUSP.PAUNR	Inspection order
	CPAN.ANR	Order
	CPAU.AGNR	Operation
	CPAUSP.AFO	OP
	CMERK.CMMNR	Characteristic number
	CMERK.MMBEZ	Characteristic designation
	CPAUSP.STPRNR	Sample
	CPAUSP.DEVICE:TYP	Device type
	CPAUSP.DEVICE:ID	Device
	CPAUSP.DEVICE:STPRNR	Device sample
	DYPSCHARF:ALT	Old inspection severity
	DYPSCHARF:NEU	New inspection severity
	CHANGE:DAT	Date of change
	CHANGE:ZEI	Time of change