

Manual

Client Performance Analysis Machines / Workplaces MC-CPAM 3.2

Version 1.1.23049

Last changed on: 01.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Performance Analysis - General	4
1.1	General	4
2	Performance Analysis	5
2.1	Dashboard: Overview	5
2.2	Dashboard: Workplace Evaluation	5

1 Performance Analysis - General

1.1 General

It is the objective of the Performance Analysis to evaluate the data available from the connected systems. Subject to the evaluation's objective, the following dashboards may be chosen.

Please note: MES Cockpit uses a separate data basis including the functions integrated there.

2 Performance Analysis

2.1 Dashboard: Overview

Function authorization MC-Overview

The overview's aim is to present information for the current shift.

The three defined KPIs such as the rate of capacity utilization, OEE and setup rate are shown for the selected workplaces and all produced yield and scrap quantities are compared with each other. KPIs are presented in a tachometer chart.

The user may select the relevant objects to restrict the objects included in the overview.

2.1.1.1 Selections

The following selection options are provided in this dashboard:

- Workplace
In addition to the workplace number, the machine's site is also shown (name of system from which the machine is imported). Only those workplaces are shown for which the user is authorized by the responsibility area or for which no responsibility area is defined. Responsibility areas of imported machines are configured and edited via the administration client of MES Cockpit.
- Cost center
Only the cost centers of displayed workplaces may be selected.
- Workplace group
Only the workplace groups of displayed workplaces may be selected.

2.2 Dashboard: Workplace Evaluation

Function authorization MC-WPAnalysis

The objective of the dashboard is to present and evaluate machine-related KPIs using different groupings and dimensions. The individual reports allow switching between the different dimensions, such as year, calendar week, shift date and shift by zooming in and out (drill down).

In addition to calculated KPIs, defined target values are also shown if defined and, as a result, they can be evaluated.

2.2.1.1 *KPI Report*

Up to three selected KPIs of the selected workplaces including the relevant target values are shown over time. In addition, the mean value of the selected data is calculated and displayed in the diagram.

2.2.1.2 *Cost Center Report*

Up to three selected KPIs of the selected workplaces are shown grouped by cost centers.

2.2.1.3 *Workplace Group Report*

Up to three selected KPIs of the selected workplaces are shown and grouped by workplace groups.

2.2.1.4 *Workplace Overview Report*

Tabular presentation of the workplace overview showing master data and the produced quantities including a yield rate. All selected machines and the total quantity are shown for the period of time selected for the machines.

2.2.1.5 *RPA Analysis Report*

The totals of individual RP accounts are presented for the selected machines and the selected period of time in a pie chart.

Please note: If no values are available for individual RP accounts, they will neither be shown in the diagram nor the legend.

2.2.1.6 *Production Overview Report*

The production overview compares the entire yield and scrap quantities (primary quantity unit) of the selected machine and the entire time selected by machine group.

2.2.1.7 *Selections*

The following selection options are provided in this dashboard:

- KPI

Only those KPIs are shown for which the user is authorized by the responsibility area or for which no responsibility area is defined. KPIs and responsibility areas are defined using the administration client of MES Cockpit.

- Workplace

In addition to the workplace number, the machine's site is also shown (name of system from which the machine is imported). Only those workplaces are shown for which the user is authorized by the responsibility area or for which no responsibility area is defined. Responsibility areas of imported machines are configured and edited via the administration client of MES Cockpit.

- Cost center

Only the cost centers of displayed workplaces may be selected.

- Workplace group

Only the workplace groups of displayed workplaces may be selected.

2.2.1.8 *Time selections*

The following times/periods may be selected in this dashboard:

- Shift
- Day
- Month
- Quarter
- Year
- Calendar week

Only the contents for which the system actually includes data are shown.