

Manual

PMV Escalation Messages PMV-ESK 8.1

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2016 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Overview of Escalation Messages for Gage Management	4
2	Available Escalations	5
2.1	Maintenance limit exceeded (RESWART.LIMIT_EXCEEDED).....	5
2.2	Resource has been created automatically. (RES.INSERT_AUTO).....	5
2.3	Resource status has changed (RES.STATUS_CHANGED)	5
2.4	Maintenance has been reset for resource (RES.MAINTENANCE_RESET)	6
2.5	Measure/comment has been entered for resource (RES.REGISTER_MEASURE).....	6

1 Overview of Escalation Messages for Gage Management

Purpose

HYDRA escalation management provides a framework of functions that can be used to forward events that occur or were recorded in HYDRA to individual users or user groups in real time. The function of escalation management is to take active steps to ensure users are notified.

After notification, escalation management monitors times until acknowledgment by the recipients and until escalation is concluded. Escalations can be forwarded to other users or user groups during processing.

Implementation considerations

You use escalation management if you would like to have active, real-time notification of specific events in the gage management / resource environment so that you can react early enough to start the calibration of gages / maintenance of resources.

Integration

The events/ escalations already triggered in the PMV environment are posted to central escalation management. This forms the framework used to forward the events triggered and to be able to follow up on them.

To notify people, escalation management accesses both [User administration](#) as well as the [HR master data](#) stored in the system. Notifications can be sent out as e-mails by integrating the local mail server into the system.

Features

- Provision of various escalation messages in the gage management / resource environment such as, for example, calibration / maintenance limits exceeded, calibration / maintenance reset or gage resource status changed.
- Forwarding of the detected event to the escalation framework.

2 Available Escalations

2.1 Maintenance limit exceeded (RESWART.LIMIT_EXCEEDED)

The cyclic program for maintenance monitoring triggers an escalation as soon as a maintenance limit has been exceeded.

Event	IDs	Description
RESWART.LIMIT_EXCEEDED	RESWART.RESTYP	Resource type
	RESWART.RES	Resource no.
	RESWART.BEZ	Maintenance
	RESWART.WARTKL	Class
	RESWART.WART:N	Value of next maintenance
	RESWART.WART:I	Actual value
	RESWART.WARTNR	Achieved threshold: 1, 2, 3
	RESWART.ART	Maintenance type

2.2 Resource has been created automatically. (RES.INSERT_AUTO)

This event is triggered if a component is assigned as production resource and tool to an operation, this component does not yet exist in HYDRA-WRM and the "automatic creation" option is enabled for the resource type in HYDRA-WRM.

Event	IDs	Description
RES.INSERT_AUTO	RES.TYP	Resource type
	RES.RES	Resource no.

2.3 Resource status has changed (RES.STATUS_CHANGED)

This event is triggered every time the status of a resource changes.

Event	IDs	Description
RES.STATUS_CHANGED	RES.RESTYP	Resource type
	RES.RES	Resource no.
	RES.RESSTA	Resource status

2.4 Maintenance has been reset for resource (RES.MAINTENANCE_RESET)

This event is triggered every time a resource maintenance is reset.

Event	IDs	Description
RES.MAINTENANCE_RESET	RES.TYP	Resource type
	RES.RES	Resource no.
	RES.BEM	Comment
	RESWART.VERWEIS	Maintenance number

Please note

This escalation supports the additional placeholders MSGPRIO, MSGCLASS and MSGRCV. These placeholders are described in the basic documentation dealing with escalations.

2.5 Measure/comment has been entered for resource (RES.REGISTER_MEASURE)

This event is triggered every time a measure/comment is entered for a resource.

Event	IDs	Description
RES.REGISTER_MEASURE	RES.TYP	Resource type
	RES.RES	Resource no.
	RES.BEM	Comment
	RES.MASSNR	Number of the measure

Please note

This escalation supports the additional placeholders MSGPRIO, MSGCLASS and MSGRCV. These placeholders are described in the basic documentation dealing with escalations.