

# 1 Single Batch Entry at AIP

## Usage

When entering single batches at the terminal, another batch can be entered in addition to the operation, which, depending on the production situation, can be defined as either an input or an output batch.

## Integration

The data is entered as part of the shop floor data collection (BDE) process. The BDE type H log records resulting from the data entry that represent the individual batch postings in chronological order can be displayed or edited in the application "[Order-related postings](#)".

## Prerequisite

The following configurations are mandatory:

### HYDRA basic settings

By checking the "create unknown batches" option in the "MPL" tab of the HYDRA basic parameter settings, a batch can be created automatically, once the batch number has been entered at the terminal. In case the function for automatic batch generation is disabled, the batches need to be created manually in HYDRA. As HYDRA checks whether or not the batch is available when logging batches on to the shop floor terminal. Upon consultation with MPDV, the function for manual batch generation can be enabled by interface or client application (not included in this license).

### [Terminal assignment](#)

Batch recording may only be enabled for machines that are assigned to terminals of the operation mode BDE and/or MDE.

### [Workplace/ resource configuration](#)

Index tab "Workplace configuration" → category "MPL" → option "Batch management" → Selection "Individual batch tracing (CHV)".



Operations not requiring management in batches can also be logged on to machines using batch management. In that case, the batch number does not have to be input. Please note that this is only possible in so-called workflow posting dialogs.

### [Operation data](#)

To be entered, the operation must be identified as requiring batch management.

The flag "Batch management requirement" can be preset by the ERP system (e.g. [interface](#): HY72PPS [Segment](#): HY72\_AG\_HD\_001 (operation) [field](#): OPT:CNR), or else set manually using the [Editing function](#) in MOC (presumes proper licensing/authorization).



Attempting to log on an operation requiring batch management at a workplace when batch management is not active is refused with an error.

## Logging on an operation requiring batch management

The operation is selected under the index tab "Select operation". The status of the workplace/ machine can be modified in the next index tab "Select status". This index tab is available only at "single user workplaces".

The batch number and the staff badge number are entered under the index tab "Batch entry/ confirmation". For this purpose, an alphanumeric batch number with a maximum of 20 digits must be entered. It may be entered either manually or by barcode.

## Changing batches at the terminal

While the operation requiring batch processing is logged on, you can switch to a new batch by using the "Change of batches" function key. The production data (quantities produced and duration) are posted to the operation and the current batch simultaneously.

The new number can be entered manually from the keyboard or by barcode. As is the case when logging on an operation, the person implementing the change of batches must possess the BDE authorization to post the operation.

## Please note

The batch currently logged on can be displayed in the OP info, provided that during customizing it was integrated into the dialog accordingly. Please note that this field can only be displayed either system-wide or specifically for a terminal group. It is not possible to show/ hide the field based on a dialog control defined at the workplace or in the entry field.



Scrap quantities collected by the dialog "partial upload" (A\_TR) are posted onto the order, but not to the batch. Consequently, these quantities are not included in the generated type "H" log record.