

1 AIP2 - Local Configuration File keyboard.ini

You configure the virtual keyboard of the AIP2 terminal in the keyboard.ini file in the directory c:\mpdv\aip2 for the specific terminal.



To activate the changes in the configuration file, you must restart the terminal software.

Logic enabling the virtual keyboard:

The AIP2 terminal shows the keyboard if an input field is focused. The keyboard is placed with reference to the field as described below:

Logic for placing the virtual keyboard:

It is tried to place the keyboard directly below the input field. If there is not enough space to the bottom of the screen, it is tried to place the keyboard directly above the input field. If the space above the control element is not sufficient for the keyboard, the keyboard is placed at the bottom of the screen.

These are the priorities for horizontal alignment:

- to the right of the control
- to the left of the control
- to the edge of the screen that is further away from the control

If the "VirtScreenSize" option is enabled, the virtual keyboard is not aligned on the virtual screen but still on the real screen. Consequently, the keyboard may also reach beyond the terminal program.

The virtual keyboard can be configured in the local keyboard.ini file on the terminal. Example:

```
[Keyboard]
HideTime=10
ScaleMultiplier=0.9
FixNumbers=ON
Configuration=ON
;Logging=ALL
;Processes=ctaip.exe
;ClassesForLetters=TVtEdit
;ClassesForNumbers=TMPDVSimpleNumericField
```

HideTime

The set value specifies for how many seconds the keyboard is invisible if you click on the key showing the icon  on the left hand side. This key is not visible if the value "0" is entered.

ScaleMultiplier

The keyboard size can be reduced and increased. The value range is between 0.9 and 4.0. A dot is used as decimal separator.

The default value is 1.0.

FixNumbers

Allowed values: ON|OFF

If FixNumbers=On is set, the number keys located in the top row of the virtual keyboard remain visible even if the Shift key or CapsLock key is pressed. ON is set by default.

Configuration

Allowed values: ON|OFF

The keyboard layout, which is installed and activated in the Windows language settings, specifies the layout of the virtual keyboard. You can activate different keyboards in the operating system. For the virtual keyboard, you can then switch between the different activated keyboards.

The entry *Configuration=ON* activates the button . Use this button to open the dialog to select one of the keyboards activated in the operating system.

Default is OFF.

Logging

Allowed values: OFF|ON|ALL

Logging can be enabled using this entry. The advanced logging is configured by setting ALL.

OFF is set by default.

Processes

The entry "Processes" specifies for which additional processes the virtual keyboard will be used. The separate entries are separated by comma (e.g. processes=notepad.exe.explorer.exe). If this entry is not included, the keyboard for these processes is available in *ctaip.exe* und *iniedit.exe*.

ClassesForLetters

This entry defines for which additional classes the alpha-numeric keyboard should be displayed. The current classes for AIP2 (TMPDVSimpleField, TsEdit, TsMemo, TMPDVTypEdit, TMPDVSimpleEditField, TMPDVPictureField, TEdit, TButtonEdit, TEditControl) are fixed in the source code. This entry can be used to extend the list.

ClassesForNumbers

This entry defines for which additional classes the numeric keyboard should be displayed. The current classes applicable for the AIP2 (TMPDVNumericField, TPagerNumField, TMPDVSimpleNumericField, TVTEdit) are fixed in the source code. This entry can be used to extend the list.



The classes that are fixed in the source code cannot be overridden using a different entry in the configuration file. If you want to display the other keyboard for a field, you can change the input type of the field in [Dialog Configuration](#).

Dialog-specific configuration

There is the option from version 1.6.0.0 of the keyboard.exe to configure the location of the virtual keyboard per dynamic dialog. The user has to extend the configuration file keyboard.ini accordingly.

Sample configuration:

```
[WF_AA_QUA]      => Name of the dynamic dialogs
X-Position=50     => Distance in pixels from the left edge of the screen
Y-Position=50     => Distance in pixels from the top edge of the screen
```



- Specifying the X- and Y-position is mandatory.
- The configuration is only available for dynamic dialogs that are configured on the MOC.

The virtual keyboard can also be switched off if the terminal is connected to a real keyboard. This can be configured in section [SYSTEM] of the [local](#) ctaip.ini file.

Example:

```
[SYSTEM]
Parameters=-t
```

Syntax:

+t/-t --> enables/disables the virtual keyboard; irrespective of the terminal type