

1 Order Postings for Operations subject to Batch Management

Overview

In addition to logging the actual operation on, operations subject to batch management also enable to log on relevant input batches.

Configuration

These system settings must be carried out to generally use operations that are subject to batch management.

Basic screen

Basic terminal screen when a machine is assigned in batch mode:

The screenshot displays the AIP terminal interface. On the left, a list of machines is shown with their status and counts. The main area is divided into sections: 'Workplace/machine' details, 'Operations' details, and 'Staff logged on'.

Workplace/machine			
Workplace/machine	Short name	Group	Status
33021	WPL02	FINISH	PRODUCTION
Cycles	Start	Duration [hrs:min]	
0	18.08.2015	06:00 2338:22	
Target cycle	Actual cycle	Yield	Scrap
20,000	0,000	833	4

Operations	
MES order number	S30002090200
Article	SAR-VPO011-M-9005
Quantities (target/yield/scrap)	1200 / 660 / 0

Staff logged on		
Person	Person	Person
10002630	85741	40563
Name	Name	Name
White, Susan	Meyers, Joseph	Green, Mary

At the bottom left, there is a 'PZE' button and an American flag icon. The bottom right corner shows the date and time: 23.11.15 16:22:40.

The basic display shows the third list "Input materials currently logged on" for machines for which the "batch management" option is configured. All active input batches of the selected machine are displayed in this list.

OP logon with input batches

A workflow including two tabs is opened by clicking the button highlighted with the red frame for logging on operations. The operation to be logged on is selected in the first tab "select operation".

The "log on operation" tab is reached by clicking "Next" where in addition to the selected OP, the defined material components are displayed in a list.

By entering a batch number in the "input batch" field and clicking the "report batch" function a batch may be logged on as input material for a component. During the entry process, the terminal checks whether or not the batch number is known to the system and may be logged on. This is also described in detail in the document dealing with the [Input batch change](#).

"Batch" field

When an OP is logged on, a batch number is created simultaneously for the next output batch to be produced. The batch number may be assigned automatically or manually (please also see the settings of "workplace configuration"). The generated batch is created with the batch number in the system and set to the "running" status.

Provided that all required input materials are logged on, the OP may be started via the "OK" button in the "OP logon" dialog. Whether input material has to be logged on or not, can be defined in the assigned material type of the component.

Once the OP has been logged on successfully, all active input batches of the selected machine are displayed in the material list.

If batches are logged on along with the OP and the user cancels the process or cannot log on the OP due to validation checking, the input batches will be logged off automatically for this OP. In this case, batches are always logged off without indicating the consumption quantity. By way of the following warning message, the user may confirm the logoff process:

The function logging off input batches automatically can be activated/deactivated by an option in the hyaipcfg.ini file:

HYAIPCFG.INI

```
[MPL-Options 0/2xxx]
ForceAutoLogOffInputBatches=0
```

Logon of unplanned input material

In addition to planned materials, it is also possible to log on "unplanned" material for an OP, using an additional feature for the OP. If the "replaceable" option is set to "J", the user is able to assign the respective component manually, when batches are logged on. However, the logon is only allowed if the material type of the input batch matches that of the component.

In the selection list the components are filtered by the material number and displayed as follows for selection:

Logon of unknown batches

An input batch, which is not yet known to the system, may be logged on for an OP using the "create unknown batches" option in the basic parameter settings.

In this case, when input batches are logged on, the system searches for a valid assignment of input material to the material type of the selected component. Provided that a matching assignment is found and the "allow entry of unknown input batches" option is configured for the material type in the "input batch processing" tab, the batch is generated by logging it on to the system. Then it is set to the "running" status. The batch is initially created in a quantity of 1.000.000.000.

Logoff/interruption of OPs

A running OP may be interrupted or logged off by clicking the "logoff/interrupt OP" button. Then a dialog opens, where the following selection can be made:

If "log off OP" is clicked the logoff dialog opens that contains the same input fields like the [Output batch change](#) dialog.

Thus, the output batch that is currently active is completed, when OPs are interrupted or logged off.