

1 Entry of Batch Attributes

Summary

In case batch attributes are defined to be recorded at the AIP terminal for the material type of the running OP, another input dialog is opened, when the output batch is changed. The dialog opens additionally after clicking "OK" in the output batch change function, interrupt OP and finish OP function.

Using batch attributes, numeric and alphanumeric values may be recorded which are then saved for the produced output batch in an additional table.

Configuration

By configuration it is possible to record any number of additionally required batch attributes for the material type.

Dialog

Example when two additional batch attributes are collected for an output batch:

Length (CM) :	0.00	✓ OK
Width (CM) :	0.00	✗ Cancel
Type () :		