

1 Local Configuration File caq72.ini

You can change specific CAQ settings in the file "caq72.ini" stored in the directory

AIP 8.1

c:\ctaip\packets

AIP 8.2

c:\mpdv\aip2\packets



To enable the changes in the caq72.ini configuration file, you must restart the terminal software.

Entry	Comment
[QUEUE_MODE_QM] section	
REFRESH_AT_RETURN=[YES,NO,ASK]	When you exit queue mode, you can select automatically =YES not at all =NO upon request =ASK for the refreshing of CAQ data Default → REFRESH_AT_RETURN=YES
REFRESH_QUERY=[ASK]	Message text for the query with REFRESH_QUERY=ASK
Section [LanguageSwitch]	
SkipDataReCalc=[ON,OFF]	To avoid long waiting times, you can suppress the changing of languages for the QM sector. You can enable this option at runtime; a restart is not necessary. Default → SkipDataReCalc=OFF

Entry	Comment
MODE=[1,2]	Use this parameter to define the mode for changing the language. MODE=1: Only the MDBI fields of the lists are translated. With this mode, the data that is already loaded in the CAQ is not translated. Different languages can therefore be shown. For example the characteristic designation/name MODE=2: The complete CAQ data structure is reloaded. NOTE! With this mode, it is possible that the data displayed is not identical to the actual data. This difference is possible when the terminal is offline, for example. Default → MODE=1 As of caq72.dll version 8.2.0.12. Only AIP 8.2!
[OPTIONS] section	
MNR_REFRESH_NEW_METHOD=[ON,OFF]	The <i>inspection status</i> and <i>inspection time of the machine list</i> are immediately updated on the <i>main view</i> of the AIP terminal when an OP including CAQ inspection order is logged off or interrupted. Requirement: The OP is logged off or interrupted directly on the terminal (not on the MOC). Default → MNR_REFRESH_NEW_METHOD=ON As of caq72.dll version 2.0.2.24 The terminal must be restarted.
Section [DATACONTEXT_LAB]	ONLY possible with tile view! As of version 8.2.0.7

Entry	Comment
DATAPROVIDER_ID	ID of the data provider according to .\gui\globaldefines.xml Default → DATAPROVIDER_ID= PPKTMNR
LOADCYCLE	List update cycle Default → LOADCYCLE=XXX
LIST	List that is requested Default → LIST=u_I_caq_inspoint_tnr
Section[DATACONTEXT_GOODS_RECEIPT]	ONLY possible with tile view! As of version 8.2.0.7
DATAPROVIDER_ID	ID of the data provider according to .\gui\globaldefines.xml Default → DATAPROVIDER_ID= PAUMNR
LOADCYCLE	List update cycle Default → LOADCYCLE=XXX
LIST	List that is requested Default → LIST=u_I_caq_inspstep_tnr
Section[DATACONTEXT_CALIBRATION]	ONLY possible with tile view! As of version 8.2.0.7
DATAPROVIDER_ID	ID of the data provider according to .\gui\globaldefines.xml Default → DATAPROVIDER_ID= PAUMNR
LOADCYCLE	List update cycle Default → LOADCYCLE=XXX
LIST	List that is requested Default → LIST= u_I_caq_inspstep_tnr