

1 Sequencing List - Transport Orders

Overview

License	MPL-TRA
---------	---------

Usage

The functionality described below enables transport orders to be displayed and recorded at the shop floor terminal AIP.

Prerequisite

In order to use this function, the relevant configuration is required.

Function at Terminal

The function is triggered manually by means of a separate button.

The sequencing list shows pending transport orders for a machine. Transport orders can be reserved and logged in from the screen.

List of transport orders

<TRANRLIST>

Machine

TRANR-01

Material buffer

HR-LAGER

Staff badge number

0002

☐ Filter
☒ Prepared ☒ Reserved ☐ Transport

Machine	OP	Article	Auftragstatu	Target qty.	Start date	Transport
TRANR-01	TR0000000300000100	4711	L	1,000	12/13/2012 14:00	R
TRANR-01	TR0000000800000100	4711-1	V	1,000	00:00	L
TRANR-01	TR00000008100000100	4711-1	V	1,000	00:00	L
TRANR-01	TR00000008400000100	5555	I	99,000	00:00	L
TRANR-01	TR00000008800000100	4711	V	2,000	00:00	L
TRANR-01	TR00000009400000100		V	1,000	00:00	C
TRANR-01	TR00000009700000100	4711	I	4,000	00:00	L
TRANR-01	TR00000009800000100	4711	L	4,000	12/13/2012 14:00	L
TRANR-01	TR00000010000000100	4711	V	4,000	00:00	L
TRANR-01	TR00000010100000100	4711	V	1,000	00:00	R
TRANR-01	TR00000010200000100	1	V	1,000	00:00	R
TRANR-01	TR00000010300000100	4711	I	4,000	00:00	L
TRANR-01	TR00000010400000100	4711	L	4,000	12/14/2012 15:05	L
TRANR-01	TR00000010500000100	4711	I	4,000	00:00	L

Page 1

• Page 2

Operation

TR00000008400000100

ESC ESC

Reserve

Start transport (pick up)

Finish transport (drop)

Reload

Fig.: List of transport orders

The following posting functions are available:

- Reserve transport order
- Log on transport order (TRANSR_AN dialog)
- Terminate transport order (TRANSR_AB dialog)



The list will only show orders which are configured for display in the terminal sequencing list. If the terminal is offline, the posting function is available to a limited extent on the basis of the available data in the sequencing list. In the offline case, errors are not indicated if a posting fails at the server.

Display fields:

Machine

Assigned machine from basic screen.

Material buffer

By entering a material buffer, the sequencing list display can be filtered according to the source material buffer.

Filter

The sequencing list display can be filtered by applying the 3 status filters "reserved, logged on, terminated" and the material buffer.

Operation number

Enables manual entry of a transport operation. The operation must always be available in the sequencing list at the terminal.

Grid list contents "Order pool transport management":

All transport operations scheduled for this machine group of the transport are shown in the order pool.

Description of the main items:

OP status (AST)

I = Transport operation is in "Initial" status

V = Transport operation was reserved on machine for pending transport

L = Transport operation was started

E = Transport is completed

Operation (ANR)

Transport operation number

Article number (ATK)

Material number for transport order Is empty if resources are transported.

Target quantity (SGR:GUTP)

Stored target quantity for the transport. Is identical with the batch quantity in the case of batch-related transport. The value for resources is always 1.

Batch (AGR_TRANR_CNR)

For a batch-related transport order, this shows the batch number to be transported.

Resource (AGR_TRANR_RES)

For a resource transport, this shows the resource number to be transported.

Source buffer (AGR_TRANR_SMP)

Material buffer from where the transport is to be started.

Target buffer (AGR_TRANR_TMP)

Material buffer to which the object is to be transported.

Transport type (AGR_TRANR_ART)

L = Batch-related transport order

R = Transport order for resource

A = Article-related transport entered in HLS through planning

Reserve transport order

The Reserve transport order function can be used by the operator to adopt a transport order. This means that

- the transport operation is planned on the machine
- the status of the transport order changes from Initial (I) to Prepared (V)
- The object to be transported (batch or resource) changes to the "Provided for transport" status.

After activating the function button, the following confirmation dialog is displayed:



Fig.: Confirmation for reservation

The following items are verified upon reservation:

- The transport order must have the 'Initial' (I) status.

Result:

- Upon successful reservation, the status changes to Prepared (V) and the display is updated.