

1 Start Transport Order

Overview

License	MPL-TRA
---------	---------

Usage

The functionality described below enables the operation of a transport order to be started.

Prerequisite

The data base patch ***dbp_mpl_transportation.hsc*** must have been run.



The OP status Prepared (V) must be configured in the status assignment for the order type. It must be possible to record and manually change the status V.

Features

Input parameters:

- Transport order operation number (TRANR.ANR)
- Machine number on which the transport operation is to be logged on (TRANR.MNR)
- Resource number for a resource transport (TRANR.RES and TRANR.RESTYP)
- Batch number for article-related transport (TRANR.CNR)
- Source material buffer (TRANR.SMP)
- Target material buffer (TRANR.TMP)

The BAPI call TRANR.START performs the following checks:

- The transport order must be in the Prepared (V) status.
- For an article-related transport order (transport type=A), a free batch with a remaining quantity >= transport quantity must be provided.
- For a resource or batch transport, the object must be in the source material buffer of the transport order.
- As an option, the staff badge number is checked if it is transmitted (KNR).

Result of BAPI call TRANR.START:

- The transport operation is logged on the machine as Running (command A_AN)
- The operation status of the transport operation changes from Prepared (V) to Running (L)

- For an article-related transport order (transport type = A) which was created from planning, the batch entered for transport is assigned to the transport order here. If the batch has a remaining quantity > target quantity of the transport order, a partial quantity of this batch with a new batch number is split off and assigned to the transport order.
- The object to be transported changes to the status
 - Batch:** Batch status = T (Transport)
Effect: As long as the batch is in the transport status, it cannot be logged on as input batch.
 - Resource:** Resource status = <dependent on object configuration for resource type>
- Entry in history:
 - Batch:** Batch change in batch history
 - Resource:** Event RES_STATUS in WRM history

Configuration

The following entry is used to determine the status to be set as the transport status of a resource (transport type=R) for each resource type:

Object type=**MPL**
Object ID 1=**RESTYP**
Object ID 2=<Resource type of resource>
Parameter=**TRSTA**
Parameter value=<Resource status>