

1 Batch Tracing

Summary

Menu	Material management → Batch tracing → Batch tracing
Transaction code	battr
Function authorization	battr

Usage

This evaluation is to be used to determine, with regard to the output batches, which input batches have entered and with regard to input batches, which output batches they have entered into. The direct predecessors (batch origin) and the direct successors (batch consumption) are shown.

The batch quantity for which batch tracing is to be performed can be specified by the exclusive entry of the machine number, order number, material number or batch number. Here only those batches are considered that were generated in the specified period.

Selection criteria

The following selection criteria are available in the application:

Batch

Direct input/ output batches:

When the identifier "Direct input/output batches" is selected, the input batches that entered directly and/or the output batches that were produced directly from the input are displayed.

Origin:

When the identifier "Origin" is selected, the overall batch origin is determined. In this way, the batch origin displays all of the batches that entered and all of the output batches for the selected batch.

Consumption:

When the identifier "Consumption" is selected, all of the output batches for the selected batch are displayed for which this batch was consumed.

In addition, a limitation can be made reflecting a specific batch number.

Point in time

All produced input and output batches in the selected period are displayed.

Workplace

All produced input and output batches for the selected workplace are displayed.

Item

All produced input and output batches for the selected item are displayed.

If several selection criteria are used overlapping results are displayed in the workplace overview.

Notes:

- If the batch number is displayed with zeroes (e.g. 0000000000), there is no input batch for the batch origin.
- When the selections workplace and item are made, only batch relationships with existing input batches are shown.

Field descriptions

In the input/output batch detail application, all batches are displayed according to the selections entered.

The selected columns are described in the following:

Input batch

Input batch number

Output batch

Output batch number

Workplace

Workplace at which the batch was generated

Material type

[Material type](#) of the batch

Material

Material number of the batch

Name

Plain text of the material

Production date/ Logon or logoff date

Production date and time for output batches

Logon or logoff date and time for input batches

Serial number

Assigned serial numbers for this batch. The ADE-SNR functionality can be used to establish a connection between a batch and a serial number.

Toolbar**Graphic batch tracing**

Starts the application [graphic batch tracing](#).