

1 Groups

Overview

HYDRA menu	Master data → Workplace / Maschinen → Groups
FEDRA menu	Detailed scheduling → Master data → Groups
Transaction code	grp
Function authorization	mdgrp

Purpose

You use this application to specify groups:

For planning in the shop floor scheduling module, a dependency between workplaces/machines and capacity groups is defined. The following data can be assigned to a capacity group, which can be overwritten if defined with an individual capacity (workplaces/machine).

Group data is used as long as requirements are only defined with respect to the group.

The transport time is a planned buffer for material that is transported between two operations. A transport matrix can be stored in the system to determine the transport time. When a new order or operation is created, the transport time is calculated using this matrix and then transferred to the operation. You use location groups to identify the transport time between locations. You define a group for each location and identify it as a location group.

You also define *Report groups* for evaluation purposes. They can be defined globally or for a specific user.

Selection criteria

The application provides the following selection criteria:

group

Group name

Company

Stored company

Capacity group

Restricts the capacity groups

Report group

Restricts evaluation/report groups

Location group

Restricts location groups

Line group

Restricts line group (subject to the license)

Field descriptions

group

Identifies the group



Only alphabetic characters, also used to identify workplaces/machines (no umlauts, no special characters), are allowed for capacity groups and location groups.

The identifier for the capacity groups can not exceed eight digits.

Location group can only have a maximum of four digits.

Groups must be unique.

Name

Name or description of the group

Sing. type

If this identifier is set, resources of the same type can only be assigned to a group.

Please note that once a group has been created, the identifier cannot be changed anymore.

Company

Company (comment)

Cost center

Cost center of the group. If the cost center of the group is defined, you can also select by cost center in the order overview.

You can find further information on the cost centers in [Notes on editing groups and group assignments](#).

Responsibility area

Responsibility area to change the group definition

Capacity group

A capacity group summarizes primary capacities, namely machines or workplaces. A requirement can be specified in the operation for a capacity group. In capacity planning, orders or their operations are scheduled on primary capacities.

A capacity group must be of *sing. type*. That means only machines/workplaces can be assigned in the system, which have been created as a resource with resource type MNR. Master data → Workplace/machines → Workplace configuration. (Only applicable if HYDRA is used.)

Please note that once a capacity group has been created, the identifier/flag cannot be changed anymore.

You can only plan operations for a machine group if the machine group is a capacity group.

You can find notes on how to edit capacity groups or group assignment in

Location group

You can specify transition times for location groups in the *Transport matrix*. These times are used as transport time, when operations are created.

Please note that once a location group has been created, the identifier/flag cannot be changed anymore.

You can find notes on how to edit capacity groups or group assignment at: [Notes on editing groups and group assignments](#).

Year model

A year model of the group is used for scheduling.

Performance level

This value is used by the shop floor scheduling module, when the remaining run time (remaining processing time) is calculated. A performance level < 100% increases the remaining runtime (= remaining processing time); a performance level > 100% reduces it.

Production variants

Production variants can be defined in the system for planning in the shop floor scheduling for specific orders. In case production variants are not used in all areas, this configuration relating to groups can *overwrite* the utilization of production variants. Consequently, the group configuration takes priority over the order type configuration.

However, if the setting *N - Not used* was made for the order type, then no production variants are used for this order type. The group configuration does not have any effect in this case.

Refer to the application manual for further information on configuring the query for production variants.

Including shortage capacity

Individual capacities assigned to this capacity group are shortage capacities. Attention is given to potential competition when performing detailed planning for such capacities.

Consideration during dispatching: Continuous capacity

Individual capacities assigned to this capacity group are relevant merely for scheduling. The planning takes place here without consideration of clashes.

During simulation: Shortage capacity

Reserved; currently not used.

→During simulation: Continuous capacity

Reserved; currently not used.

→Report group

You can define *Report groups* for evaluation purposes. *Report groups* are groups of machines or workplaces that can be independent of the capacity groups, e.g. expensive machines, slow machines.



Once an evaluation group has been created, the indicator cannot be changed.

For further information on editing evaluation groups or group assignments, refer to the following section:

[Notes on editing groups and group assignments.](#)

User

A user can be entered in the User field if the evaluation group should only be displayed to this user.. You can only enter this field when you prepare an evaluation group. You cannot edit this field in editing dialog (read only!).

**Notes on editing groups and group assignments*****To automatically create capacity groups***

When creating a workplace or a machine, a group is automatically created as a *Capacity group* if no group exists yet.

For this new group, certain settings (for example, shift model, performance level) of the workplace just created are transferred. If the group exists, the group setting are not changed by creating a new workplace or change the workplace data.

Then the created workplace is automatically assigned to this capacity group.

If the group is modified at a work center the group assignment to the capacity group will be modified as well.

If a work center is deleted the assignment to previous groups will also be deleted automatically. Provided that a group assignment does no longer exist, the group is not deleted automatically.

The cost center of the workplace is not transferred to the group as it could be the case that workplaces with different cost centers are assigned to a capacity group. If, on the other hand, a cost center is entered in the group configuration, a plausibility check is performed when a new group is created or an existing machine/workplace configuration is changed. This ensures that the cost center of the workplace matches the cost center of the group. If this is not the case, the user is notified with the error message: "The cost center of the machine must be the same as the cost center of the group". This check is not performed, when the group is changed.

Assignment of workplace to capacity groups

If you add a new workplace [Workplace and resource configuration](#), this workplace is automatically assigned to a capacity group. This capacity group has the same name as the group specified in the workplace/resource configuration.

If the group is changed for a workplace/resource configuration, the assignment to the previous capacity group is deleted and assigned to the new capacity group. If the capacity group does not exist, the system automatically creates a capacity group and assigns the workplace.

Please note that a workplace or machine can only be assigned to one capacity group. Workplaces/machines that are not assigned to a capacity group are not included in the planning.

Assignment of workplaces for location groups

Please note that a workplace or machine can only be assigned to one capacity group.

Assignment of workplaces for evaluation groups

It is allowed to assign a workplace or a machine to several evaluation groups.