

1 Resource Status Texts

Overview

Menu	Master data → Resources → Resource status texts
Transaction code	rstat
Function authorization	mdrstat.*

The texts define the status values of parallel resource statuses.

Purpose

You must define the status texts for the status values. The status values refer to the available parallel resource status types. The status values can be specified for each resource type and optionally for resource families

Integration

You can define parallel status types in addition to and independent of the default BDE machine status. The application "Resource status types" defines the possible status types.

Requirements

The license for the use of parallel statuses is required.

Selection criteria

The application provides the following selection criteria:

Resource type, Resource family

These fields identify the resource type and the resource family.

Status type

Selection of the available status types

Status text number

You can filter the list by the status entered here.

Field descriptions

Resource type, Resource family

These fields identify the resource type and the resource family.

Status type

Status type of the resource types and resource families

Status text number, Status text

Number of the status text and the text of this number

Color

Definition of the status color that is used to color a status in specific reports.

Responsibility area

Responsibility area of the user who can view and use the status value.

Modified on

Date and user of last modification.