

1 Activating Material Monitoring

Usage

You activate the material monitoring job if you would like the system to automatically implement the status of known batches in the system based on durations defined in the system.

Requirements

You defined the process time defaults for minimum storage time, warning time and/or expiry time in [material type](#) or in [assignment of material to material type](#).

Procedure

Make an entry in the Scheduler for the cyclic call of the monitoring job and define the call interval, if it is different.

Parameter name	Value
For uploading material receipts:	
Product key	MPL-MMO
License key	MPL-MMO
Command (Windows):	sh.exe ./mpl_lsta.scr
Command (Unix):	./mpl_lsta.scr
Comment:	MPL - Status monitoring
Interval	5



The job is run every five minutes in the system standard delivery. If this interval is sufficient for you, no further adjustments are required.

Results

The system runs the job cyclically at the defined interval.

