

1 DMC-MDE: Configuration in HYDRA

Workplace configuration

Configure the machine in the [Workplace configuration](#) → MDE configuration with the following data to integrate the machine in HYDRA DMC:

Parameter name	Value
Monitoring type	Cyclic monitoring Monitoring via operating signal No monitoring
Min. cycle/disturbance time	Min. cycle/disturbance time (cycles monitoring enabled)
Cycle extension	Cycle extension (cycles monitoring enabled)

Counter configuration

Maintain the counters in use per machine in the [Counter configuration](#) with the following data to integrate the counters in HYDRA DMC:

Parameter name	Value
Counter input	Number/Input of the counter
Identifier "Cycles monitoring"	If this identifier is set for a channel, incoming counter pulses are considered during cycle monitoring. Only the first counter configured with the identifier "For monitoring" is used to calculate the actual cycle. Also set this counter if monitoring via operating signal is enabled and an actual cycle is to be calculated at the same time.
Posting as cycles	Yes or No

Parameter name	Value
Posting as	Yield Scrap quantity Rework quantity Open quantity

Machine status configuration

Maintain the machine statuses in use in the [Status assignment of machines/workplaces](#) with the following data to integrate the machine statuses in HYDRA DMC:

Parameter name	Value
Production identifier	Create statuses with the following production identifiers: P Production S Other status
Identifier "Activate production lock"	Set the identifier, if you want to set a production lock with this status.
Identifier "Set machine lock output"	Set the identifier, if you want to set the output with this status.
Identifier "Automatically via digital input" and "Digital input"	Set the identifier, if you want to record the status via a digital input, and assign the digital input used to this end.