

1 Configuration of Throughput Batch Processing

Activation at the machine

Enable the throughput batch processing in [machine master data](#) → workplace configuration → MPL:

Parameter name	Value
Batch management	D

Activation at the material type

Enable the below-mentioned processing for the [material type](#) of the incoming batch:

Parameter name	Value
Hand batch number down	Active
Input batch only valid for exactly 1 output batch	Active

Activation at the operation

Define the [material type](#) enabled for throughput batch processing as the material type for the operation.

Parameter name	Value
Material type	<material type enabled for throughput batch processing>

Set the "batch management requirement" flag for the [operation](#) → processing:

Parameter name	Value
Batch management requirement	Active

Activation at the operation's component

Define the material type enabled for throughput batch processing at a [component](#).

Parameter name	Value
Material type	<material type enabled for throughput batch processing>