

SIPLACE Connector – Station Switching -

Subjects/Contents

1	Objectives.....	2
2	Workplace/machine configuration in HYDRA (MOC).....	2
2.1	Workplace/machine	2
2.1.1	Configuration	2
2.1.2	Machine status	2
3	Configuration Siplace Connector	3
3.1	Exchange of station ID.....	3
4	Restarting the SiplaceConnector.....	5

1 Objectives

This documents describes which modifications to the configuration are required if individual stations are exchanged within a Siplace line.



Please note: This document only deals with the necessary modifications to HYDRA and the configuration within the HYDRA-SiplaceConnector. Configurations that might be required within the SiplaceSoftware are not taken into account and not part of this document.

2 Workplace/machine configuration in HYDRA (MOC)

2.1 Workplace/machine

2.1.1 Configuration

Menu	Master data → Workplaces/ Machines → Workplace configuration
Transaction code	res

Changes to the machine/workplace configuration are not required.

2.1.2 Machine status

Menu	Master data → Workplaces/ machines → Status assignment
Transaction code	mst

Changes to the status assignments of machines/workplaces are not necessary.

3 Configuration Siplace Connector

3.1 Exchange of station ID

The SiplaceConnector configuration has to be modified if one or several stations are exchanged within a Siplace line.

The list of stations is to be updated in the configuration file **config.xml** (within the directory of the SiplaceConnector) for every line (corresponds to a machine/workplace in HYDRA) in which one or several stations have been switched/changed/removed.

Basis:

One line (Line_1) consisting of four stations (L1_ST1, L1_ST2, L1_ST3, L1_ST4).



Please note: The names refer to the designations of the line and stations within the Siplace software (SiplaceLineControl)

Excerpt from the configuration file config.xml:

```
<ComponentConfiguration Name="LineStateMerger1"
Class="mpdv.MachineDataCollector.Core.Components.LineStateMerger">

  <Parameter Name="StatePriority" Value="30000,5,4,6,7,3,2,1" />

  <Parameter Name="LineName" Value="Linie_1" />

  <Parameter Name="StationList" Value="L1_ST1,L1_ST2,L1_ST3,L1_ST4" />

  <Parameter Name="SuppressUnknownStations" Value="true" />

</ComponentConfiguration>
```

Field descriptions

Element	Value	Comment
<code><ComponentConfiguration Name="LineStateMerger1" Class="mpdv.MachineDataCollector.C ore.Components.LineStateMerger"></code>	LineStateMerger1	Configuration of the line recorded by the SiplaceConnector. The "name" entry must be unique and numbered consecutively. Moreover, the number of lines must match the specification "NumberofLines" within the configuration file.
<code><Parameter Name="StatePriority" Value="30000,5,4,6,7,3,2,1" /></code>	30000,5,4,6,7,3,2,1	Weighting/mapping of machine statuses
<code><Parameter Name="LineName" Value="Linie_1" /></code>	Linie_1	Name of the line within the Siplace LineControl
<code><Parameter Name="StationList" Value="L1_ST1,L1_ST2,L1_ST3,L1_S T4" /></code>	L1_ST1,L1_ST2, L1_ST3,L1_ST4	Names (from LineControl) of the single stations within the line.
<code><Parameter Name="SuppressUnknownStations" Value="true" /></code>		Messages from stations that are not included in the "StationList" are ignored.
<code></ComponentConfiguration></code>		End of the line configuration

If one or several stations are exchanged within the line, the parameter entry

```
<Parameter Name="StationList" Value="L1_ST1,L1_ST2,L1_ST3,L1_ST4" />
```

has to be changed accordingly.

Example: Station **L1_ST3** is replaced by station **L1_ST8**. Then the entry is to be changed as follows.

Old:

```
<Parameter Name="StationList" Value="L1_ST1,L1_ST2,L1_ST3,L1_ST4" />
```

New:

```
<Parameter Name="StationList" Value="L1_ST1,L1_ST2,L1_ST8,L1_ST4" />
```

4 Restarting the SiplaceConnector

The SiplaceConnector is to be restarted, once the configuration file has been changed and saved.