

1 Configuration AIP QM Cavity Entry

Basic Configuration

In the case of subsequent installation of AIP QM cavity entry on an existing HYDRA 8 system, please follow the steps below:

1. Save the existing dialog configuration:
 - a. UNIX systems (to be performed on server prompt in HYDRA directory): *hydlgcfg.out*
DLGCFG.TYP=% DLGCFG.DLGUSR=% DLGCFG.DLG=% DATEI=dialog.dlg
 - b. Windows systems (to be performed in a DOS window in HYDRA directory): *hydlgcfg.exe*
DLGCFG.TYP=% DLGCFG.DLGUSR=% DLGCFG.DLG=% DATEI=dialog.dlg

2. Please load the new dialog configurations with the following command now:

- a. UNIX systems:
hymw.out -u9999 -b db_sql/aip_qm_cavity.dlg
- b. Windows systems:
hymw.exe -u9999 -b db_sql/aip_qm_cavity.dlg

This will mean that the affected dialog(s) (currently only QEE_MW_ME_ES_PP_SI) are read **as default** (with type "DEF" and dialog user "999") and/or the existing one(s) is/are updated.

3. Copy the dialog QEE_MW_ME_ES_PP_SI from the default (type "DEF" with dialog user "999") to type "DEF" and dialog user "0" on MOC using the System settings→Terminals→Dynamic dialogs application (transaction code ddconf). For this purpose, you have to switch to HYDRA Professional Mode.
4. Activate the new dynamic dialogs:
 - a. UNIX systems:
hydialog.scr AIPTNR 0
 - b. Windows systems:
sh.exe hydialog.scr AIPTNR 0

Please note: This command will activate the default dialogs. If the system uses terminal-specific dialogs, these must be adapted by an MPDV consultant.

5. If terminal groups are used, the dialogs are to be copied to the relevant groups and activated for these terminal groups.