

1 Configuration for the Collection of Serial Numbers

Activation at machine/workplace

These configurations have to be made for the [machine / workplace](#) to enable the collection of serial numbers:

Parameter name	Value
Workplace configuration → Workplace master data → Workplace category	N Machine
Workplace configuration → Workplace master data → Workplace type	E Single workplace
Workplace configuration → MPL → Batch management	L Batch tracing (input/output batches)
Workplace configuration → MPL → Preceding material buffer	If required, define a preceding material buffer .
Workplace configuration → MPL → Subsequent material buffer	If required, define a subsequent material buffer .
Workplace configuration → MPL → Automat. generation of batch numbers	J Automatic generation of batch numbers for production batches (MPL) enabled

Maintain material types - for the operation

Maintain the [material types](#) to be defined for the operation and adapt them to your specific requirements of data collection.

Maintain material types – for components

Maintain the [material types](#) to be defined in the component list and adapt them to your specific requirements of data collection. Configure at least the following values for the component that is integrated as merged batch including assigned serial numbers in the operation:

Parameter name	Value
----------------	-------

Parameter name	Value
Input batch processing → Inventory management	R - Yes, backflush (retrograde)
General → Options → transferred at interface	Enable this option if you expect consumption postings or final backflushes (notification of goods receipts) for this material type. Then another configuration can be used to control the transfer of merged batches and serial numbers separately.

Maintain reasons

Maintain [reasons for scrap and rework as well as reasons for open quantities](#), if you use these quality classes.

Maintain transport units

Create [transport units](#) in the system if you want to use them for data collection. Assign transport unit ans according material type.

Assign material types to transport units

If you want to use [transport units](#) and you created them in the system, you may assign them to the [material types](#) maintained in the system and define a default transport unit for each material type. This one will then be selected in advance in the input dialog.

Perform the assignment in the [assignment of TPU to material type](#).

Activation at the operation

These options have to be set for the operation.

Parameter name	Value
Batch management requirement	Yes
Serial number requirement	A Collection of serial numbers

These options are available to edit this information:

Manual maintenance in the operation

Edit the options manually for the [operation](#)

Maintenance of processing code (customizing)

Edit the options for the [processing code](#).

Maintenance of the template (customizing)

Edit the options of the [processing code](#) with value "A" - collection of serial numbers and assign the processing code to an [operation template](#).

Explicit specifications for the interface (recommended procedure)

Explicitly transfer the options for the operation at the interface.

Activation in components list

Maintain the input quantity in the [component list](#) by entering "1.0" units for components listed as merged batch including assigned serials numbers. Assign the relevant material types to the components.

Activation of the link between serial number and input batch

For tracing it is necessary to link the incorporated input batches with the produced serial numbers. To enable this processing, a configuration has to be enabled in [INI configuration](#). The entry itself is part of the default delivery and only needs to be enabled.

Parameter name	Value
INI name	MPL
Section	SERIALNUMBER
Key	CONNECT_SNR_CNR
Value	Y
Active	Enable the entry

Configure batch attributes for data collection when recording serial numbers

If you want to enter batch attributes manually when collecting serial numbers, create the [batch attributes](#) to be recorded in the system in relation to the [material type](#) of the operation. To do so, maintain at least these configurations:

Parameter name	Value
Options → Capture attribute while generating batch	Enable the option.
Options → Position	Specify the position - the system sorts the configured attributes in an ascending numeric order (bottom up).
Data type	Maintain the data type and length of the attribute to be recorded

Control the generation of goods movements

Define for incorporated merged batches and serials numbers as well as for produced merged batches and serial numbers if you require goods movements subject to uploads to be provided. To do so, configure the following settings in [advanced object configuration](#):



The goods movement option has to be enabled for the relevant material type to be able to use this configuration.

Parameter name	Value
Configuration for goods issues (consumptions)	
Object type	MPL
Object ID 1	SNR - serial number SAM - merged batch
Object ID 2	MATTYP
Object ID 3	Material type the entry applies for
Object ID 4	CMM_A
Parameter	CREATE_MOVEMENT
Parameter value	Y

Parameter name	Value
<i>Configuration for goods receipts (generated material)</i>	
Object type	MPL
Object ID 1	SNR - serial number SAM - merged batch
Object ID 2	MATTYP
Object ID 3	Material type the entry applies for
Object ID 4	CMM_E
Parameter	CREATE_MOVEMENT
Parameter value	Y