

Manual

Cavity-Related Change in Partitioning BDE-NBT 8.1

Version 1.1.4716

Last changed on: 19.06.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Übersicht Nestbezogene Teiligkeitsänderung	4
2	Entering Cavity-Related Partitioning at AIP	5

1 Übersicht Nestbezogene Teiligkeitsänderung

Purpose

This component is used when you wish to perform and document a cavity-related change in partitioning or cavity.

Integration

The cavity-related change in partitioning is performed at the Windows-based BDE terminal. It represents an extension of the posting dialog "Change partitioning" (M_TLG) available in the BDE/MDE.

If you use the tool and resource management system (WRM) and its WRM-NST component, extended tests against WRM master data are possible.

Features

- Definition of reasons for the change in partitionings/cavities at the Windows-based BDE terminal
- Collection of cavity fade-in or cavity dimming at the Windows-based BDE terminal. Input of the cavity number, selection of a reason and entry of an optional comment
- Inspection of the partitioning at posting of the order against the partitioning of the tool resource (precondition: WRM-NST) and warning if exceeded.
- Display of a list for selection of a cavity and plausibility check of the cavity number against the cavities defined at the tool resource (precondition: WRM-NST).
- Reducing or increasing the partitioning of the machine and the active operation by the number of faded-in or dimmed cavities
- Additional activation/deactivation of the mold cavity master data and calculation of the current partitioning in the tool master data record (precondition: WRM-NST).
- Logging of the posting "Change in partitioning" as an event
- Display of the logged posting in the workplace/machine history (precondition: MDE-MMD).

Please note: The posting dialogs are activated during HYDRA customizing.

2 Entering Cavity-Related Partitioning at AIP

Usage

You use this function if you would like to access documentation relating to cavities that concern covering and uncovering tool cavities.

Integration

The partitioning defined on the selected operation is changed by modifying partitioning. Partitioning modifications are documented in machine history.

When tool and resource management (WRM) is used, the partitioning defined on the currently logged-on tool is also modified due to the effects of the cavity-related partitioning change.

Prerequisite

A relevant license is required for this function to work. The configuration requirements are described in the section [Configuration](#).

Display on the AIP

The M_TLG_NEST dialog can be configured on the AIP instead of the M_TLG dialog. This configuration is done at the time the system is customized by MPDV.

Description of function

When the dialog is opened, the order-specific information is extracted from the selected operation and displayed. Except for the "Comment" field, all fields must be filled in.

Cavity number (mandatory field)

The cavity number can be selected from a list (only when used with WRM) or entered manually.

Reason (mandatory field)

In the list of choices for a reason, reasons are displayed to choose from based on the selection criteria "Type of change".

Each reason must be configured in the "Reasons" configuration on the client separately by increase (reason type "E") or decrease (reason type "R").

Comment (optional field)

A comment for the posting can be entered here.

Staff badge number (mandatory field)

Staff badge number entry for the person to be logged on.



The cavity change is made on the server. Thus, a cavity change can only be made on the terminal in online mode, because otherwise the lists on the terminal cannot be updated.

Configuration

The configuration was set up in the default configuration file ctaipbut.ini as follows.

Standard configuration

```
...  
[MNR-ALL-Page2]  
;1=M_TLG_NEST,L,Kavität ändern,Objects.png  
1=M_TLG,L,Teiligkeit ändern,Objects.png  
...
```

Configuration after customizing

```
...  
[MNR-ALL-Page2]  
1=M_TLG_NEST,L,Kavität ändern,Objects.png  
;1=M_TLG,L,Teiligkeit ändern,Objects.png  
...
```