

Manual

PDV Escalation Messages PDV-ESK 8.2

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Overview: PDV Escalation Messages.....	4
2	Available Escalations	5
2.1	Overview of available events.....	5
3	Configuration PDV-ESK	7
3.1	Activate escalation messages	7
3.2	Define limits and activate automatic generation of errors.....	7
3.3	Further conditions	8
3.4	Debug options	8

1 Overview: PDV Escalation Messages

Purpose

HYDRA Escalation Management provides a framework of functions for prompt forwarding of recorded or live events to individual users or user groups. Escalation Management actively notifies users.

After notification, Escalation Management monitors times until acknowledgment by the recipients and until escalation is concluded. Escalations can be forwarded to other users or user groups during processing.

Implementation notes

You use Escalation Management if you would like to have active, prompt notification of specific events in the BDE production environment to react early enough to prevent downtimes.

Integration

The events/ escalations already triggered in the PDV environment are forwarded to central Escalation Management. This forms the framework for forwarding and following up on triggered events.

To notify staff, Escalation Management accesses both [User administration](#) and [HR master data](#) stored in the system. Notifications can be sent out as e-mails by integrating the local mail server into the system.

Features

- Provision of various escalation messages for Process Data Collection such as "action limits exceeded" or "tolerance limits exceeded".
- Event configuration: configuration of order-related events.
- Forwarding of detected events to the framework of Escalation Management.

2 Available Escalations

2.1 Overview of available events

event_id	event_name	
PPMM.ACTION_LIMIT_EXCEEDED	Action limit* exceeded	PDV71 PDV72 PDV81
PPMM.TOLERANCE_LIMIT_EXCEEDED	Tolerance limit exceeded	PDV71 PDV72 PDV81

* In PDV, the "action limit" is the process action limit

Event	Description	Acronyms	Description	Notes
PPMM.ACTION_LIMIT_EXCEEDED	Process action limit exceeded	MNR.MNR	Machine number	The terminal triggers an escalation if a violation of the process action limit is identified.
		PPMM.MMNR	Characteristic number	
		MM.BEZK	Characteristic designation/name	
		MM.BEZL	Characteristic designation/name	
		MM.EINH	Unit	
		PPMM.MW	Measured value	
		PPMM.SW	Target value	
		PPMM.OTG	Upper tolerance limit	
		PPMM.UTG	Lower tolerance limit	
		PPMM.OPEG	Upper process action limit	
		PPMM.UPEG	Lower process action limit	
PPMM.TOLERANCE_LIMIT_EXCEEDED	Tolerance limit exceeded	MNR.MNR	Machine number	The terminal triggers an escalation if a violation of the tolerance limit is identified.
		PPMM.MMNR	Characteristic number	
		MM.BEZK	Characteristic designation/name	
		MM.BEZL	Characteristic designation/name	
		MM.EINH	Unit	
		PPMM.MW	Measured value	
		PPMM.SW	Target value	
		PPMM.OTG	Upper tolerance limit	
		PPMM.UTG	Lower tolerance limit	
		PPMM.OPEG	Upper process action limit	
		PPMM.UPEG	Lower process action limit	
PPMM.ALARM_CHANNEL_SET	Alert channel is set	MNR.MNR	Machine number	Characteristic number, name, unit and measured value only if the alert is triggered by a violation of the limit value.
		PPMM.MMNR	Characteristic number	
		MM.BEZ	Characteristic designation/name	
		MM.EINH	Unit	
		PPMM.MW	Measured value	
		EV.EVENT	Event	

Event	Description	Acronyms	Description	Notes
		EV.CAPTION	Event name	Event and event name only with triggering event.

3 Configuration PDV-ESK

3.1 Activate escalation messages

Escalation messages are activated in the terminal. The configuration file `pdv_dll` is stored in the directory "`ctwin`" or "`ctaip`". In this file, you can modify the `CallESK` parameter. By default, the function is disabled and set to "`N`". The function is enabled if the parameter is set to the value "`Y`".

Excerpt from the file `pdv_dll.ini`:

```
[Common]
; # @Eskappendix:      file ending of captured escalations
Eskappendix=pesk
[Blade]
; # @CallESK:          flag whether escalation messages should be sent when limits are exceeded
; #                   supported values are Y (Yes, send messages) and N (do not send messages)
; # @ESKWaitTime:      time interval that has to pass before escalation messages are sent
; #                   successively
CallESK=Y
ESKWaitTime=600
```

3.2 Define limits and activate automatic generation of errors

MOC: Quality management - Process data collection - Collection rules. Go to: *Recorded characteristics*, tab *Specifications*

Here, you can define the limits mentioned below. These limits specify when an automatic error and a resulting escalation are generated. The limit value must be a valid decimal value and the option that enables the automatic generation of errors must be checked.

You may include the following limits in an escalation:

LTL	lower tolerance limit
LPAL	lower process action limit
UPAL	upper process action limit
UTL	upper tolerance limit

3.3 Further conditions

MOC: Quality management - Process data collection - Collection rules. Go to: *Recorded characteristics*, tab *Inspection - Computation*

Enable the option "Check characteristic".

In addition, the process parameter you want to evaluate must be of data type INTEGER or DECIMAL.

3.4 Debug options

You can easily trace back the correct configuration using the file pdvinitpp.2<terminal no>. The section including the process parameters is most important. The following must apply for the process parameters:

CHECKLIMITS	Y	(merkmal_pruef / [v] check characteristic)
DATATYPE	DECIMAL or INTEGER	
ESKUPIL	Y	(opeg_aktiv / in specification dialog : [v] auto. generate error for UPAL)
ESKUTL	Y	(otg_aktiv / in specification dialog : [v] auto. generate error for UTL)
ESKLTL	Y	(utg_aktiv / in specification dialog : [v] auto. generate error for LTL)
ESKLPIIL	Y	(upeg_aktiv / in specification dialog: [v] generate auto error for LPAL)
UPIL	integer	(UPAL (must not be empty or (null) if ESKUPIL= Y))
UTL	integer	(UTL (must not be empty or (null) if ESKUTL=Y))
LTL	integer	(LTL (must not be empty or (null) if ESKLTL=Y))
LPIL	integer	(LPAL (must not be empty or (null) if ESKLPIL=Y))