

Manual

Control of Room Zones, Elevators, Security Gates ZKS-RAS 8.1

Version 1.1.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Control of Room Zones, Elevators, Security Gates - Overview	4
2	Room Zones.....	5
3	Room Zone Overview	7
4	Elevator Control	9
5	Security Gate Control.....	10

1 Control of Room Zones, Elevators, Security Gates - Overview

--	--	--

Fields of application

In combination with the access control module, this function package allows to record the presence of employees in room zones, to control elevators with different authorizations for each floor and to map checkpoints where only one door may be opened at a time in the system.

Implementation notes

You use the function package if you:

- use the HYDRA access control system (ZKS) and wish to monitor room zones, control elevators or checkpoints

Integration

This function package can only be used if the HYDRA access control module is in use (function package *administration functions, access control*).

Features

- Room zones
 - Definition of room zones and by which entrances these room zones are entered or exited
 - Checking of presence or absence when entering or leaving a room zone
 - Room zone overview to show the employees who are currently present or who were present at a point in time in the past
 - Editing function to log staff in and out
- Elevator control
 - Elevator control with different authorizations for each floor
- Security gate control
 - Definition of room zones and by which entrances these room zones are entered or exited

2 Room Zones

Summary

Menu	Master data → Access control → Room zones
Transaction code	rozo
Function authorization	rozo

Room zones can be used to verify whether or not employees are present in specific rooms or areas. Room zones can be entered and exited using access points. This can be configured along with the [access points](#).

Validation checks may be enabled to make sure that an employee may only enter a room zone if he/she is not already present or may only leave it if he/she is already present.

A maximum occupation rate can be defined for room zones. Consequently, employees might be rejected if the parking lot is full, for instance.

Two requirements need to be met to be able to use room zones:

1. Both, the entries and the exits need to be controlled by access control.
2. It has to be ensured that all employees log in and out individually at the entries and exits. This can either be realized by an organizational or technical approach (e.g. turnstiles).

Field description

Room zone, designation

Number of the room zone and its name

Responsibility area

Responsibility area which the room zone is assigned to. The responsibility area is checked when editing this configuration and, in addition, it is also verified whether or not the "use" authorization is available when room zone assignments are created, changed and deleted within the [room zone overview](#).

Validation checking upon entry, validation checking upon exit

These two options specify whether the entrance into the room zone is denied if the badge is already present in the room zone or whether the exit from the room zone is denied if the badge is not present in the room zone.

Log attendance in room zone

By this option, past periods when an employee was present in the room zone can be recorded. These logs can be viewed using the [room zone overview](#). If logging is disabled, the room zone overview only shows the currently present employees and these entries are deleted when the employee exits the room zone.

Maximum occupancy

The maximum number of employees that may be present in the room zone can be configured here. Any further access attempt will be rejected and recorded including the reason "Room zone completely occupied" within the [access log](#), once this maximum number has been exceeded.

Channel for max. occupancy

The channel specified here is triggered at the ZKS terminal if the maximum number of employees that may be present in the room zone has been reached. This channel can trigger, for example, lights (red/green traffic lights).

3 Room Zone Overview

Summary

Menu	Human resource management → Access control → Room zone overview
Transaction code	rzov
Function authorization	rzov

Those employees, who are or were present in a [room zone](#) are displayed in the *room zone overview*.

Room zone overview

Main page Profile

Request data Cancel Print preview Print all Insert Copy Edit Delete Save Help on operation Help on application Help on detail application Help

Selection

Badge ... to ...

Room zone ... to ...

☐ Currently present people
☒ Past entries and exits

Date from 1/1/2011 to 2/28/2011

Time from 0:00 to 24:00 ☐ Show deleted

Room zone overview

Drag a column here to group by that column

Badge	Name	Person	Com...	Room zone	Designation	Status	Acc
2458	Meyers, Harald	50201	BSP	1	Admin. Building	Attendance	
2455	Albert, Claudia	50014	BSP	1	Admin. Building	Exit	
1458	Meyers, Joseph	85741	BSP	1	Admin. Building	Exit	
2458	Meyers, Harald	50201	BSP	3	Production Hall	Entry	
2455	Albert, Claudia	50014	BSP	1	Admin. Building	Exit	
1458	Meyers, Joseph	85741	BSP	3	Production Hall	Entry	

Room zone overview

Badge 2458 ...

Person 50201 ...

Company BSP

Room zone 1 ...

Designation Admin. Building

Status Attendance

Entry

Access 1 ... East Entrance SF

Date 1/23/2011

Time 10:01

Selection criteria

The following selection criteria are available in the application:

Currently present people/ Past entries and exits

This option can be used to select whether the currently present employees or the logs of past presences shall be displayed.

Show deleted

When this button is activated, also deleted loggings will be shown. The columns *Editor*, *Modified on* and *Deleted* lead to more details on deleted loggings.



The loggings of room zones can be modified since it might happen, for example, that an employee leaves a monitored room without that this exit is recorded. This might be the case if the employee leaves in the same time as another person present. If the plausibility check for presences in the [room zone](#) is active, this employee must not enter the room again since the access control assumes that he/she is still within the room zone.

4 Elevator Control

Summary

The elevator control allows for several entrances (floors) to be controlled via one reader. When a badge is read, the terminal checks all entrances (floors) that are configured for this reader and releases the door opener contacts of the authorized accesses, which are linked with the pushbuttons of the elevator and release the appropriate buttons.

The door status contact indicates which button was pushed. Provided that the door status contacts are configured in accesses, the access protocol is only generated, once a button has been pushed and thus it is possible to check in the access protocol which floor the employee entered. In case the door status contacts are not configured in entrances, an access protocol is generated for each authorized floor. Thus, it may be checked who might be in a floor, however without knowing whether the employee has actually entered this floor.

A separate access/entrance is created for every floor of an elevator control. Consequently, each floor may have different authorizations. If several accesses/entrances are created for one reader it is verified that the floor number is unique. The floors are defined in the “advanced settings” tab of the [access](#).



Online-checks are not performed for the elevator control to avoid one or several online checks from being made every time the elevator is used by employees who are not allowed to enter all floors.



A maximum of nine entrances and, as a result, nine floors may be managed by one ZKS terminal.

5 Security Gate Control

Summary

A security gate consists of two or several entries. Only one entry may be opened at a time. Access is denied in case an entry is already open when trying to open another entrance.

A security gate can be configured within the field “security gate with access point” in the “advanced settings” tab of the [access](#).

To enhance the security gate by another entrance, the new entrance number is to be entered in one of the two entrances.

The access by way of which the security gate has been configured cannot be changed. However, accesses that have not yet been assigned to a security gate may be added to an existing one or entrances may be removed from a security gate.



All entries of a security gate have to be connected to the same HYDRA-ZKS terminal.



The access status has to be monitored for all entrances in order to be able to monitor a security gate. The “maximum duration of open access” and “relay time door opener” have to be set for this purpose.