

1 Barcode Input with Prefix

A barcode is interpreted as prefix barcode if the third character is a dot. In this case the first two characters identify the barcode type. The actual barcode starts with the fourth character.

ID+ Prefix	Example	Comment --> processing
-----	-----	---- General ---
00.	00.ABC123	Data not defined, → 00. will be deleted and "ABC123" will be passed on to standard processing
01.	01.OK 01.ESC	Action barcode → Dialog cancelled or ended with OK button or Esc button.
-----	-----	---- HYDRA-ADE + HYDRA-LLE + HYDRA-MDE ---
10.		(combined) Order/sequence/OP number → acronym <ANR>
11.		Order (header) → acronym <AUNR>
12.		Sequence → acronym <AFOLG>
13.		OP → acronym <AGNR>
14.		Sub-order number -> Acronym <UAGNR>
22.		Split no. → acronym <SPLNR>
15.		Upload/confirmation number → Acronym <RMNR>
16.	16.EXTRUDER-7 16,200	Machine → Acronym <MNR> → Passed on to dialog with MNR=EXTRUDER-7 or MNR=200
17.	17.1 17.1001	Machine status → Acronym <MST> → Passed on to dialog with MST=1 or MST=1001
18.	18.1 18.1001	Scrap reason → Acronym <EGG:AUS> → Passed on to dialog with EGG:AUS =1 or EGG:AUS=1001
19.	19.1 19.1001	Deviation reason → Acronym < EGG:GUT > → Passed on to dialog with EGG:GUT =1 or EGG:GUT=1001
20.	20.1 20.MF	Operator position → Acronym <BPOS> → Passed on to dialog with BPOS =1 or BPOS = MF
21.		Wage and premium indicators → Acronym <LPKZ>
-----	-----	----HYDRA-WRM + HYDRA-DNC + HYDRA-PDV + HYDRA-MPL ---
40.	40,100 40.MONTAGE	Destination → Acronym <ZLO> → Passed on to dialog with ZLO=100 or ZLO= MONTAGE
41.	41.KARTON 41.KISTE	Transport unit → Acronym <TPE> → Passed on to dialog with TPE = KARTON or TPE = KISTE
42.		Batch number → Acronym <CNR>→→
43.		Throughput batch number → Acronym <DLL>→→
44.		Alternative batch number → Acronym <CNR:ALT1>→→
45.		Alternative batch number → Acronym <CNR:ALT2>
46.		Alternative batch number → Acronym <CNR:ALT3>
47.		Alternative batch number → Acronym <CNR:ALT4>
48.		Alternative batch number → Acronym <CNR:ALT5>
49.		Alternative batch number → Acronym <CNR:ALT6>

ID+ Prefix	Example	Comment --> processing
-----	-----	---- Mainly for the HYDRA-PZE module ---
50.		Badge number → Acronym <KNR>
51.		Personnel number → Acronym <PNR>
52.	52.EDV 52.VERTRIEB	Cost center → Acronym <KST> → Passed on to dialog with KST=EDV or KST=VERTRIEB
53.	53.1 53.1001	Absence reason → Acronym <FGR> → Passed on to dialog with FGR=1 or FGR=1001
-----	-----	---- Customer-specific barcodes ---
90.		
...		

In case barcodes are required, which actually have a dot at the third place (e.g. if the machine/workplace number has a dot as third character), it is possible to define an alternative indicator for barcode prefixes in the HyTnrCfg.ini terminal configuration, e.g.

[Terminal->USR 0]

BarcodePrefixChar=\$



If another prefix is actually required, the respective barcode font in use must be able to represent this prefix.

Examples for barcodes

Barcode printing: Font "Codedreineun" and prefix "."

Prefix	Barcode	Raw data
10.	*10.123456780100*	ANR = 123456780100
	10._ABCD12340100	ANR=_ABCD12340100

Prefix	Barcode	Raw data
11.	*11.12345678*	AUNR = 12345678
12.	*12.01*	AFOLG = 01
13.	*13.0100*	AGNR = 0100
14.	*14.0000*	UAGNR = 0000
15.	*15.123456789012345*	RMNR = 123465789012345
22.	*22.02*	SPLNR = 02

Prefix	Barcode	Raw data
16.	*16.123456*	MNR = 123456
17.	*17.1122*	MST = 1122
18.	*18.1234*	EGG:AUS = 1234
19.	*19.123456789*	EGG:GUT = 132456789
20.	*20.13*	BPOS = 13
21.	*21.1221*	LPKZ = 1221

Prefix	Barcode	Raw data
50.	*50.1337*	KNR = 1337

1.1 Configuration of customized barcode prefixes

Section [barcode]	
BarKenn90=SAPCNR BarKenn91=EGR:GUT	The barcode prefixes 90...99 can be assigned here according to the customer's requirements. This means, if a barcode with the relevant prefix is used, it will be transferred to the dialog along with the assigned ID. Then the barcode has the following structure: <Prefix>.<Net barcode> e.g.: "90.12345" → SAPCNR=12345

Firmly assigned barcode prefixes:

10:ANR 53:FGR

11:AUNR

12:AFOLG

13:AGNR

14:UAGNR

15:RMNR

16:MNR

17:MST

18:AUSGRD

19:AGGGRD

20:BPOS

21:LPKZ

22:SPLNR

40:ZLO

41:TPE

42:CNR

43:DLL

44:CNR:ALT1

45:CNR:ALT2

46:CNR:ALT3

47:CNR:ALT4

48:CNR:ALT5

49:CNR:ALT6

50:KNR

51:PNR

52:KST

