

1 AIP2 - Local Configurations File ctaipbut.ini

Buttons are configured for specific terminals in the file ctaipbut.ini stored in the terminal directory c:\MPDV\AIP2.

The button pages of the main view and the OP info dialog may be configured in the configuration file ctaipbut.ini.



The buttons can only be configured like this in the main view if the new design of the AIP2 has been deactivated.

The server directory \<serverDir>\ctnet\win\aip2 contains the complete INI files of the standard. Deviations from this are created in the customer-specific directories provided for this purpose, e.g. \<serverDir>\1\custom\aip2\tgrp_901.



Create the corresponding, empty file (e.g.: ctaipbut.ini) in this directory. Copy all sections e.g. [ANR-ALL-Page1] to this file. The configuration is performed in this file.

After the terminal restart a merge (summary) of the files from the root directory \<serverDir>\ctnet\win\aip2 with the files of the custom directory \<serverDir>\1\custom\aip2\tgrp_901 takes place, which are transferred locally to the terminal in the directory c:\MPDV\AIP2.



All sections including the string "-Page" are imported.

Entry	Comment
Definition of sections [LST-MODUS-PageX.]	General schematic structure of a button page Definition of a section LST = List identifier of the button page (MNR, ANR, LIST3) MODUS = Mode of the machine LN = MPL – Mode DN = DLL – Mode LR = RF – Mode (reel-based manufacturing) LS = RS – Mode (cutting reels) LC = Handling unit (packing station) or XX = <MPL_MOD>[1] + <TYPE>[] YY = Value from the MNR.LST column <MNRBTN.MODUS> Otherwise if no applicable entry is found for the machine mode, the section ...ALL will be used (if available) X = Button page The definition specifying the mode a machine is running on is implemented in the AIP application program.
Sample configuration [MNR-...-Page1] 1=A_AN, L, log on OP 2=BLANK, L 3=\$MPL-PAL\$PAL_AN,L,log on pallet, 4=%BART:PZE=J%PZE,R,PZE,PZE. PNG <u>Note:</u> In one section numbering of entries <u>must</u> be consecutive from 1...n. A gap in numbering indicates the completion of a page!	<u>General structure:</u> x=<Function>,<Alignment>,<ButtonName>,<Icon> For example: 1=A_AN,L,log OP on,AGAN.PNG - Function A_AN - Alignment L or R (from the first "R" on always "R") - ButtonName Log on OP - Icon optional icon name (PNG, resolution 24x24 px) <u>Special functions:</u> \$...\$ (e.g. \$MPL-PAL\$) License check fails → Button is deleted %...% (e.g. %BART:PZE=J% .) Check field with value in (T)terminal (K) label → only show if they match BLANK Insert distance between buttons

Entry	Comment									
Configuration of functions using wildcards x=A_AN*,L, log on OP x=A_UN*,R, interrupt OP	The dialog to be opened is located as described below if buttons are configured using wildcards ID A_AN* - Calling dialog: A_AN - Identification of the machine type - Supplementing the dialog based on the machine type - Check whether or not the dialog is available if this is the case - calling dialog: A_AN_MPL - Evaluation of the posting type (only with A_AN) - Supplementing the dialog based on the <i>posting type</i> - Check whether or not the dialog is available if this is the case - calling dialog: A_P_AN_MPL - Calling up the located workflow or dialog If the function is <A_UN*> or <A_AB*>, it will be checked whether or not the OP to be logged off is a merged OP. - If this is the case, <A_UN*> is changed into <SA_UN> or <A_AB*> into <SA_AB> If the virtual column <MNRDLG.SUFFIX> includes a value, it will always be used (if available). <table><tr><td>ButtonFkt</td><td>MNRDLG.SUFFIX</td><td>Dialog</td></tr><tr><td>e.g. A_AN*</td><td><XYZ></td><td>A(_P)_AN_XYZ</td></tr><tr><td>A_TR*</td><td><ABC></td><td>A_TR_ABC</td></tr></table>	ButtonFkt	MNRDLG.SUFFIX	Dialog	e.g. A_AN*	<XYZ>	A(_P)_AN_XYZ	A_TR*	<ABC>	A_TR_ABC
ButtonFkt	MNRDLG.SUFFIX	Dialog								
e.g. A_AN*	<XYZ>	A(_P)_AN_XYZ								
A_TR*	<ABC>	A_TR_ABC								
Further standard buttons: P_SPERRE VIEW ICON PDV_ISTW WF_BDE_KOM SA_AN DNC MINIMIZE	Lock status "production" Switching of the basic view: List view ↔ presentation of individual machines Calling up icon view (only possible if configured in the machine configuration) Calling up the actual value view of PDV Input of BDE comments Log on merged operation Calling up the DNC startup screen Minimizing of the terminal program → Windows 7 requires the compatibility mode XP									
USER1...USER9	User-defined buttons showing and starting external software The programs are configured in the section [ext. software] of the ctaip.ini file									
Button IDs for the machine info [MNR-ALL-Page2] 1=M_INFO.INFO,L, show information 2=M_INFO.PERS,L, staff 3=M_INFO.MSPROT,L, machine status log	Consequently, the relevant info dialog including the selected page is opened in the foreground. Switching to other pages is allowed. M_INFO may be used to show the info page in the foreground: M_INFO=M_INFO.INFO									

Entry	Comment
Button IDs for OP info: <pre>[ANR-ALL-Page3] 1=A_INFO.DOKU,L,documents 2=A_INFO.HILF,L,production resources and tools 3=A_INFO.KOMP,L,components 4=A_INFO.BMK,L,RPA 5=A_INFO.FORT,L,progress 6=A_INFO.NOTE,L,notes A_INFO.TEXT1,L,User text1 A_INFO.PICT1,L,User image1 A_INFO.SCRINF1,L,User scriptInf1 A_INFO.DIALOG1,L,User dialogs</pre>	Consequently, the relevant info dialog including the selected page is opened in the foreground. Switching to other pages is allowed. A_INFO may be used to show the information page in the foreground: <pre>A_INFO= A_INFO.INFO</pre> Direct call of user-defined pages configured in the section [OP info] of the ctaipbut.ini file. Example: Dialog1=WF_BDE_KOM_LIST,BDE comments <pre>→ A_INFO.DIALOG1,L,BDE comments</pre>
Configuration of a function with different modes Just as it is the case for the configuration of the ANR/MNR info tabs, a function can be configured with different modes. <pre>1=RES_WART.MNR,L,machine maintenance 2=RES_WART.RES,L,resource maintenance 3=RES_WART,L,other maintenance</pre>	In the configured examples, the dialog < RES_WART > is requested with the below-mentioned modes. <pre>1 < MNR > 2 < RES > 3 without mode</pre> The values can be read out as follows in the terminal script. <pre>VPar("BTN.FKT") Function + mode VPar("BTN.FUNC") Function VPar("BTN.MODE") Mode</pre>

Entry	Comment
Available button sections and buttons for pages of the OP info dialog: [A_INFO-Page1] [A_INFO.DOKU-Page1] 3=AI_VIEW,R,open document 4=AI_VIEW_CLOSE,R,close document [A_INFO.HILF-Page1] [A_INFO.KOMP-Page1] [A_INFO.BMK-Page1] [A_INFO.FORT-Page1] [A_INFO.NOTIZ] [A_INFO.DEFAULT-Page1] Recommended for all pages: 1=AI_CLOSE,L,close information OP	Overview Document view Production resources and tools Components Resource Performance Accounts (RPA) Progress bar Notes Configuration of a default page (used if no section is defined for the tab). The IDs may also be used for the keys in the dynamic dialog (field "function").
Available button sections and buttons for pages of the machine info dialog: [M_INFO-Page1] [M_INFO.PERS-Page1] 2=P_AN,R,log person on 3=P_AB,R,log person off 4=P_AAB,R,log everyone off [M_INFO.MSPROT-Page1] [M_INFO.DEFAULT-Page1] For all pages: 1=MI_CLOSE,L,close machine information	Overview Staff logged on Machine status log Configuration of a default page (used if no section is defined for the tab).

Entry	Comment
Definition of sections [ButtonPanel]	General section for the configuration of global settings for all used button panels → 2 in main view (MNR , ANR) → (W)ork(F)low
functionkey_visible=on	Shows function keys (e.g. "F3") in button panels in order for the selection to be made using function keys (by default = off).
radiobuttonkey_visible=on	Presentation of function keys in radio group boxes of a workflow (by default = off).
functionkey_pze_visible=on	Display of function keys in PZE module (by default = off).
Definition of sections [LIST3-ALL-Page1]	General section configuring functions of the configurable third list of the main screen. INFO: The different types of the "3rd list" are configured in the machine label. The layout of a "3rd list" is defined in the "hytnrcfg.ini" file. → All used lists have to be configured with their identifier „“ as follows. → When changing machines, the "3rd list" is hidden/shown and buttons for "3rd lists" that are not configured are disabled.
as of CTAIP V# 2.0.2.33 <u>..=~<VISLIST-ID>~,L,,<PNG-File></u>	
The characters "~" (or previously "S", should no longer be used) have been designed to identify third list buttons. Correct processing/updating (disabled/enabled) is only possible in the third grid list of the main screen.	
1=~M~,L,,PALETTE20x20.PNG	Entry for "material list" → "[VISLIST3(M)]" from "hytnrcfg.ini"
2=~P~,L,,PERSON20x20.PNG	Entry for "list of persons" → "[VISLIST3(P)]" from "hytnrcfg.ini"
3=~R~,L,,RESS20x20.PNG	Entry for "MNR_AMAT.LST" → "[VISLIST3(R)]" from "hytnrcfg.ini" with the configured Bitmap "
4=~A~,L,,NUM.PNG	Entry for "material list" → "[VISLIST3(A)]" from "hytnrcfg.ini"
5=~G~,L,,PERSON20x20.PNG	Entry for "list of persons GWP" → "[VISLIST3(G)]" from "hytnrcfg.ini"