

1 AIP2 Operation

1.1 Special Control and Display Elements on the AIP2

Tables

Uniform selection lists are used in AIP 8.2 posting dialogs:

Filter	
Status	Status
1	PRODUCTION
2	SETUP
3	ORDER SHORTAGE
4	OUT OF MATERIAL
5	OUT OF STAFF
6	START UP
22	COLOUR CHANGE
97	ELECTRICAL FAILURE
98	MECHANICAL FAILURE
99	GENERAL DISTURBANCE

Page 1 • Page 2

If information is available for more than one page, the page numbers are displayed below the table. The current page is highlighted in bold letters. If the user clicks/touches a page, the display directly changes to this page.

If more pages are available than the page numbers displayed, the following buttons can be displayed on the left or right hand side depending on the context (available as of SP10/2016):

-  : If you click this button, the system jumps to the first page of the next page navigation. This means: If *Page 1 ... Page 9* were displayed for the page navigation, the system jumps to *Page 10*.
-  : If you click this button, the system jumps to the first page of the next page navigation. This means: If *Page 10 ... Page 18* were displayed for the page navigation, the system jumps to *Page 9*.
-  : If you click this button, the system directly jumps to *Page 1*.
-  : If you click this button, the system directly jumps to the last page.

You can select an operation using the mouse, touch screen, keyboard (arrow keys: '↑' or '↓'), scanner or by entering it manually.

The content of tables or lists depends on the respective context. Example: When you log on an operation, those operations are available that are included in the sequencing list or planned for the respective workplace or group. When you interrupt an operation, only running operations are available for selection.



Scrolling page by page (up or down) in the table.



Scrolling to the left or right. Only those buttons are activated that make sense for the current situation (context sensitive). This figure shows that scrolling to the left has been deactivated.



Optionally you can display a “table filter” (customization). This is an automatic filter that, once it has been entered, directly affects the table without having to update it. This process is realized through full-text search for (defined) columns. The search is *case-insensitive*.

Virtual keyboard

Using the virtual keyboard, you can enter data manually via touch screen or a connected mouse. The virtual keyboard is displayed automatically as soon as the focus is on an input field. The keyboard layout, which is installed and activated in the Windows language settings, specifies the layout of the virtual keyboard.



Moving the virtual keyboard



Hiding the keyboard for 10 seconds



Switching between the alphanumeric and numeric keyboard



Selecting the keyboard layout (language)



Changing the scaling/size of the keyboard



To move the keyboard, you must configure the driver accordingly (configuration in the control panel of the terminal/PC)!

If you do not want to display the virtual keyboard in general, you must enter the parameter `-t` in the entry `parameters=` of the configuration file `ctaip.ini`.

Date display

AIP supports a country-specific date format in dynamic dialogs. The option "short date" has to be selected in the "regional settings" of the Windows "control panel" of the terminal/PC. Please note:

- Years are always four characters long.
- Months and days are always 2 characters long.
- Allowed separators are: '-' (minus), '/' (backslash) and '.' (dot).
- Blanks must not be included in the "short date" format, i.e. the <BLANK> separator is not allowed.
- The date separator "." (dot) is only allowed in connection with the DD.MM.YYYY format.
- The date format, which might possibly be configured in dynamic dialogs, is ignored.

Examples

- | | |
|-----------------------|------------|
| • English(USA) | MM/DD/YYYY |
| • Danish | MM-DD-YYYY |
| • Customer-specific 1 | YYYY-MM-DD |
| • Customer-specific 2 | YYYY/MM/DD |
| • Customer-specific 3 | MM/YYYY/DD |

Note

If the date format used is other than the permitted formats, a note appears when the program is started and the date format is set to MM/DD/YYYY.

In the status bar, the year format is shortened and displayed only with two characters.

1.2 General description of the posting process on the AIP2

Many AIP posting dialogs are divided into several views (sub-dialogs). These views (sub-dialogs) cover the entire screen so that only one dialog is visible at a time. In a “workflow concept” the user is navigated through the posting dialog step by step. In the following, this process is described using the example *Interrupt operation*. Other posting dialogs are operated in the same way.

The action *Interrupt operation* is performed. To start this action, you click the button *Interrupt* when you have selected an operation:

Interrupt

The dialog *Interrupt operation* opens and the first view (sub-dialog) is displayed. The header displays the function that is currently being executed (here: *Interrupt operation*).

The screenshot shows the 'Interrupt operation' dialog for 'S61003050100 InjectionMolding at workplace 60610'. The dialog is divided into three steps: 1. Enter quantities, 2. Choose status, and 3. Confirmation. The first step is active.

Annotations:

- 1st view (sub-dialog):** The views are run through one after the other.
- Posting that is currently being performed:** Points to the 'Interrupt operation' header.
- Quantities already recorded (yield, scrap):** Points to the 'Yield' and 'Scrap' input fields.
- General OP data:** Points to the 'Operation 0100 InjectionMolding' section.
- Active input field:** Points to the 'Yield' input field.
- Virtual keyboard:** Points to the numeric keypad.

General OP data:

Prod.Order	S61003050100	Target qty.	90000 PCS
Article	SAR-FMO011-K-5013	Yield	1442 PCS
	Mirror housing right, blu	Scrap	33 PCS
		Completion	1%

Yield **Scrap**

Virtual keyboard:

7	8	9	←	0 DIMENSIONAL DEVIATION
4	5	6	-	0 DIRT
1	2	3	→	0 OTHERS
0	,			0 SCRATCHES
				0 SETTING ERROR
				0 TOLERANCE EXCEEDED

Buttons: Cancel, Go on

Footer: mpcv, UK flag, 04.12.15 15:10:28

In the first dialog *Enter quantities*, the user can enter the produced yield or scrap quantities. Subject to the active input field, the virtual keyboard is shown or hidden automatically.

Quantities can be entered using the virtual or real keyboard. The user can go to the next field using the tabulator key (which can also be found on the virtual keyboard). When the user has entered all values in the first view, the next view (sub-dialog) can be opened by clicking **Next**.

The **Cancel** button is displayed in all sub-dialogs. Click this button to cancel/close the entire process at any time.

To open the next view (**Select status** in the example), click the **Next** button or another tab (in our example: **Select status** or **Confirmation**). Please note in this context, that no view can be skipped when they are navigated upwards (view 1 → view 2 → view 3). This means: When you are in the first view (*enter quantities*) and you click the third view (*confirmation*), the second view (*select status*) will be displayed first.

Vice versa, when navigating downwards (e.g. from the *confirm* view to the *enter quantities* view), each view can directly be opened by clicking the required tab. In this case, views can actually be skipped. Using the **Back** button, views are opened one after the other (upwards).

As long as the dialog has not been confirmed, the data entered can be changed at any time by scrolling back and forth.

Filter field for the list

Status list

In the second view *Select status*, you select the workplace status that is set, when the operation has been interrupted. You can select the status from the status list displayed. This list can be restricted using the *Filter* field. Once the required values have been entered, the next view/sub-dialog can be opened by clicking **Next** (in our example it is the last view).

Interrupt operation S61003050100 InjectionMolding at workplace 60610

1 Enter quantities 2 Choose status 3 Confirmation

Operation 0100 InjectionMolding

Prod.Order	S6100305	Target qty.	90000 PCS
Article	SAR-FMO011-K-5013	Yield	1442 PCS
	Mirror housing right, blu	Scrap	33 PCS
		Completion	1%

Workplace 60610 ENG21

New status OUT OF MATERIAL

Entered quantities

Yield	5
Scrap	0

Staff Number

Workplace data

Quantities posted for the OP

Input field for the badge number

Cancel Back Interrupt OP

04.12.15 15:15:45

The sub-dialog *Confirmation* shows a summary of all values entered in the dialog. If the user agrees with the entered data, the **Interrupt operation** dialog can be confirmed, once the badge number has been entered. Then the dialog is sent to the server and posted.

If an input field of the dialog is not completed properly (e.g. a mandatory field is empty), the field is highlighted in red in the respective view and gets the focus. The user can then directly correct the value.



If a workflow dialog is opened, you can click the ESC key to directly exit the dialog. This exit is also possible, if the virtual keyboard is displayed. As a consequence, you cannot use the ESC key to close the virtual keyboard.